


TRACTOR - - MODEL NUMBER 7177A89


CHASSIS AND ENCLOSURES



Ref #	Part Number	Qty	Description
1	160392		CHASSIS
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
5	155272		BUMPER-HOOD/DASH
9	161917X012		DASH
10	72140608		SUB= 72110608
11	155927		"PANEL-DASH,LH"
12	145660		CLIP.TINNERMAN
13	155936		"PANEL-DASH,RH"
14	17490608		SCREW LT
17	159639X418		HOOD.STEEL.ASSY
18	126938X		SUB= 532126938
20	156437		"PLATE-MTG,BATT/FU"
23	124028X		SUB= 532124028
25	19131312		WASHER
26	73800600		NUT
28	157428		GRILL
29	146654		LENS.EURO.W/DECAL
30	151287X418		FEND/FTREST PNT
31	139976		BRACKET SUPT FEND
33	145244X418		FOOTREST.LT.LT/GT
34	145243X418		FOOTREST.RH.LT/GT
35	72110606		BOLT
37	17490508		SCREW LT
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	161464		SCREW.HEX.WS.HD
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	150127		AIR DUCT
60	72140606		BOLT
64	154798		DASH-LOWER
74	73680400		SUB= 73690400
140	158418		BRKT SUSPENSION
142	156095		PLATE.REINFORCEMT
143	154966		"BRKT-S'BAR,CHASSI"
144			CHECK WITH SUPPLIER
145	156524		"ROD POVOT,CHASSIS"
	5479J		PLUG BUTTON T

TRACTOR - - MODEL NUMBER 7177A89

DANA TRANSAXLE - MODEL NUMBER 4360-128




Ref #	Part Number	Qty	Description
1	160955		HOUSING.UPPER(5305-P)
2	2274J		SUB= 74760412
3	134400		SUB= 68003
4	105904X		"SPRING, DETENT LT"
5	160940		SCREW.TAPPING.1/4-20X.734
6	138235		KIT SHIFTER ASM
7	108727X		SUB= 108776X
8	148266		SUB= 105911X
9	148269		SEAL.OIL.DAN.5508
10	2225J		RETAINING RING LT
11	134793		ASM KIT SHIM 4689
12	148268		BEARING.FLNG.5511
13	120415X		WASHER T
14	142674		KEY WOODRUFF-DANA
15	161563		INPUT SHAFT KIT 6250
16	161564		PINION.BEVEL.12T(5620)
17	105909X		"RING,RETAINING LT"
18	105910X		"CHAIN,24 PTCH LT"
19	160942		COVER.DETENT.(5584)
20	160943		GEAR.SPUR.12T.(5627)
21	148267		CLUTCH.COL.5467
22	138236		ASM KIT CLTCH KEY
23	73810500		NUT.LOCK.5/16-24
24	142676		SHAFT INTERM DANA
25	2244J		WOODRUFF KEY
26	105916X		"RING,RETAINING LT"
27	120470X		SPROCKET 18T T
28	110070X		SPACER YT
29	142677		GEAR SPUR 37 TTH
30	142681		GEAR SPUR 35 TTH
31	124644X		GEAR SPUR 30T
32	108980X		GEAR 25T LT
33	120406X		GEAR SPUR 22 TT
34	134796		SPUR GEAR 19T
35	105925X		"WASHER, PLAIN LT"
36	2228J		WASHER 045
37	2231J		WASHER 031
38	160944		ASSY.GEAR.6153 12T&30T
39	124639X		SHAFT IDLER
40	120472X		SPACER T
41	105928X		SPROCKET 9T LT
42	161565		GEAR.BEVEL.36T(5621)
43	134394		ASM KIT SHIM
44	120473X		SHAFT T
45	142678		GEAR SPUR 12 TTH
46	143697		SUB= 148305
47	124641X		GEAR SPUR 20T
48	106589X		"GEAR, SPUR 25T LT"
49	120408X		GEAR 28T T
50	105937X		"GEAR, SPUR 31T LT"
51	2226J		WASHER 060
52	134401		NEOPRENE WASHER
53	2264J		WASHER 031
54	160946		AXLE.LH(5528-1)
55	160947		MITER 5270 12T.SPLINED
56	160948		RING.RETAINING.(5270)
57	110071X		SUB= 120478X
58	120952X		SHAFT T

Ref #	Part Number	Qty	Description
59	160949		MITER 5623.12T.IDLER
60	160950		AXLE.RH.(5528-2) DANA
61	160951		HOUSING.KIT (6088)
62	120961X		PUCK T
63	7294J		BRAKE DISC. T
64	108989X		SPACER LT
65	160952		JAW, BRAKE
66	120954X		PIN T
67	160953		SCREW.(5562) .5/16-18X2.35
68	138244		SUB= 108992X
69	108996X		WASHER LT
70	160954		BRACKET, ANTI-ROTATION
71	120951X		PUCK T
72	120416X		SUB= 126976X




TRACTOR - - MODEL NUMBER 7177A89

DECALS




Ref #	Part Number	Qty	Description
1	156368		"DECAL-DASH,OPER"
2	143470		DECAL STEER WHL
3	141579		DECAL HOOD RH
4	141580		DECAL HOOD LH
5	273775		DECAL, HP ENGINE
6	141583		DECAL DECK MULCH
8	141517		DECAL DECK WIZ +
9	127520		NLA
10	157002		"DECAL DANGER,FEND"
11	150218		DECAL.LENS.WIZARD
13	141502		DECAL CHASSIS WIZ
14	160396		"DECAL-SCHEM,BELT"
18	143388		NAMEPLATE.HD.WIZA
20	145005		DECAL.BATRY.3-3908
	138311		DECAL HANDLE LIFT
	154515		"PAD-FOOTREST,LH"
	154516		"PAD-FOOTREST, RH"
	162301		MANUAL.O.7177A89



TRACTOR - - MODEL NUMBER 7177A89


DRIVE






Ref #	Part Number	Qty	Description
2	146682		SPRING.BRAKE.RETU
3	123666X		PULLEY TRANS
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
6	17490512		SCREW
8	154792		"ROD SHIFT,FENDER"
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
13	74550412		BOLT.1/4-28.W/PAT
14	10040400		LOCKWASHER
15	74490544		BOLT.HX.FLG.5/16
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	124236X		CAP
30	130807		TRANSAXLE MTG BKT
31	127275X		"KEEPER,BELT LH T"
32	74760512		BOLT
34	155071		SHAFT ASM-PEDAL F
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	154777		SUB= 165692
42	19131312		WASHER
47	127783		SUB= 139245
48	154407		BELLCRANK.CLUTCH
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	160855		"V-BELT,95.3"
58	127274X		"KEEPER,BELT RH T"
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	154778		KEEPER-BELT
70	134683		KEEPER BELT ENG
72	19132012		WASHER
74	109502X		SPACER LT
75	121749X		WASHER
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER

Ref #	Part Number	Qty	Description
80	160783		ARM.SHIFT.TRANS.
81	161077		SHAFT ASSY CROSS
82	123782X		"SPRING,TORSION"
83	19171216		WASHER
84	145643		"ROD.TIE.20""P930LT"
85	150360		NUT.CNT.LOCK.1/4
86	157480		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	158391		SUB= 158391X428
90	124346X		NUT
112	19091210		WASHER LT
116	72110610		BOLT RDHD 3/8-16
148	159103		SPACER
149	122052X		SPACER RETAINER
150	150935		BUSHING.NYLON
151	19133210		WASHER



TRACTOR -- MODEL NUMBER 7177A89


ELECTRICAL



Ref #	Part Number	Qty	Description
1	144925		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
8	156417		"CASE,BATTERY.MECH"
15	147688		FASTNER.SNAP-IN
16	153664		SWITCH INTERLOCK
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146147		CABLE.BTRY.6GA.RD
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
40	156442		HARNES-IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
45	121433X		SUB= 122822X
52	141940		PROTECTION LOOP
70	140422		HARNES.ENG.DUAL

TRACTOR - - MODEL NUMBER 7177A89



ENGINE



Ref #	Part Number	Qty	Description
1	140310		CONTROL THROTTLE
2	17720410		SCREW LT
3			CHECK WITH SUPPLIER
4	137352		MUFFLER
13	272293		GASKET ENG 1 313 LD TIN PLATED
14	13280324		PIPE NIPPLE
15	13200300		ELBOW
16	11050600		LOCKWASHER
23	159880		SHIELD.BRN/DBR.GD
29	137180		SUB= 532137180
31	161911		TANK.FUEL.FRONT.
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
35	17490512		SCREW
37	137040		LINE FUEL
38			CHECK WITH SUPPLIER
40	124028X		SUB= 532124028
44	17490412		SCREW HEX CRT
46	19091416		WASHER
62	10040500		LOCKWASHER
72	71070512		SCREW
78	17490620		SCREW
81	128861		NUT

TRACTOR - - MODEL NUMBER 7177A89


BRIGGS & STRATTON ENGINE - MODEL NUMBER 311707, TYPE NUMBER 0132-E1



★ REQUIRES SPECIAL TOOLS
TO INSTALL, SEE REPAIR
INSTRUCTION MANUAL.

1019 LABEL KIT

1058 OWNER'S MANUAL




Ref #	Part Number	Qty	Description
1	690156		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	690188		HEAD, CYLINDER
6	94927		WASHER, GOVERNOR LEVER
7	273763		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	690136		CRANKSHAFT
20	291675		SEAL, OIL
22	95187		SCREW
23	690222		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	692271		PISTON, ASSEMBLY
25	692272		PISTON ASSEMBLY
25	692273		PISTON ASSEMBLY
25	692274		PISTON ASSEMBLY
26	690162		RING SET, PISTON
26	690164		RING SET, PISTON
26	690166		RING SET, PISTON
26	690168		RING SET, PISTON
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28	498320		PIN ASSY., PISTON, .005" OVERSIZE
29	499468		ROD ASSEMBLY, CONNECTING
29	499940		ROD ASSEMBLY, CONNECTING
32	95190		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
40	224641		RETAINER, VALVE SPRING
43	40815		GOV./OIL SLINGER
45	262411		TAPPET, VALVE
46	496884		GEAR, CAM
50	690193		MANIFOLD, INTAKE
51	281735		GASKET, INTAKE
51A	273650		GASKET, INTAKE
53	94637		STUD, CARBURETOR MOUNTING
73	494439		SCREEN, ROTATING
75	225136		WASHER, SPRING
78	94821		SCREW, SEMS
87	491323		SEAL, GOVERNOR
93	281346		BUSHING, THROTTLE SHAFT
94	498030		VALVE, IDLE, ADJUSTMENT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224558		VALVE, CHOKE
108A	224540		VALVE, CHOKE

Ref #	Part Number	Qty	Description
110	225137		WASHER, FLAT
116	270920		SEAL, OIL FILLER CAP
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)
117	232119		JET, MAIN (HIGH ALTITUDE)
121	690191		CARBURETOR OVERHAUL KIT
123	95160		SCREW
125	690194		CARBURETOR
130	224539		VALVE, THROTTLE
131	493379		THROTTLE SHAFT KIT
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
141	495097		SHAFT
141A	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
146	94196		KEY, TIMING GEAR
163	281051		P/N CONFLICT - CHECK WITH SUPPLIER
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
186	493496		ELBOW, FUEL PIPE
187	298049		LINE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
199	494768		VALVE, SHUT-OFF
205	94903		SCREW, HEX HEAD
205A	94073		SCREW, HEX HEAD
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
216A	262766		LINK, CHOKE
222	495611		PLATE, GOVERNOR CONTROL
224	95163		SCREW
227	493935		LEVER ASSY, GOVERNOR
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
294	810104		ADJUSTER, ROCKER ARM
304	225511		HOUSING, BLOWER
304A	225017		HOUSING, BLOWER, INNER, BLACK
305	94682		SCREW
305A	94822		SCREW, SEMS
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	94003		BOLT
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
354	94010		LOCKNUT, AIR CLEANER MOUNTING
355	281164		WASHER, FLOAT BOWL SCREW
356	494705		WIRE, STOP
358	690189		GASKET SET
363	19203		PULLER, FLYWHEEL
381	94863		SCREW
383	89838		WRENCH SPARK PLUG
461	94734		SCREW
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT


Ref #	Part Number	Qty	Description
482	93621		SCREW, SEMS
493	224968		BRACKET, BLOWER HOUSING, FRONT
493A	224969		BRACKET, BLOWER HOUSING, REAR
503	806000		STRAP, STARTER
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
525	496113		TUBE, OIL FILLER
529	281370		SEAL, FILLER TUBE
535	496894		CARTRIDGE, AIR CLEANER
544	497603		ARMATURE, STARTER
552	491986		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
592A	92278		NUT, HEX
601	95162		CLAMP, FUEL LINE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
616	495157		CRANK, GOVERNOR, 1/4" DIAMETER
634	494453		SEAL, SPRING ASSY.
634A	494455		SEAL, SPRING ASSY.
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94905		SCREW
663	94929		SCREW, SELF-TAPPING
663A	94704		SCREW, AIR CLEANER
668	805402		SPACER, ROTATING SCREEN
689	262715		SPRING, CHOKE
673	94896		SCREW, SEMS
718	230192		PIN, DOWEL
726	399676		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	281390		CLIP, WIRE
729A	225170		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	499994		COUNTERWEIGHT
759	230787		PIN, COUNTERWEIGHT
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
789	497708		WIRE ASSY
801	497626		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
830	94555		STUD, ROCKER ARM
547	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	224110		TERMINAL, IGNITION CABLE
868	499236		SEAL, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
878	393362		HARNESS, ALTERNATOR
947	497672		SOLENOID
967	272403		ELEMENT, AIR CLEANER
968	281758		COVER, AIR CLEANER
975	494933		BOWL, FLOAT
977	690192		GASKET SET, CARBURETOR
987	281166		SEAL, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
1005	281400		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	690180		LABEL KIT
1022	272475		GASKET, COVER
1023	225521		COVER, ROCKER
1026	494432		ROD, PUSH, INTAKE
1026A	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	690190		VALVE, OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	273807		LABEL KIT, EMISSION
1044	94673		SCREW, SHOULDER, HEX HEAD
1058	273686		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
	690191		CARBURETOR OVERHAUL KIT



TRACTOR - - MODEL NUMBER 7177A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 311707, TYPE NUMBER 0132-E1




Ref #	Part Number	Qty	Description
1	690156		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	690188		HEAD, CYLINDER
6	94927		WASHER, GOVERNOR LEVER
7	273763		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	690136		CRANKSHAFT
20	291675		SEAL, OIL
22	95187		SCREW
23	690222		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	692271		PISTON, ASSEMBLY
25	692272		PISTON ASSEMBLY
25	692273		PISTON ASSEMBLY
25	692274		PISTON ASSEMBLY
26	690162		RING SET, PISTON
26	690164		RING SET, PISTON
26	690166		RING SET, PISTON
26	690168		RING SET, PISTON
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28	498320		PIN ASSY., PISTON, .005" OVERSIZE
29	499468		ROD ASSEMBLY, CONNECTING
29	499940		ROD ASSEMBLY, CONNECTING
32	95190		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
40	224641		RETAINER, VALVE SPRING
43	40815		GOV./OIL SLINGER
45	262411		TAPPET, VALVE
46	496884		GEAR, CAM
50	690193		MANIFOLD, INTAKE
51	281735		GASKET, INTAKE
51A	273650		GASKET, INTAKE
53	94637		STUD, CARBURETOR MOUNTING
73	494439		SCREEN, ROTATING
75	225136		WASHER, SPRING
78	94821		SCREW, SEMS
87	491323		SEAL, GOVERNOR
93	281346		BUSHING, THROTTLE SHAFT
94	498030		VALVE, IDLE, ADJUSTMENT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224558		VALVE, CHOKE
108A	224540		VALVE, CHOKE

Ref #	Part Number	Qty	Description
110	225137		WASHER, FLAT
116	270920		SEAL, OIL FILLER CAP
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)
117	232119		JET, MAIN (HIGH ALTITUDE)
121	690191		CARBURETOR OVERHAUL KIT
123	95160		SCREW
125	690194		CARBURETOR
130	224539		VALVE, THROTTLE
131	493379		THROTTLE SHAFT KIT
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
141	495097		SHAFT
141A	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
146	94196		KEY, TIMING GEAR
163	281051		P/N CONFLICT - CHECK WITH SUPPLIER
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
186	493496		ELBOW, FUEL PIPE
187	298049		LINE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
199	494768		VALVE, SHUT-OFF
205	94903		SCREW, HEX HEAD
205A	94073		SCREW, HEX HEAD
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
216A	262766		LINK, CHOKE
222	495611		PLATE, GOVERNOR CONTROL
224	95163		SCREW
227	493935		LEVER ASSY, GOVERNOR
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
294	810104		ADJUSTER, ROCKER ARM
304	225511		HOUSING, BLOWER
304A	225017		HOUSING, BLOWER, INNER, BLACK
305	94682		SCREW
305A	94822		SCREW, SEMS
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	94003		BOLT
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
354	94010		LOCKNUT, AIR CLEANER MOUNTING
355	281164		WASHER, FLOAT BOWL SCREW
356	494705		WIRE, STOP
358	690189		GASKET SET
363	19203		PULLER, FLYWHEEL
381	94863		SCREW
383	89838		WRENCH SPARK PLUG
461	94734		SCREW
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT


Ref #	Part Number	Qty	Description
482	93621		SCREW, SEMS
493	224968		BRACKET, BLOWER HOUSING, FRONT
493A	224969		BRACKET, BLOWER HOUSING, REAR
503	806000		STRAP, STARTER
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
525	496113		TUBE, OIL FILLER
529	281370		SEAL, FILLER TUBE
535	496894		CARTRIDGE, AIR CLEANER
544	497603		ARMATURE, STARTER
552	491986		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
592A	92278		NUT, HEX
601	95162		CLAMP, FUEL LINE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
616	495157		CRANK, GOVERNOR, 1/4" DIAMETER
634	494453		SEAL, SPRING ASSY.
634A	494455		SEAL, SPRING ASSY.
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94905		SCREW
663	94929		SCREW, SELF-TAPPING
663A	94704		SCREW, AIR CLEANER
668	805402		SPACER, ROTATING SCREEN
689	262715		SPRING, CHOKE
673	94896		SCREW, SEMS
718	230192		PIN, DOWEL
726	399676		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	281390		CLIP, WIRE
729A	225170		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	499994		COUNTERWEIGHT
759	230787		PIN, COUNTERWEIGHT
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
789	497708		WIRE ASSY
801	497626		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
830	94555		STUD, ROCKER ARM
547	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	224110		TERMINAL, IGNITION CABLE
868	499236		SEAL, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
878	393362		HARNESS, ALTERNATOR
947	497672		SOLENOID
967	272403		ELEMENT, AIR CLEANER
968	281758		COVER, AIR CLEANER
975	494933		BOWL, FLOAT
977	690192		GASKET SET, CARBURETOR
987	281166		SEAL, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
1005	281400		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	690180		LABEL KIT
1022	272475		GASKET, COVER
1023	225521		COVER, ROCKER
1026	494432		ROD, PUSH, INTAKE
1026A	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	690190		VALVE, OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	273807		LABEL KIT, EMISSION
1044	94673		SCREW, SHOULDER, HEX HEAD
1058	273686		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
	690191		CARBURETOR OVERHAUL KIT




TRACTOR - - MODEL NUMBER 7177A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 311707, TYPE NUMBER 0132-E1



THIS CARBURETOR SERVICES BOTH CHOKE-A-MATIC AND MANUAL CHOKE SYSTEMS




Ref #	Part Number	Qty	Description
1	690156		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	690188		HEAD, CYLINDER
6	94927		WASHER, GOVERNOR LEVER
7	273763		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	690136		CRANKSHAFT
20	291675		SEAL, OIL
22	95187		SCREW
23	690222		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	692271		PISTON, ASSEMBLY
25	692272		PISTON ASSEMBLY
25	692273		PISTON ASSEMBLY
25	692274		PISTON ASSEMBLY
26	690162		RING SET, PISTON
26	690164		RING SET, PISTON
26	690166		RING SET, PISTON
26	690168		RING SET, PISTON
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28	498320		PIN ASSY., PISTON, .005" OVERSIZE
29	499468		ROD ASSEMBLY, CONNECTING
29	499940		ROD ASSEMBLY, CONNECTING
32	95190		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
40	224641		RETAINER, VALVE SPRING
43	40815		GOV./OIL SLINGER
45	262411		TAPPET, VALVE
46	496884		GEAR, CAM
50	690193		MANIFOLD, INTAKE
51	281735		GASKET, INTAKE
51A	273650		GASKET, INTAKE
53	94637		STUD, CARBURETOR MOUNTING
73	494439		SCREEN, ROTATING
75	225136		WASHER, SPRING
78	94821		SCREW, SEMS
87	491323		SEAL, GOVERNOR
93	281346		BUSHING, THROTTLE SHAFT
94	498030		VALVE, IDLE, ADJUSTMENT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224558		VALVE, CHOKE
108A	224540		VALVE, CHOKE

Ref #	Part Number	Qty	Description
110	225137		WASHER, FLAT
116	270920		SEAL, OIL FILLER CAP
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)
117	232119		JET, MAIN (HIGH ALTITUDE)
121	690191		CARBURETOR OVERHAUL KIT
123	95160		SCREW
125	690194		CARBURETOR
130	224539		VALVE, THROTTLE
131	493379		THROTTLE SHAFT KIT
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
141	495097		SHAFT
141A	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
146	94196		KEY, TIMING GEAR
163	281051		P/N CONFLICT - CHECK WITH SUPPLIER
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
186	493496		ELBOW, FUEL PIPE
187	298049		LINE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
199	494768		VALVE, SHUT-OFF
205	94903		SCREW, HEX HEAD
205A	94073		SCREW, HEX HEAD
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
216A	262766		LINK, CHOKE
222	495611		PLATE, GOVERNOR CONTROL
224	95163		SCREW
227	493935		LEVER ASSY, GOVERNOR
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
294	810104		ADJUSTER, ROCKER ARM
304	225511		HOUSING, BLOWER
304A	225017		HOUSING, BLOWER, INNER, BLACK
305	94682		SCREW
305A	94822		SCREW, SEMS
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	94003		BOLT
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
354	94010		LOCKNUT, AIR CLEANER MOUNTING
355	281164		WASHER, FLOAT BOWL SCREW
356	494705		WIRE, STOP
358	690189		GASKET SET
363	19203		PULLER, FLYWHEEL
381	94863		SCREW
383	89838		WRENCH SPARK PLUG
461	94734		SCREW
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT


Ref #	Part Number	Qty	Description
482	93621		SCREW, SEMS
493	224968		BRACKET, BLOWER HOUSING, FRONT
493A	224969		BRACKET, BLOWER HOUSING, REAR
503	806000		STRAP, STARTER
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
525	496113		TUBE, OIL FILLER
529	281370		SEAL, FILLER TUBE
535	496894		CARTRIDGE, AIR CLEANER
544	497603		ARMATURE, STARTER
552	491986		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
592A	92278		NUT, HEX
601	95162		CLAMP, FUEL LINE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
616	495157		CRANK, GOVERNOR, 1/4" DIAMETER
634	494453		SEAL, SPRING ASSY.
634A	494455		SEAL, SPRING ASSY.
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94905		SCREW
663	94929		SCREW, SELF-TAPPING
663A	94704		SCREW, AIR CLEANER
668	805402		SPACER, ROTATING SCREEN
689	262715		SPRING, CHOKE
673	94896		SCREW, SEMS
718	230192		PIN, DOWEL
726	399676		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	281390		CLIP, WIRE
729A	225170		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	499994		COUNTERWEIGHT
759	230787		PIN, COUNTERWEIGHT
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
789	497708		WIRE ASSY
801	497626		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
830	94555		STUD, ROCKER ARM
547	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	224110		TERMINAL, IGNITION CABLE
868	499236		SEAL, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
878	393362		HARNESS, ALTERNATOR
947	497672		SOLENOID
967	272403		ELEMENT, AIR CLEANER
968	281758		COVER, AIR CLEANER
975	494933		BOWL, FLOAT
977	690192		GASKET SET, CARBURETOR
987	281166		SEAL, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
1005	281400		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	690180		LABEL KIT
1022	272475		GASKET, COVER
1023	225521		COVER, ROCKER
1026	494432		ROD, PUSH, INTAKE
1026A	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	690190		VALVE, OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	273807		LABEL KIT, EMISSION
1044	94673		SCREW, SHOULDER, HEX HEAD
1058	273686		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
	690191		CARBURETOR OVERHAUL KIT



TRACTOR -- MODEL NUMBER 7177A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 311707, TYPE NUMBER 0132-E1




Ref #	Part Number	Qty	Description
1	690156		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	690188		HEAD, CYLINDER
6	94927		WASHER, GOVERNOR LEVER
7	273763		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	690136		CRANKSHAFT
20	291675		SEAL, OIL
22	95187		SCREW
23	690222		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	692271		PISTON, ASSEMBLY
25	692272		PISTON ASSEMBLY
25	692273		PISTON ASSEMBLY
25	692274		PISTON ASSEMBLY
26	690162		RING SET, PISTON
26	690164		RING SET, PISTON
26	690166		RING SET, PISTON
26	690168		RING SET, PISTON
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28	498320		PIN ASSY., PISTON, .005" OVERSIZE
29	499468		ROD ASSEMBLY, CONNECTING
29	499940		ROD ASSEMBLY, CONNECTING
32	95190		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
40	224641		RETAINER, VALVE SPRING
43	40815		GOV./OIL SLINGER
45	262411		TAPPET, VALVE
46	496884		GEAR, CAM
50	690193		MANIFOLD, INTAKE
51	281735		GASKET, INTAKE
51A	273650		GASKET, INTAKE
53	94637		STUD, CARBURETOR MOUNTING
73	494439		SCREEN, ROTATING
75	225136		WASHER, SPRING
78	94821		SCREW, SEMS
87	491323		SEAL, GOVERNOR
93	281346		BUSHING, THROTTLE SHAFT
94	498030		VALVE, IDLE, ADJUSTMENT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224558		VALVE, CHOKE
108A	224540		VALVE, CHOKE

Ref #	Part Number	Qty	Description
110	225137		WASHER, FLAT
116	270920		SEAL, OIL FILLER CAP
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)
117	232119		JET, MAIN (HIGH ALTITUDE)
121	690191		CARBURETOR OVERHAUL KIT
123	95160		SCREW
125	690194		CARBURETOR
130	224539		VALVE, THROTTLE
131	493379		THROTTLE SHAFT KIT
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
141	495097		SHAFT
141A	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
146	94196		KEY, TIMING GEAR
163	281051		P/N CONFLICT - CHECK WITH SUPPLIER
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
186	493496		ELBOW, FUEL PIPE
187	298049		LINE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
199	494768		VALVE, SHUT-OFF
205	94903		SCREW, HEX HEAD
205A	94073		SCREW, HEX HEAD
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
216A	262766		LINK, CHOKE
222	495611		PLATE, GOVERNOR CONTROL
224	95163		SCREW
227	493935		LEVER ASSY, GOVERNOR
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
294	810104		ADJUSTER, ROCKER ARM
304	225511		HOUSING, BLOWER
304A	225017		HOUSING, BLOWER, INNER, BLACK
305	94682		SCREW
305A	94822		SCREW, SEMS
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	94003		BOLT
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
354	94010		LOCKNUT, AIR CLEANER MOUNTING
355	281164		WASHER, FLOAT BOWL SCREW
356	494705		WIRE, STOP
358	690189		GASKET SET
363	19203		PULLER, FLYWHEEL
381	94863		SCREW
383	89838		WRENCH SPARK PLUG
461	94734		SCREW
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT


Ref #	Part Number	Qty	Description
482	93621		SCREW, SEMS
493	224968		BRACKET, BLOWER HOUSING, FRONT
493A	224969		BRACKET, BLOWER HOUSING, REAR
503	806000		STRAP, STARTER
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
525	496113		TUBE, OIL FILLER
529	281370		SEAL, FILLER TUBE
535	496894		CARTRIDGE, AIR CLEANER
544	497603		ARMATURE, STARTER
552	491986		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
592A	92278		NUT, HEX
601	95162		CLAMP, FUEL LINE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
616	495157		CRANK, GOVERNOR, 1/4" DIAMETER
634	494453		SEAL, SPRING ASSY.
634A	494455		SEAL, SPRING ASSY.
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94905		SCREW
663	94929		SCREW, SELF-TAPPING
663A	94704		SCREW, AIR CLEANER
668	805402		SPACER, ROTATING SCREEN
689	262715		SPRING, CHOKE
673	94896		SCREW, SEMS
718	230192		PIN, DOWEL
726	399676		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	281390		CLIP, WIRE
729A	225170		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	499994		COUNTERWEIGHT
759	230787		PIN, COUNTERWEIGHT
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
789	497708		WIRE ASSY
801	497626		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
830	94555		STUD, ROCKER ARM
547	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	224110		TERMINAL, IGNITION CABLE
868	499236		SEAL, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
878	393362		HARNESS, ALTERNATOR
947	497672		SOLENOID
967	272403		ELEMENT, AIR CLEANER
968	281758		COVER, AIR CLEANER
975	494933		BOWL, FLOAT
977	690192		GASKET SET, CARBURETOR
987	281166		SEAL, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
1005	281400		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	690180		LABEL KIT
1022	272475		GASKET, COVER
1023	225521		COVER, ROCKER
1026	494432		ROD, PUSH, INTAKE
1026A	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	690190		VALVE, OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	273807		LABEL KIT, EMISSION
1044	94673		SCREW, SHOULDER, HEX HEAD
1058	273686		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
	690191		CARBURETOR OVERHAUL KIT





TRACTOR - - MODEL NUMBER 7177A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 311707, TYPE NUMBER 0132-E1



★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL.




Ref #	Part Number	Qty	Description
1	690156		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	690188		HEAD, CYLINDER
6	94927		WASHER, GOVERNOR LEVER
7	273763		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	690136		CRANKSHAFT
20	291675		SEAL, OIL
22	95187		SCREW
23	690222		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	692271		PISTON, ASSEMBLY
25	692272		PISTON ASSEMBLY
25	692273		PISTON ASSEMBLY
25	692274		PISTON ASSEMBLY
26	690162		RING SET, PISTON
26	690164		RING SET, PISTON
26	690166		RING SET, PISTON
26	690168		RING SET, PISTON
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28	498320		PIN ASSY., PISTON, .005" OVERSIZE
29	499468		ROD ASSEMBLY, CONNECTING
29	499940		ROD ASSEMBLY, CONNECTING
32	95190		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
40	224641		RETAINER, VALVE SPRING
43	40815		GOV./OIL SLINGER
45	262411		TAPPET, VALVE
46	496884		GEAR, CAM
50	690193		MANIFOLD, INTAKE
51	281735		GASKET, INTAKE
51A	273650		GASKET, INTAKE
53	94637		STUD, CARBURETOR MOUNTING
73	494439		SCREEN, ROTATING
75	225136		WASHER, SPRING
78	94821		SCREW, SEMS
87	491323		SEAL, GOVERNOR
93	281346		BUSHING, THROTTLE SHAFT
94	498030		VALVE, IDLE, ADJUSTMENT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224558		VALVE, CHOKE
108A	224540		VALVE, CHOKE

Ref #	Part Number	Qty	Description
110	225137		WASHER, FLAT
116	270920		SEAL, OIL FILLER CAP
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)
117	232119		JET, MAIN (HIGH ALTITUDE)
121	690191		CARBURETOR OVERHAUL KIT
123	95160		SCREW
125	690194		CARBURETOR
130	224539		VALVE, THROTTLE
131	493379		THROTTLE SHAFT KIT
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
141	495097		SHAFT
141A	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
146	94196		KEY, TIMING GEAR
163	281051		P/N CONFLICT - CHECK WITH SUPPLIER
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
186	493496		ELBOW, FUEL PIPE
187	298049		LINE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
199	494768		VALVE, SHUT-OFF
205	94903		SCREW, HEX HEAD
205A	94073		SCREW, HEX HEAD
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
216A	262766		LINK, CHOKE
222	495611		PLATE, GOVERNOR CONTROL
224	95163		SCREW
227	493935		LEVER ASSY, GOVERNOR
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
294	810104		ADJUSTER, ROCKER ARM
304	225511		HOUSING, BLOWER
304A	225017		HOUSING, BLOWER, INNER, BLACK
305	94682		SCREW
305A	94822		SCREW, SEMS
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	94003		BOLT
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
354	94010		LOCKNUT, AIR CLEANER MOUNTING
355	281164		WASHER, FLOAT BOWL SCREW
356	494705		WIRE, STOP
358	690189		GASKET SET
363	19203		PULLER, FLYWHEEL
381	94863		SCREW
383	89838		WRENCH SPARK PLUG
461	94734		SCREW
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT


Ref #	Part Number	Qty	Description
482	93621		SCREW, SEMS
493	224968		BRACKET, BLOWER HOUSING, FRONT
493A	224969		BRACKET, BLOWER HOUSING, REAR
503	806000		STRAP, STARTER
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
525	496113		TUBE, OIL FILLER
529	281370		SEAL, FILLER TUBE
535	496894		CARTRIDGE, AIR CLEANER
544	497603		ARMATURE, STARTER
552	491986		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
592A	92278		NUT, HEX
601	95162		CLAMP, FUEL LINE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
616	495157		CRANK, GOVERNOR, 1/4" DIAMETER
634	494453		SEAL, SPRING ASSY.
634A	494455		SEAL, SPRING ASSY.
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94905		SCREW
663	94929		SCREW, SELF-TAPPING
663A	94704		SCREW, AIR CLEANER
668	805402		SPACER, ROTATING SCREEN
689	262715		SPRING, CHOKE
673	94896		SCREW, SEMS
718	230192		PIN, DOWEL
726	399676		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	281390		CLIP, WIRE
729A	225170		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	499994		COUNTERWEIGHT
759	230787		PIN, COUNTERWEIGHT
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
789	497708		WIRE ASSY
801	497626		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
830	94555		STUD, ROCKER ARM
547	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	224110		TERMINAL, IGNITION CABLE
868	499236		SEAL, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
878	393362		HARNESS, ALTERNATOR
947	497672		SOLENOID
967	272403		ELEMENT, AIR CLEANER
968	281758		COVER, AIR CLEANER
975	494933		BOWL, FLOAT
977	690192		GASKET SET, CARBURETOR
987	281166		SEAL, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
1005	281400		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	690180		LABEL KIT
1022	272475		GASKET, COVER
1023	225521		COVER, ROCKER
1026	494432		ROD, PUSH, INTAKE
1026A	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	690190		VALVE, OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	273807		LABEL KIT, EMISSION
1044	94673		SCREW, SHOULDER, HEX HEAD
1058	273686		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
	690191		CARBURETOR OVERHAUL KIT



TRACTOR - - MODEL NUMBER 7177A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 311707, TYPE NUMBER 0132-E1




Ref #	Part Number	Qty	Description
1	690156		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	690188		HEAD, CYLINDER
6	94927		WASHER, GOVERNOR LEVER
7	273763		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	690136		CRANKSHAFT
20	291675		SEAL, OIL
22	95187		SCREW
23	690222		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	692271		PISTON, ASSEMBLY
25	692272		PISTON ASSEMBLY
25	692273		PISTON ASSEMBLY
25	692274		PISTON ASSEMBLY
26	690162		RING SET, PISTON
26	690164		RING SET, PISTON
26	690166		RING SET, PISTON
26	690168		RING SET, PISTON
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28	498320		PIN ASSY., PISTON, .005" OVERSIZE
29	499468		ROD ASSEMBLY, CONNECTING
29	499940		ROD ASSEMBLY, CONNECTING
32	95190		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
40	224641		RETAINER, VALVE SPRING
43	40815		GOV./OIL SLINGER
45	262411		TAPPET, VALVE
46	496884		GEAR, CAM
50	690193		MANIFOLD, INTAKE
51	281735		GASKET, INTAKE
51A	273650		GASKET, INTAKE
53	94637		STUD, CARBURETOR MOUNTING
73	494439		SCREEN, ROTATING
75	225136		WASHER, SPRING
78	94821		SCREW, SEMS
87	491323		SEAL, GOVERNOR
93	281346		BUSHING, THROTTLE SHAFT
94	498030		VALVE, IDLE, ADJUSTMENT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224558		VALVE, CHOKE
108A	224540		VALVE, CHOKE

Ref #	Part Number	Qty	Description
110	225137		WASHER, FLAT
116	270920		SEAL, OIL FILLER CAP
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)
117	232119		JET, MAIN (HIGH ALTITUDE)
121	690191		CARBURETOR OVERHAUL KIT
123	95160		SCREW
125	690194		CARBURETOR
130	224539		VALVE, THROTTLE
131	493379		THROTTLE SHAFT KIT
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
141	495097		SHAFT
141A	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
146	94196		KEY, TIMING GEAR
163	281051		P/N CONFLICT - CHECK WITH SUPPLIER
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
186	493496		ELBOW, FUEL PIPE
187	298049		LINE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
199	494768		VALVE, SHUT-OFF
205	94903		SCREW, HEX HEAD
205A	94073		SCREW, HEX HEAD
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
216A	262766		LINK, CHOKE
222	495611		PLATE, GOVERNOR CONTROL
224	95163		SCREW
227	493935		LEVER ASSY, GOVERNOR
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
294	810104		ADJUSTER, ROCKER ARM
304	225511		HOUSING, BLOWER
304A	225017		HOUSING, BLOWER, INNER, BLACK
305	94682		SCREW
305A	94822		SCREW, SEMS
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	94003		BOLT
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
354	94010		LOCKNUT, AIR CLEANER MOUNTING
355	281164		WASHER, FLOAT BOWL SCREW
356	494705		WIRE, STOP
358	690189		GASKET SET
363	19203		PULLER, FLYWHEEL
381	94863		SCREW
383	89838		WRENCH SPARK PLUG
461	94734		SCREW
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT


Ref #	Part Number	Qty	Description
482	93621		SCREW, SEMS
493	224968		BRACKET, BLOWER HOUSING, FRONT
493A	224969		BRACKET, BLOWER HOUSING, REAR
503	806000		STRAP, STARTER
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
525	496113		TUBE, OIL FILLER
529	281370		SEAL, FILLER TUBE
535	496894		CARTRIDGE, AIR CLEANER
544	497603		ARMATURE, STARTER
552	491986		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
592A	92278		NUT, HEX
601	95162		CLAMP, FUEL LINE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
616	495157		CRANK, GOVERNOR, 1/4" DIAMETER
634	494453		SEAL, SPRING ASSY.
634A	494455		SEAL, SPRING ASSY.
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94905		SCREW
663	94929		SCREW, SELF-TAPPING
663A	94704		SCREW, AIR CLEANER
668	805402		SPACER, ROTATING SCREEN
689	262715		SPRING, CHOKE
673	94896		SCREW, SEMS
718	230192		PIN, DOWEL
726	399676		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	281390		CLIP, WIRE
729A	225170		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	499994		COUNTERWEIGHT
759	230787		PIN, COUNTERWEIGHT
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
789	497708		WIRE ASSY
801	497626		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
830	94555		STUD, ROCKER ARM
547	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	224110		TERMINAL, IGNITION CABLE
868	499236		SEAL, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
878	393362		HARNESS, ALTERNATOR
947	497672		SOLENOID
967	272403		ELEMENT, AIR CLEANER
968	281758		COVER, AIR CLEANER
975	494933		BOWL, FLOAT
977	690192		GASKET SET, CARBURETOR
987	281166		SEAL, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
1005	281400		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	690180		LABEL KIT
1022	272475		GASKET, COVER
1023	225521		COVER, ROCKER
1026	494432		ROD, PUSH, INTAKE
1026A	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	690190		VALVE, OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	273807		LABEL KIT, EMISSION
1044	94673		SCREW, SHOULDER, HEX HEAD
1058	273686		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
	690191		CARBURETOR OVERHAUL KIT



TRACTOR - - MODEL NUMBER 7177A89


LIFT



Ref #	Part Number	Qty	Description
1	159460		WIRE ASM W.SPRING
2	159471		"SHAFT ASM LIFT,RH"
3	105767X		PIN-GROOVE LT
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
11	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
23	110807X		NUT T
24	19131016		WASHER
25	2876H		SPRING T
26	76020308		SUB= 3145
27	126971X		SUB= 532126971
28	73350600		NUT
29	138057		KNOB INF 3/8-16
30	150233		TRUNNION
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8
36	155097		POINTER-INDICAT
37	123935X		"PLUG,HOLE"
38	17490512		SCREW
40	19112410		WASHER
41	155098		INDICATOR HEIGHT
49	145212		NUT.HXFLG.LOCK.
50	110452X		NUT PUSH M

TRACTOR -- MODEL NUMBER 7177A89

MOWER DECK





Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	159770		BAFFLE VORTEX 42
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	157722		"SCREW-THD ROLL,WA"
31	129963		WASHER
32	153535		PULLEY.MANDREL.42
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45			CHECK WITH SUPPLIER
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	155066		ROLLER ASM-CAM
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845X900		SUB= 131845
54	133943		HARDENED WASHER
55	155046		ARM-IDLER
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	162132		KNOB.RD.7/16-14
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND

Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	160570		LEVER.ASM.CLUTCH
79	127498		BUSHING
80	153701		SPRING.CLUTCH.MWR
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	156084		"KEEPER-BELT,FIXED"
85	72140618		BOLT RDHD 3/8-16
92	73800600		NUT
101	136420		"COVER.MULCH.42""
102	71161010		SCREW
103	19061216		WASHER #10
104	10071000		LOCKWASHER
105	160793		LATCH ASSY.BAGGER
106	2029J		WELDNUT
111	155197		BRACKET.GWHL.LH.
112	155198		BRACKET.GWHL.RH.
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	137644		BOLT.SHOULDER
117	133957		WHEEL GAGE DONUT
118	73930600		LOCKNUT
119	19121414		WASHER
121	143723		BRACKET.EXTRD.GWL
128	153390		WASHER.FELT.
129	19131312		WASHER
130	74780616		BOLT
131	72140608		SUB= 72110608
132	19132203		WASHER GT
141	6266H		WASHER .T
	130794		MANDREL ASM
	145411		SUB= 164963

TRACTOR - - MODEL NUMBER 7177A89

SCHEMATIC



IGNITION SWITCH

POSITION	CIRCUIT	"MAKE"
OFF	G+M+L	NONE
RUN/LIGHT	B+L	A+Y
RUN	B+L	NONE
START	B+L+S	NONE


WIRING INSULATED CLIPS

NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.


Der Ersatzteilspezialist im Internet.

TRACTOR - - MODEL NUMBER 7177A89

SEAT ASSEMBLY




Ref #	Part Number	Qty	Description
1	140117		SEAT.2400/1416.BK
2	140551		BRACKET PVT SEAT
3	74760616		BOLT
4	19131610		WASHER PM
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
8	17490616		SCREW GTV
9	19131614		WASHER
10	155925		PAN-SEAT
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050412		BOLT-RD HD SQ NK
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	153236		"BOLT,SHOULDER"
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER




TRACTOR - - MODEL NUMBER 7177A89

STEERING ASSEMBLY



Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	154427		AXLE ASM
3	156483		SPINDLE.ASM.LH
4	157473		"SPINDLE ASM,RH"
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	156438		DRAGLINK-STAMPED
11	10040600		LOCKWASHER
13	154779		BEARING AXLE
15	73901000		"NUT-LOC,FLANGE LT"
17	156546		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
22	71200410		SCREW HEX SOC1/4-
23	127501		SUB= 918127501
25	154406		BRKT-STEERING
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	155099		BUSHING.STEERING
37	152927		"SCREW-TT,10-32 FL"
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	100711L		ADAPTER LT
42	145054		BOOT.STEER.PL
43	121749X		WASHER
44	153720		EXT SHAFT STEERIN
46	121232X		CAP
47	6855M		ZERK M
51	73800500		NUT
54	74780520		BOLT
62	156594		KIT STEERING ASM
63	74780616		BOLT
65	154780		SPACER AXLE
66	154404		"BEARING-ARM,PITMA"
67	74781044		BOLT
68	154429		BRACE AXLE

WHEELS AND TIRES



Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	122082X		SUB= 918122082X
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP
	144334		SEALANT.TIRE 10 OZ. TUBE

