










TRACTOR - - MODEL NUMBER 9149A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 287707, TYPE NUMBER 1255-E1



★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

Ref #	Part Number	Qty	Description
1	496412		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	495858		HEAD, CYLINDER
7	272614		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
12	271996		GASKET, CRANKCASE COVER .009"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	495860		PISTON ASSY, STANDARD SIZE
25	495977		PISTON ASSY .010" OVERSIZE
25	495978		PISTON ASSY .020" OVERSIZE
25	495979		PISTON ASSY .030" OVERSIZE
26	495854		RING SET, PISTON, STANDARD SIZE
26	495852		RING SET, PISTON, .010" OVERSIZE
26	495851		RING SET, PISTON, .020" OVERSIZE
26	495855		RING SET, PISTON, .030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
29	494504		ROD ASSY, CONNECTING
29	495490		ROD ASSY, CONNECTING
32	94695		SCREW
32A	94648		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
37	224502		GUARD, FLYWHEEL
40	224641		RETAINER, VALVE SPRING
45	262411		TAPPET, VALVE
26	496884		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272569		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
73	224948		SCREEN, FLUSH ROTATING
75	225136		WASHER, SPRING
78	94626		SCREW, SEMS
93	281346		BUSHING, THROTTLE SHAFT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224540		VALVE, CHOKE
111	262719		SPRING, CHOKE
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)

Ref #	Part Number	Qty	Description
118	498030		VALVE, IDLE, ADJUSTMENT
121	499233		CARBURETOR OVERHAUL KIT
123	94913		SCREW, TORX HEX
125	499153		CARBURETOR ASSY
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
164	214047		ELBOW, CARBURETOR
166	94555		STUD, ROCKER ARM
171			CHECK WITH SUPPLIER
187	492790		HOSE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
201	262767		LINK, GOVERNOR
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	495157		CRANK, GOVERNOR, 1/4" DIAMETER
227	493935		LEVER ASSY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
294	810068		SCREW, SET
304	496318		HOUSING, BLOWER
305	94786		SCREW
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	497602		BOLT, THRU
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
346	93705		SUB= 69485
356	497708		WIRE ASSY
356A	497671		WIRE, STOP
356B	494705		WIRE, STOP
358	495993		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94903		SCREW, HEX HEAD
445	496894		CARTRIDGE, AIR CLEANER
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
524	281370		SEAL, FILLER TUBE


Ref #	Part Number	Qty	Description
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	497603		ARMATURE, STARTER
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	493496		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
634	494455		SEAL, SPRING ASSY.
634A	491323		SEAL, GOVERNOR
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94906		SCREW
663	94929		SCREW, SELF-TAPPING
668	280848		SPACER
718	230192		PIN, DOWEL
726	392134		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	225170		RETAINER, WIRE
729A	281390		CLIP, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	493880		TERMINAL, IGNITION CABLE
868	494435		SEAL ASSEMBLY, VALVE
868A	272610		GASKET, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
872	281104		COVER, AIR CLEANER
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
947	497672		SOLENOID
965	94108		LOCKNUT, AIR CLEANER MOUNTING
975	495933		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1005	280687		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	496758		LABEL KIT
1022	272475		GASKET, COVER
1023	224552		COVER, ROCKER ARM
1026	494432		ROD, PUSH, INTAKE
1026	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	495992		VALVE OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	499364		LABEL KIT, EMISSIONS

Ref #	Part Number	Qty	Description
1044	94673		SCREW, SHOULDER, HEX HEAD
1045	231828		EXTENSION, CRANKSHAFT
1058	272623		MANUAL, OWNER'S
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
2500	28N707-1026		REPLACEMENT ENGINE
	496050		REPLACEMENT SHORTBLOCK



TRACTOR - - MODEL NUMBER 9149A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 287707, TYPE NUMBER 1265-E1



Ref #	Part Number	Qty	Description
1	496412		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	495858		HEAD, CYLINDER
7	272614		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
12	271996		GASKET, CRANKCASE COVER .009"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	495860		PISTON ASSY, STANDARD SIZE
25	495977		PISTON ASSY .010" OVERSIZE
25	495978		PISTON ASSY .020" OVERSIZE
25	495979		PISTON ASSY .030" OVERSIZE
26	495854		RING SET, PISTON, STANDARD SIZE
26	495852		RING SET, PISTON, .010" OVERSIZE
26	495851		RING SET, PISTON, .020" OVERSIZE
26	495855		RING SET, PISTON, .030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
29	494504		ROD ASSY, CONNECTING
29	495490		ROD ASSY, CONNECTING
32	94695		SCREW
32A	94648		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
37	224502		GUARD, FLYWHEEL
40	224641		RETAINER, VALVE SPRING
45	262411		TAPPET, VALVE
26	496884		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272569		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
73	224948		SCREEN, FLUSH ROTATING
75	225136		WASHER, SPRING
78	94626		SCREW, SEMS
93	281346		BUSHING, THROTTLE SHAFT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224540		VALVE, CHOKE
111	262719		SPRING, CHOKE
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)

Ref #	Part Number	Qty	Description
118	498030		VALVE, IDLE, ADJUSTMENT
121	499233		CARBURETOR OVERHAUL KIT
123	94913		SCREW, TORX HEX
125	499153		CARBURETOR ASSY
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
164	214047		ELBOW, CARBURETOR
166	94555		STUD, ROCKER ARM
171			CHECK WITH SUPPLIER
187	492790		HOSE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
201	262767		LINK, GOVERNOR
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	495157		CRANK, GOVERNOR, 1/4" DIAMETER
227	493935		LEVER ASSY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
294	810068		SCREW, SET
304	496318		HOUSING, BLOWER
305	94786		SCREW
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	497602		BOLT, THRU
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
346	93705		SUB= 69485
356	497708		WIRE ASSY
356A	497671		WIRE, STOP
356B	494705		WIRE, STOP
358	495993		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94903		SCREW, HEX HEAD
445	496894		CARTRIDGE, AIR CLEANER
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
524	281370		SEAL, FILLER TUBE


Ref #	Part Number	Qty	Description
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	497603		ARMATURE, STARTER
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	493496		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
634	494455		SEAL, SPRING ASSY.
634A	491323		SEAL, GOVERNOR
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94906		SCREW
663	94929		SCREW, SELF-TAPPING
668	280848		SPACER
718	230192		PIN, DOWEL
726	392134		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	225170		RETAINER, WIRE
729A	281390		CLIP, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	493880		TERMINAL, IGNITION CABLE
868	494435		SEAL ASSEMBLY, VALVE
868A	272610		GASKET, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
872	281104		COVER, AIR CLEANER
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
947	497672		SOLENOID
965	94108		LOCKNUT, AIR CLEANER MOUNTING
975	495933		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1005	280687		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	496758		LABEL KIT
1022	272475		GASKET, COVER
1023	224552		COVER, ROCKER ARM
1026	494432		ROD, PUSH, INTAKE
1026	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	495992		VALVE OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	499364		LABEL KIT, EMISSIONS

Ref #	Part Number	Qty	Description
1044	94673		SCREW, SHOULDER, HEX HEAD
1045	231828		EXTENSION, CRANKSHAFT
1058	272623		MANUAL, OWNER'S
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
2500	28N707-1026		REPLACEMENT ENGINE
	496050		REPLACEMENT SHORTBLOCK




TRACTOR - - MODEL NUMBER 9149A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 267707, TYPE NUMBER 1255-E1



★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL



Ref #	Part Number	Qty	Description
1	496412		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	495858		HEAD, CYLINDER
7	272614		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
12	271996		GASKET, CRANKCASE COVER .009"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	495860		PISTON ASSY, STANDARD SIZE
25	495977		PISTON ASSY .010" OVERSIZE
25	495978		PISTON ASSY .020" OVERSIZE
25	495979		PISTON ASSY .030" OVERSIZE
26	495854		RING SET, PISTON, STANDARD SIZE
26	495852		RING SET, PISTON, .010" OVERSIZE
26	495851		RING SET, PISTON, .020" OVERSIZE
26	495855		RING SET, PISTON, .030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
29	494504		ROD ASSY, CONNECTING
29	495490		ROD ASSY, CONNECTING
32	94695		SCREW
32A	94648		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
37	224502		GUARD, FLYWHEEL
40	224641		RETAINER, VALVE SPRING
45	262411		TAPPET, VALVE
26	496884		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272569		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
73	224948		SCREEN, FLUSH ROTATING
75	225136		WASHER, SPRING
78	94626		SCREW, SEMS
93	281346		BUSHING, THROTTLE SHAFT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224540		VALVE, CHOKE
111	262719		SPRING, CHOKE
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)

Ref #	Part Number	Qty	Description
118	498030		VALVE, IDLE, ADJUSTMENT
121	499233		CARBURETOR OVERHAUL KIT
123	94913		SCREW, TORX HEX
125	499153		CARBURETOR ASSY
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
164	214047		ELBOW, CARBURETOR
166	94555		STUD, ROCKER ARM
171			CHECK WITH SUPPLIER
187	492790		HOSE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
201	262767		LINK, GOVERNOR
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	495157		CRANK, GOVERNOR, 1/4" DIAMETER
227	493935		LEVER ASSY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
294	810068		SCREW, SET
304	496318		HOUSING, BLOWER
305	94786		SCREW
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	497602		BOLT, THRU
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
346	93705		SUB= 69485
356	497708		WIRE ASSY
356A	497671		WIRE, STOP
356B	494705		WIRE, STOP
358	495993		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94903		SCREW, HEX HEAD
445	496894		CARTRIDGE, AIR CLEANER
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
524	281370		SEAL, FILLER TUBE



Ref #	Part Number	Qty	Description
	525 496113		TUBE, OIL FILLER
	535 272403		ELEMENT, AIR CLEANER
	537 281106		O-RING, AIR CLEANER
	544 497603		ARMATURE, STARTER
	552 231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
	562 94907		BOLT, GOVENOR LEVEL
	592 231978		NUT, HEX
	601 93053		CLAMP, HOSE, GREEN
	611 493496		ELBOW, FUEL PIPE
	614 93306		COTTER, HAIR PIN
	615 263080		RETAINER
	634 494455		SEAL, SPRING ASSY.
	634A 491323		SEAL, GOVERNOR
	635 280872		ELBOW, SPARK PLUG
	646 224546		BRACE, AIR CLEANER
	657 94906		SCREW
	663 94929		SCREW, SELF-TAPPING
	668 280848		SPACER
	718 230192		PIN, DOWEL
	726 392134		GEAR, RING
	727 490324		COVER, STARTER
	728 94951		SCREW, HEX HEAD
	729 225170		RETAINER, WIRE
	729A 281390		CLIP, WIRE
	741 262932		GEAR, TIMING
	757 213998		LINK, COUNTERWEIGHT
	758 399891		COUNTERWEIGHT ASSY
	759 298909		PIN ASSY, PISTON, STD
	761 94593		SCREW, COUNTERWEIGHT
	783 280104		GEAR, STARTER
	801 394856		CAP, DRIVE
	802 497605		P/N CONFLICT - CHECK WITH SUPPLIER
	803 497604		HOUSING, STARTER
	842 270920		SEAL, OIL FILLER CAP
	847 496415		P/N CONFLICT - CHECK WITH SUPPLIER
	851 493880		TERMINAL, IGNITION CABLE
	868 494435		SEAL ASSEMBLY, VALVE
	868A 272610		GASKET, VALVE
	871 262835		BUSHING, GUIDE (INTAKE & EXHAUST)
	872 281104		COVER, AIR CLEANER
	875 495862		BODY, AIR CLEANER
	877 393456		DIODE & CONNECTOR ASSY
	947 497672		SOLENOID
	965 94108		LOCKNUT, AIR CLEANER MOUNTING
	975 495933		BOWL ASSEMBLY, CARBURETOR
	977 494385		CARBURETOR GASKET KIT
	987 281166		SEAL, THROTTLE SHAFT
	1005 280687		FAN, FLYWHEEL
	1006 224413		RETAINER, FAN
	1019 496758		LABEL KIT
	1022 272475		GASKET, COVER
	1023 224552		COVER, ROCKER ARM
	1026 494432		ROD, PUSH, INTAKE
	1026 495136		ROD, PUSH, EXHAUST
	1029 224554		ARM, ROCKER
	1033 495992		VALVE OVERHAUL KIT
	1034 495248		GUIDE ASSEMBLY, PUSH ROD
	1036 499364		LABEL KIT, EMISSIONS

Ref #	Part Number	Qty	Description
1044	94673		SCREW, SHOULDER, HEX HEAD
1045	231828		EXTENSION, CRANKSHAFT
1058	272623		MANUAL, OWNER'S
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
2500	28N707-1026		REPLACEMENT ENGINE
	496050		REPLACEMENT SHORTBLOCK



TRACTOR - - MODEL NUMBER 9149A89

BRIGGS & STRATTON ENGINE - MODEL NUMBER 287707, TYPE NUMBER 1255-E1



Ref #	Part Number	Qty	Description
1	496412		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	494238		BASE, ENGINE
5	495858		HEAD, CYLINDER
7	272614		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	281246		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12	271997		GASKET, CRANKCASE COVER .005"
12	271996		GASKET, CRANKCASE COVER .009"
13	94728		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	495860		PISTON ASSY, STANDARD SIZE
25	495977		PISTON ASSY .010" OVERSIZE
25	495978		PISTON ASSY .020" OVERSIZE
25	495979		PISTON ASSY .030" OVERSIZE
26	495854		RING SET, PISTON, STANDARD SIZE
26	495852		RING SET, PISTON, .010" OVERSIZE
26	495851		RING SET, PISTON, .020" OVERSIZE
26	495855		RING SET, PISTON, .030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
29	494504		ROD ASSY, CONNECTING
29	495490		ROD ASSY, CONNECTING
32	94695		SCREW
32A	94648		SCREW
33	495856		VALVE, EXHAUST
34	495857		VALVE, INTAKE
35	262811		SPRING, VALVE
37	224502		GUARD, FLYWHEEL
40	224641		RETAINER, VALVE SPRING
45	262411		TAPPET, VALVE
26	496884		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272569		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
73	224948		SCREEN, FLUSH ROTATING
75	225136		WASHER, SPRING
78	94626		SCREW, SEMS
93	281346		BUSHING, THROTTLE SHAFT
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT
108	224540		VALVE, CHOKE
111	262719		SPRING, CHOKE
117	232118		JET, MAIN (STANDARD)
117	232119		JET, MAIN (HIGH ALTITUDE)

Ref #	Part Number	Qty	Description
118	498030		VALVE, IDLE, ADJUSTMENT
121	499233		CARBURETOR OVERHAUL KIT
123	94913		SCREW, TORX HEX
125	499153		CARBURETOR ASSY
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	232117		NOZZLE, CARBURETOR
164	214047		ELBOW, CARBURETOR
166	94555		STUD, ROCKER ARM
171			CHECK WITH SUPPLIER
187	492790		HOSE, FUEL
188	94627		SCREW, SEMS 3/4"
192	492160		SCREW ASSY, ROCKER ARM
201	262767		LINK, GOVERNOR
209	260695		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	495157		CRANK, GOVERNOR, 1/4" DIAMETER
227	493935		LEVER ASSY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
232	262785		SPRING, GOVERNOR LINK
238	262836		CAP, VALVE
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
294	810068		SCREW, SET
304	496318		HOUSING, BLOWER
305	94786		SCREW
306	225020		SHIELD, CYLINDER
307	94930		SCREW
309	497595		MOTOR, STARTING, 12 VOLT
310	497602		BOLT, THRU
311	497608		BRUSH SET
333	495859		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	491055		PLUG, SPARK
346	93705		SUB= 69485
356	497708		WIRE ASSY
356A	497671		WIRE, STOP
356B	494705		WIRE, STOP
358	495993		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94903		SCREW, HEX HEAD
445	496894		CARTRIDGE, AIR CLEANER
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	495230		CAP AND DIPSTICK, OIL FILLER
524	281370		SEAL, FILLER TUBE


Ref #	Part Number	Qty	Description
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	497603		ARMATURE, STARTER
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	493496		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	263080		RETAINER
634	494455		SEAL, SPRING ASSY.
634A	491323		SEAL, GOVERNOR
635	280872		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	94906		SCREW
663	94929		SCREW, SELF-TAPPING
668	280848		SPACER
718	230192		PIN, DOWEL
726	392134		GEAR, RING
727	490324		COVER, STARTER
728	94951		SCREW, HEX HEAD
729	225170		RETAINER, WIRE
729A	281390		CLIP, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	493880		TERMINAL, IGNITION CABLE
868	494435		SEAL ASSEMBLY, VALVE
868A	272610		GASKET, VALVE
871	262835		BUSHING, GUIDE (INTAKE & EXHAUST)
872	281104		COVER, AIR CLEANER
875	495862		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
947	497672		SOLENOID
965	94108		LOCKNUT, AIR CLEANER MOUNTING
975	495933		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1005	280687		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	496758		LABEL KIT
1022	272475		GASKET, COVER
1023	224552		COVER, ROCKER ARM
1026	494432		ROD, PUSH, INTAKE
1026	495136		ROD, PUSH, EXHAUST
1029	224554		ARM, ROCKER
1033	495992		VALVE OVERHAUL KIT
1034	495248		GUIDE ASSEMBLY, PUSH ROD
1036	499364		LABEL KIT, EMISSIONS

Ref #	Part Number	Qty	Description
1044	94673		SCREW, SHOULDER, HEX HEAD
1045	231828		EXTENSION, CRANKSHAFT
1058	272623		MANUAL, OWNER'S
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER
1091	281364		CAP, LIMITER
2500	28N707-1026		REPLACEMENT ENGINE
	496050		REPLACEMENT SHORTBLOCK



TRACTOR -- MODEL NUMBER 9149A89


CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
1	160393		CHASSIS
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
5	155272		BUMPER-HOOD/DASH
6	155923		SADDLE
8	155138		CLIP.RETAINER
9	161937X011		DASH SILKSCREEN
10	72140608		SUB= 72110608
11	155927		"PANEL-DASH,LH"
12	145660		CLIP.TINNERMAN
13	155934X010		SUB= 169117X010
14	17490608		SCREW LT
15	74180512		SCREW
16	73510500		NUT
17	159639X505		HOOD.STEEL.ASSY
20	156437		"PLATE-MTG,BATT/FU"
23	124028X		SUB= 532124028
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
28	157373		GRILLE-MS428
29	140273		LENS GRILLE
30	157583X505		FENDER.LT.W/SHIFT
31	136619		BRKT FENDER
33	145244X505		FOOTREST.LH.LT/GT
34	145243X505		FOOTREST.RH.LT/GT
35	72110606		BOLT
37			CHECK WITH SUPPLIER
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	161464		SCREW.HEX.WS.HD
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	150127		AIR DUCT
71	73680400		SUB= 73690400
140	158418		BRKT SUSPENSION
145	156524		"ROD POVOT,CHASSIS"
	5479J		PLUG BUTTON T

TRACTOR - - MODEL NUMBER 9149A89

DECALS




Ref #	Part Number	Qty	Description
			REFER TO IMAGE
1	146615		DECAL.FENDER.WIZ
2	145005		DECAL.BATRY.3-3908
3	163017		DECAL.HOOD.RH
4	141517		DECAL DECK WIZ +
5	272991		DECAL, ENGINE
6	157002		"DECAL DANGER,FEND"
7	4900J		DECAL T
8	163018		DECAL.HOOD.LH
9	143349		"DECAL.CHASSIS.42"""
13	146678		DECAL.INS.STRG.WL
15	160396		"DECAL-SCHEM,BELT"
16	127521		NLA
19	156868		"DECAL INST,SADDLE"
	138311		DECAL HANDLE LIFT
	142341		DECAL DRAWBAR LH
	162779		MANUAL.O.9149A89.E
	157199		"PAD-FOOTREST,SQ"



TRACTOR -- MODEL NUMBER 9149A89

DRIVE






Ref #	Part Number	Qty	Description
1	140607		TRANSAXLE HYD 0319-0500
2	142431		SPRING RET BRAKE
3	144698		PULLEY.4.20.HYDRO
8	141003		ROD SHIFT FEND LT
10	76020416		PIN COTTER 1/8
15	74490544		BOLT.HX.FLG.5/16
16	73800500		NUT
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	145627		ROD.BRAKE.HYDRO.
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	71673		PLUNGER CAP T
30	130807		TRANSAXLE MTG BKT
32	74760512		BOLT
34	155071		SHAFT ASM-PEDAL F
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	154777		SUB= 165692
42	19131312		WASHER
47	127783		SUB= 139245
48	154407		BELLCRANK.CLUTCH
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	161850		SUB= 165813
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	161399		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	161488		ENGINE BELT KEEP
69	142432		SCREW HEXWSH H-L
70	134683		KEEPER BELT ENG
71	141417		STRAP.TORQ.LH.HYD
72	19132012		WASHER
73	141418		STRAP.TORQ.RH.HYD
74	121199X		SPACER SPLIT
75			CHECK WITH SUPPLIER
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER
81	161081		SHAFT ASSEMBLY
82	123782X		"SPRING TORSION"
83	19171216		WASHER

Ref #	Part Number	Qty	Description
84	141423		ROD.TIE.BALL.HYD.
86	157480		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	151147		SUB= 164893
91	74780536		NLA
92	74780524		HEX BOLT
93	142564		"LINE FUEL HYD 4""
94	140462		"FAN 7"" HYDRO"
95	144643		SUB= 918144643
96			CHECK WITH SUPPLIER
97	144201		KEEPER.BELT.RH.HY
98	73510600		NUT
100	19111216		WASHER M
103	73940800		SUB= 73360800
104	141421		ARM.CONTROL.PUMP
105	71070516		SCREW CAP 5/16-18
106	74780520		BOLT
108	17541026		SCREW.HXHD.10-20
109	145098		ADAPTOR.FAN.HYDRO
116	72110610		BOLT RDHD 3/8-16
144	19111016		WASHER
148	159103		SPACER
149	122052X		SPACER RETAINER
150	150935		BUSHING.NYLON
151	19133210		WASHER

TRACTOR -- MODEL NUMBER 9149A89


ELECTRICAL




Ref #	Part Number	Qty	Description
1	144925		SUB= 123899X
2			CHECK WITH SUPPLIER
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
8	156417		"CASE,BATTERY.MECH"
16	153664		SWITCH INTERLOCK
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146147		CABLE.BTRY.6GA.RD
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
40	156442		HARNES-IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
48	140844		ADAPTER AMMETER
52	141940		PROTECTION LOOP
70	140422		HARNES.ENG.DUAL

TRACTOR -- MODEL NUMBER 9149A89

ENGINE




Ref #	Part Number	Qty	Description
1	140310		CONTROL THROTTLE
2	17720410		SCREW LT
3			CHECK WITH SUPPLIER
4	137352		MUFFLER
13	272293		GASKET ENG 1 313 LD TIN PLATED
14	13280324		PIPE NIPPLE
15	13200300		ELBOW
16	11050600		LOCKWASHER
23	159880		SHIELD.BRN/DBR.GD
29	137180		SUB= 532137180
31	161911		TANK.FUEL.FRONT.
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
35	17490512		SCREW
37	137040		LINE FUEL
38			CHECK WITH SUPPLIER
40	124028X		SUB= 532124028
44	17490412		SCREW HEX CRT
46	19091416		WASHER
62	10040500		LOCKWASHER
72	71070512		SCREW
78	17490620		SCREW
81	128861		NUT




TRACTOR - - MODEL NUMBER 9149A89

LIFT



Ref #	Part Number	Qty	Description
1	159460		WIRE ASM W.SPRING
2	159471		"SHAFT ASM LIFT,RH"
3	105767X		PIN-GROOVE LT
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	109413X		GRIP
8	124526X		SUB= 125925X
11	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8





Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	159770		BAFFLE VORTEX 42
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	157722		"SCREW-THD ROLL,WA"
31	129963		WASHER
32	153535		PULLEY.MANDREL.42
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	155066		ROLLER ASM-CAM
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845X900		SUB= 131845
54	133943		HARDENED WASHER
55	155046		ARM-IDLER
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	162132		KNOB.RD.7/16-14
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND

Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	160570		LEVER.ASM.CLUTCH
79	127498		BUSHING
80	153701		SPRING.CLUTCH.MWR
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	156084		"KEEPER-BELT,FIXED"
85	72140618		BOLT RDHD 3/8-16
92	73800600		NUT
111	155197		BRACKET.GWHL.LH.
112	155198		BRACKET.GWHL.RH.
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	4898H		BOLT M
117	105455X		WHEEL.GAGE.BLK.PL
118	73930600		LOCKNUT
119	19121414		WASHER
120	19171512		WASHER
121	143723		BRACKET.EXTRD.GWL
128	153390		WASHER.FELT.
132	19132203		WASHER GT
141	6266H		WASHER .T
	130794		MANDREL ASM
	145411		SUB= 164963

TRACTOR - - MODEL NUMBER 9149A89

SCHEMATIC



IGNITION SWITCH

POSITION	CIRCUIT	"MAKES"
OFF	G + M + L	NONE
RUN/LIGHT	B + L	A + Y
RUN	B + L	NONE
START	B + L + S	NONE

NOTE
YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.


WIRING INSULATED CLIPS

NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.


TRACTOR - - MODEL NUMBER 9149A89

SEAT ASSEMBLY

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.





Ref #	Part Number	Qty	Description
1	127428		SUB= 140119
2	140551		BRACKET PVT SEAT
3	74760616		BOLT
4	19131610		WASHER PM
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
8	17490616		SCREW GTV
9	19131614		WASHER
10	155925		PAN-SEAT
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050412		BOLT-RD HD SQ NK
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	153236		"BOLT,SHOULDER"
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER



TRACTOR - - MODEL NUMBER 9149A89

STEERING ASSEMBLY







Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	154427		AXLE ASM
3	156483		SPINDLE.ASM.LH
4	157473		"SPINDLE ASM,RH"
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	156438		DRAGLINK-STAMPED
11	10040600		LOCKWASHER
13	154779		BEARING AXLE
15	73901000		"NUT-LOC,FLANGE LT"
17	156546		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
22	71200410		SCREW HEX SOC1/4-
23	127501		SUB= 918127501
25	154406		BRKT-STEERING
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	155099		BUSHING.STEERING
37	152927		"SCREW-TT,10-32 FL"
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	100711L		ADAPTER LT
42	145054		BOOT.STEER.PL
43			CHECK WITH SUPPLIER
44	153720		EXT SHAFT STEERIN
46	121232X		CAP
47	6855M		ZERK M
51	73800500		NUT
54	74780520		BOLT
62	156594		KIT STEERING ASM
63	74780616		BOLT
65	154780		SPACER AXLE
66	154404		"BEARING-ARM,PITMA"
67	74781044		BOLT
68	154429		BRACE AXLE

TRACTOR - - MODEL NUMBER 9149A89 HYDRO TRANSAXLE - MODEL NUMBER 0310-500

TRANSAXLE






Ref #	Part Number	Qty	Description
1	142986		HOUSING.L.44863RM
2	142987		HOUSING.UPR.70122
3	142932		SEAL.9008000-0128
4	142928		RING.RET.2003016.
5	142933		RING.RET.2003052.
6	142934		BEARING.(50552)42X68X16
7	142935		CRADLE- 2003023.
8	150771		BEARING.THU.50551
9	142937		SWASHPLT.2003087.
13	142938		BLOCK.CLYN.70079.
14	142939		ARM.TRUN.2003005.
15	142940		SEAL.9008000-0126
17	142941		GUIDE.2000015.
18	150772		SHAFT.MOTOR.50449
19	150773		BEARING.THU.50552
23	142944		BLOCK.CYLIN.70082
24	142945		SEAL.LIP.45074
25	142946		ACTUATOR.2003555
26	150774		KIT.CEN.SEC.70250
27	142948		SEAL.LIP.45075
28	142949		RING RETAIN 50007
29	142950		WASHER.44872
30	150787		PLATE.BYP.2003554
34	142951		ELEMENT.OIL.44964
35	142952		ARM.BYPASS.50270
36	142953		RING.RETAIN.44870
37	142954		ARM.ACTUAT.23710
38	142955		PIN.ACTUAT.44891
39	150777		BOLT.50316
40	150778		NUT.LOCK.HX.50317
41	142958		KIT.BRAKE.70135
43	142884		WASHER HYD 44130
44	142990		DIFFERENTIAL.70126
52	142991		WASHER.HYD.44875
53	142961		SEAL.HYDRO.45076
56	142963		SHAFT.INPUT.50005
58	142964		BOLT.1/4-20.44876
59	142965		PIN.HYDRO.50002
62	142966		ARM.CONTROL.50254
63	142967		PUCK.DAMPER.50281
64	142920		SCREW.SET.50018.
68	142969		SPRING.HYD.50277
69	144610		STUD.5/16-24.DANA
92	142977		SPRING.2003014.
93	142978		WASHER.2003017
98	142993		BEARING.SLV.50137
99	142976		SEAL.WIPER.50941
113	142917		CAP.VENT.70109
114	142918		O-RING.ASM.70110
119	142980		SPACER.HYD.50278
134	144607		NUT.CAS.HYD.44142
135	144608		PIN.COT.HYD.44101
139	150775		SPRING.COMP.50431
140	150776		NUT.HEX.50269

TRACTOR - - MODEL NUMBER 9149A89

WHEELS & TIRES



NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	106268X		SUB= 122074X
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP
	144334		SEALANT.TIRE 10 OZ. TUBE

