


Ref #	Part Number	Qty	Description
1	145501		CHASSIS.WLD.11GA
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
5	11050600		LOCKWASHER
6	145208X016		SUB= 155924X015
7	126842X		"SHIELD,HEAT HOOD"
8	126471X		"CLIP,INSULATOR"
9	145938X001		DASH
10	72140608		SUB= 72110608
11	135464		DASH PANEL LH
12	11030400		LOCKWASHER GT
13	124031X012		SUB= 155934X010
14	17490608		SCREW LT
15	74180512		SCREW
16	73510500		NUT
17	131445X417		SUB= 154988X417
18	126938X		SUB= 532126938
19	17521312		SCREW SLTD HXHD
21	122933X		"RIVET,PLASTIC"
22	124479X		SUB= 532124479
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
27	17030814		SUB= 91817030814
28	140135		SUB= 142035
29	124029X		SUB= 124029X599
30	109872X417		SUB= 157584X417
31	136619		BRKT FENDER
33	145244X417		FOOTREST.LH.LT/GT
34	145243X417		FOOTREST.RH.LT/GT
35	72110606		BOLT
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
100	105037X		FOAM-STRIP LT
	5479J		PLUG BUTTON T


TRACTOR - - MODEL NUMBER 917.252500

DANA TRANSAXLE - MODEL NUMBER 4360-79




Ref #	Part Number	Qty	Description
1	142671		HOUSING UPPER TRN
2	2274J		SUB= 74760412
3	134400		SUB= 68003
4	105904X		"SPRING, DETENT LT"
5	105905X		"SCREW, SET LT"
6	138235		KIT SHIFTER ASM
7	134399		SHIFTER BOOT
8	134791		SCREW TAP W/SEAL
9	138241		SQUARE RING
10	142672		SUB= 2225J
11	134793		ASM KIT SHIM 4689
12	142673		BEARING FLAN-DANA
13	120415X		WASHER T
14	142674		KEY WOODRUFF-DANA
15	138234		AS KIT INPUT SHFT
16	110078X		PINION 14T T
17	105909X		"RING,RETAINING LT"
18	105910X		"CHAIN,24 PTCH LT"
19	105911X		BEARING.FLNG.5510
20	142675		GEAR SPUR 14 TTH
21	138246		COLLAR CLUTCH
22	138236		ASM KIT CLTCH KEY
23	73810500		NUT.LOCK.5/16-24
24	142676		SHAFT INTERM DANA
25	2244J		WOODRUFF KEY
26	105916X		"RING,RETAINING LT"
27	120470X		SPROCKET 18T T
28	110070X		SPACER YT
29	142677		GEAR SPUR 37 TTH
30	142681		GEAR SPUR 35 TTH
31	120405X		SUB= 124644X
32	108980X		GEAR 25T LT
33	120406X		GEAR SPUR 22 TT
34	134796		SPUR GEAR 19T
35	105925X		"WASHER, PLAIN LT"
36	2232J		WASHER 025
37	108978X		SPACER
38	110079X		ASSM GEAR COMB
39	124639X		SHAFT IDLER
40	120472X		SPACER T
41	105928X		SPROCKET 9T LT
42	110084X		SUB= 167148
43	134394		ASM KIT SHIM
44	120473X		SHAFT T
45	142678		GEAR SPUR 12 TTH
46	142679		GEAR SPUR 15 TTH
47	120407X		SUB= 124641X
48	106589X		"GEAR, SPUR 25T LT"
49	120408X		GEAR 28T T
50	105937X		"GEAR, SPUR 31T LT"
51	2226J		WASHER 060
52	134401		NEOPRENE WASHER
53	2264J		WASHER 031
54	120474X		SUB= 154658
55	110081X		GEAR 15T T
56	105941X		"RING,RETAINING LT"
57	110071X		SUB= 120478X
58	120952X		SHAFT T

Ref #	Part Number	Qty	Description
59	110082X		GEAR 1ST T
60	120475X		SUB= 154659
61	142680		HOUSING LOWER TNS
62	120961X		PUCK T
63	7294J		BRAKE DISC. T
64	108989X		SPACER LT
65	120953X		SUB= 918120953X
66	120954X		PIN T
67	134799		TAP SCREW
68	138244		SUB= 108992X
69	108996X		WASHER LT
70	120956X		NLA
71	106596X		"SCREW, TAPPING LT"
72	120951X		PUCK T
73	120416X		SUB= 126976X





TRACTOR - - MODEL NUMBER 917.252500

DECALS



Ref #	Part Number	Qty	Description
1	138955		DECAL.DASH.INST.
2	142236		SUB= 272937
3	140560		DECAL.HOOD.RH
4	140561		DECAL.HOOD.LH
5	132674		GRILL DECAL
6	133644		DECAL
7	142248		DECAL SIDE PN IC
8	140837		DECAL BRAK PARK
9	125880X		"DECAL,FENDER"
11	137537		SUB= 156439
12	4900J		DECAL T
13	146046		DECAL.BELT-V.SCHM
14	131473		CHASSIS DECAL
15	136832		DECAL
16	145245		SUB= 918145245
17	142251		DECAL.INS.HD.13HP
18	133179		DECAL MWR QC SYS
21	131265		DECAL LIGHTBOX
	138311		DECAL HANDLE LIFT
	145247		FASTNER.POPIN.(8)
	146433		MANUAL OWNERS 252500 ENGLISH
	146435		MANUAL OWNERS 252500 SPANISH






Ref #	Part Number	Qty	Description
1	142603		SUB= 160664
2	146682		SPRING.BRAKE.RETU
3	123666X		PULLEY TRANS
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
6	17490512		SCREW
7	130802		SUB= 162240
8	131679		SHIFT ROD
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
12	19151216		WASHER
11	105701X		WASH-SHFT PLT LT
12	19151216		WASHER
13	74550412		BOLT.1/4-28.W/PAT
14	10040400		LOCKWASHER
15	74780544		BOLT HEX
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
24	73350600		NUT
25	106888X		SPRING ROD LT
56	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	124236X		CAP
30	130807		TRANSAXLE MTG BKT
31	127275X		"KEEPER,BELT LH T"
32	74760512		BOLT
34	122424X		SUB= 149001
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	130801		SUB= 138255
58	127274X		"KEEPER,BELT RH T"
59	140312		KEEPER BELT CNTSP
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	129921		KEEPER.BELT.ENG.L

Ref #	Part Number	Qty	Description
70	134683		KEEPER BELT ENG
72	19132012		WASHER
74	109502X		SPACER LT
75	121749X		WASHER
76	12000001		E-RING LT
78	121748X		WASHER
100	19111216		WASHER M
112	19091210		WASHER LT






Ref #	Part Number	Qty	Description
1	121265X		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
5	121264X		"CAP,BATTERY "
6	73220400		SUB= 50675
7	109238X		TUBE T
8	129965		SUB= 156417
9	109596X		HOSE CLAMP T
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
25	146147		CABLE.BTRY.6GA.RD
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	144921		SUB= 163088
31	140400		SUB= 145774
32	141226		COVER KEY SWITCH
33	140403		KEY MLD CRAF DELT
34	110712X		SWITCH LT
35	108236X		BRACKET LT
36	17021008		SCREW
38	140336		BRACKET SWITCH IN
39	109553X		SWITCH INTERLOCKT
40	146057		HARNES.IGN.DASH.
41	71110412		BOLT.HX.1/4-20
24	131563		SUB= 154336
43	145673		SUB= 146154
44	73800400		NUT
45	121433X		SUB= 122822X
49	11151000		LOCKWASHER
70	140413		HARNES ENG DUAL

TRACTOR - - MODEL NUMBER 917.252500

ENGINE




OPTIONAL EQUIPMENT
Spark Arrester

Ref #	Part Number	Qty	Description
1	132759		SUB= 918132759
2	17720410		SCREW LT
3	140591		ENGINE SAM B&S DMD 13EEC ICGLD
4	137348		MUFFLER
13	125593X		SUB= 272293
14	13280324		PIPE NIPPLE
15	13200300		ELBOW
16	11050600		LOCKWASHER
18	136718		SHIELD HEAT
19	105839X		RECEPTACLE LT
20	105838X		RETAINER LT
21	19091016		WASHER
22	123650X		STUD.1/4.TURN
23	128953		HEAT SHIELD
24	17021008		SCREW
29	137180		SUB= 532137180
30	127057X		SUB= 532127057
31	109202X		TANK.FUEL.LT.
32	123549X		SUB= 158990
33	123487X		HOSE CLAMP
37	137040		LINE FUEL
38			REFER TO IMAGE
40	124028X		SUB= 532124028
44	17490412		SCREW HEX CRT
46	19091416		WASHER
62	10040500		LOCKWASHER
72	71070512		SCREW
78	17490620		SCREW
81	73510400		NUT

TRACTOR - - MODEL NUMBER 917.252500

BRIGGS & STRATTON ENGINE - MODEL NUMBER 28M707, TYPE NUMBER 0137-01





Ref #	Part Number	Qty	Description
1	496413		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
6	22963		WASHER, FLAT
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
	271997		GASKET, CRANKCASE COVER .005"
	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394661		PISTON ASSEMBLY, STANDARD
	394662		PISTON ASSEMBLY .010" OVERSIZE
	394663		PISTON ASSEMBLY .020" OVERSIZE
	394664		PISTON ASSEMBLY .030" OVERSIZE
26	391780		RING SET, PISTON, STANDARD
	392331		RING SET, PISTON, STANDARD SIZE
	391781		RING SET, PISTON .010" OVERSIZE
	391782		RING SET, PISTON .020" OVERSIZE
	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
89	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272554		GASKET CARB
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT

Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94073		SCREW, HEX HEAD
284A	94704		SCREW, AIR CLEANER
304	496280		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309	394805		MOTER AND DRIVE ASSY.
310	94003		BOLT
311	395538		BRUSH ASSEMBLY
332A	94314		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER
455	222451		CARTRIDGE, AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	226968		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	495878		STARTER DRIVE GROUP
512	398003		CLUTCH ASSEMBLY
523	495230		CAP AND DIPSTICK, OIL FILLER

Ref #	Part Number	Qty	Description
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	390837		ARMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	494421		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	49034		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	24723		RETAINER, WIRE
741	262962		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	395537		END CAP ASSY. COMMUTATOR
803	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
872	281361		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
876	495877		RETAINER AND PIN
877	393456		DIODE & CONNECTOR ASSY
896	94288		ROLL PIN
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1005	281355		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD

TRACTOR - - MODEL NUMBER 917.252500

BRIGGS & STRATTON ENGINE - - MODEL NUMBER 28M707, TYPE NUMBER 0137-01




Ref #	Part Number	Qty	Description
1	496413		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
6	22963		WASHER, FLAT
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
	271997		GASKET, CRANKCASE COVER .005"
	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394661		PISTON ASSEMBLY, STANDARD
	394662		PISTON ASSEMBLY .010" OVERSIZE
	394663		PISTON ASSEMBLY .020" OVERSIZE
	394664		PISTON ASSEMBLY .030" OVERSIZE
26	391780		RING SET, PISTON, STANDARD
	392331		RING SET, PISTON, STANDARD SIZE
	391781		RING SET, PISTON .010" OVERSIZE
	391782		RING SET, PISTON .020" OVERSIZE
	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
89	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272554		GASKET CARB
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT

Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94073		SCREW, HEX HEAD
284A	94704		SCREW, AIR CLEANER
304	496280		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309	394805		MOTER AND DRIVE ASSY.
310	94003		BOLT
311	395538		BRUSH ASSEMBLY
332A	94314		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER
455	222451		CARTRIDGE, AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	226968		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	495878		STARTER DRIVE GROUP
512	398003		CLUTCH ASSEMBLY
523	495230		CAP AND DIPSTICK, OIL FILLER

Ref #	Part Number	Qty	Description
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	390837		ARRMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	494421		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	49034		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	24723		RETAINER, WIRE
741	262962		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	395537		END CAP ASSY. COMMUTATOR
803	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
872	281361		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
876	495877		RETAINER AND PIN
877	393456		DIODE & CONNECTOR ASSY
896	94288		ROLL PIN
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1005	281355		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD

TRACTOR -- MODEL NUMBER 917.252500

BRIGGS & STRATTON ENGINE - MODEL NUMBER 28M707, TYPE NUMBER 0137-01







Ref #	Part Number	Qty	Description
1	496413		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
6	22963		WASHER, FLAT
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
	271997		GASKET, CRANKCASE COVER .005"
	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394661		PISTON ASSEMBLY, STANDARD
	394662		PISTON ASSEMBLY .010" OVERSIZE
	394663		PISTON ASSEMBLY .020" OVERSIZE
	394664		PISTON ASSEMBLY .030" OVERSIZE
26	391780		RING SET, PISTON, STANDARD
	392331		RING SET, PISTON, STANDARD SIZE
	391781		RING SET, PISTON .010" OVERSIZE
	391782		RING SET, PISTON .020" OVERSIZE
	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
89	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272554		GASKET CARB
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT

Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94073		SCREW, HEX HEAD
284A	94704		SCREW, AIR CLEANER
304	496280		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309	394805		MOTER AND DRIVE ASSY.
310	94003		BOLT
311	395538		BRUSH ASSEMBLY
332A	94314		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER
455	222451		CARTRIDGE, AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	226968		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	495878		STARTER DRIVE GROUP
512	398003		CLUTCH ASSEMBLY
523	495230		CAP AND DIPSTICK, OIL FILLER

Ref #	Part Number	Qty	Description
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	390837		ARRMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	494421		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	49034		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	24723		RETAINER, WIRE
741	262962		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	395537		END CAP ASSY. COMMUTATOR
803	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
872	281361		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
876	495877		RETAINER AND PIN
877	393456		DIODE & CONNECTOR ASSY
896	94288		ROLL PIN
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1005	281355		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD

TRACTOR - - MODEL NUMBER 917.252500

BRIGGS & STRATTON ENGINE - MODEL NUMBER 28M707, TYPE NUMBER 0137-01




Ref #	Part Number	Qty	Description
1	496413		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
6	22963		WASHER, FLAT
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
	271997		GASKET, CRANKCASE COVER .005"
	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394661		PISTON ASSEMBLY, STANDARD
	394662		PISTON ASSEMBLY .010" OVERSIZE
	394663		PISTON ASSEMBLY .020" OVERSIZE
	394664		PISTON ASSEMBLY .030" OVERSIZE
26	391780		RING SET, PISTON, STANDARD
	392331		RING SET, PISTON, STANDARD SIZE
	391781		RING SET, PISTON .010" OVERSIZE
	391782		RING SET, PISTON .020" OVERSIZE
	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
89	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	272554		GASKET CARB
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT

Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94073		SCREW, HEX HEAD
284A	94704		SCREW, AIR CLEANER
304	496280		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309	394805		MOTER AND DRIVE ASSY.
310	94003		BOLT
311	395538		BRUSH ASSEMBLY
332A	94314		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER
455	222451		CARTRIDGE, AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	226968		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	495878		STARTER DRIVE GROUP
512	398003		CLUTCH ASSEMBLY
523	495230		CAP AND DIPSTICK, OIL FILLER


Ref #	Part Number	Qty	Description
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
535	272403		ELEMENT, AIR CLEANER
537	281106		O-RING, AIR CLEANER
544	390837		ARRMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	494421		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	49034		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	24723		RETAINER, WIRE
741	262962		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
783	280104		GEAR, STARTER
801	394856		CAP, DRIVE
802	395537		END CAP ASSY. COMMUTATOR
803	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
872	281361		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
876	495877		RETAINER AND PIN
877	393456		DIODE & CONNECTOR ASSY
896	94288		ROLL PIN
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1005	281355		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD

TRACTOR - - MODEL NUMBER 917.252500

LIFT




Ref #	Part Number	Qty	Description
1	136973		WIRE ASM
2	122507X		SUB= 145117
3	105767X		PIN-GROOVE LT
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
10	122512X		SUB= 532122512
11	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8




TRACTOR - - MODEL NUMBER 917.252500

MOWER



Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	STD533107		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	STD624008		RETAINER RING
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	STD551137		WASHER, LOCK
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	138776		SUB= 157722
31	129963		WASHER
32	129861		SUB= 153535
33	137266		SUB= 139729
34	STD533717		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	STD624003		RETAINER
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	133940		SUB= 151785
50	131340		SHOULDER BOLT
51	STD541410		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	140084		SUB= 151785
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	106932X		KNOB T(3/8 HOLE)
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND


Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	140334		SUB= 154810
79	127498		BUSHING
80	128759		SUB= 918128759
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	144394		SUB= 156084
85	STD533725		BOLT CARRIAGE
92	73800600		NUT
	130794		MANDREL ASM
	145411		SUB= 164963




TRACTOR - - MODEL NUMBER 917.252500


SEAT ASSEMBLY

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



Ref #	Part Number	Qty	Description
1	140122		SUB= 140119
2	140551		BRACKET PVT SEAT
3	74760616		BOLT
4	19131610		WASHER PM
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
8	17490616		SCREW GTV
9	19131614		WASHER
10	140552		SUB= 155925
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	139888		BOLT.SHLD.5/16-18
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER






Ref #	Part Number	Qty	Description
1	139768		SUB= 150547
2	142033		AXLE ASM FRONT
3	135227		SPINDLE LH
4	135228		SPINDLE RH
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	130468		SUB= 532130468
11	10040600		LOCKWASHER
12	73610600		SUB= 7810H
13	110438X		BEARING
14	74011056		BOLT HEX 5/8-11
15	73901000		"NUT-LOC,FLANGE LT"
16	132624		AXLE PIN
17	132614		SHAFT ASM
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71070410		"SCREW,SPECIAL"
23	127501		SUB= 918127501
24	109816X		NYLINER T
25	124036X		"BRKT,STEERING"
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	132196		SUB= 155106
37	17431008		SUB= 98000165
38	139769		CAP WHL STR SEARS
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	104820X		ADAPTER-WHEEL LT
42	124417X		BOOT STR SHAFT
43	121749X		WASHER
46	121232X		CAP
47	6855M		ZERK M

TRACTOR - - MODEL NUMBER 917.252500

WHEELS & TIRES



NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X417		"RIM,FRT T"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X417		"RIM 8""
9	124635X		SUB= 126957X
10	7152J		TUBE.18X9.5-8
11	140757X		CAP HUB AXLE BLK 1 50X 1 00

