


# TRACTOR -- MODEL NUMBER AYP1184A69


## CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
1	145501		CHASSIS.WLD.11GA
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
6	145208X016		SUB= 155924X015
8	126471X		"CLIP,INSULATOR"
9	140072		SUB= 532142465
10	72140608		SUB= 72110608
11	146965		PANEL.DASH.LH.
12	145660		CLIP.TINNERMAN
13	146959		PANEL.DASH.RH
14	17490608		SCREW LT
17	139394X505		SUB= 159639X505
20	140281		SUB= 140281X431
23	124028X		SUB= 532124028
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
28	140434		GRILL.BLK
29	140273		LENS GRILLE
30	109872X505		FENDER
31	139976		BRACKET SUPT FEND
33	105476X505		FOOTREST LH
34	105475X505		FOOTREST RH
35	72110606		BOLT
37	17490508		SCREW LT
38	139886		BRACKET ASM LH
37	139887		BRACKET ASM RH
40	139977		SPACER FENDER LT
41	139978		PLATE EXTEN FEND
48	138096		RIVET.PUSH.PLATE
49	17490412		SCREW HEX CRT
50	142779		BRACE SUPT DASH
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	17030814		SUB= 91817030814
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	140547		DUCT.AIR.B&S.18HP
60	72140606		BOLT
61	19171416		WASHER
68	73510400		NUT
	5479J		PLUG BUTTON T
	134014		PLUG DOME

## TRACTOR - - MODEL NUMBER AYP1184A69

### DECALS




Ref #	Part Number	Qty	Description
1	146451		DECAL.BTRY.DANGER
3	146676		DECAL.HD.RH.WIZAR
5	273244		DECAL ENGINE
6	133796		DECAL
7	4900J		DECAL T
8	146677		DECAL.HD.LH.WIZAR
9	141502		DECAL CHASSIS WIZ
10	151536		DECAL.INS.HD.WIZA
13	146678		DECAL.INS.STRG.WL
15	136832		DECAL
16	127521		NLA
19	140819		SUB= 156867
	138311		DECAL HANDLE LIFT
	152757		MANUAL.AYP1184A69




# TRACTOR - - MODEL NUMBER AYP1184A69

## DRIVE




Ref #	Part Number	Qty	Description
1	145607		SUB= 161451
2	146682		SPRING.BRAKE.RETU
3	123666X		PULLEY TRANS
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
6	17490512		SCREW
7	130802		SUB= 162240
8	131679		SHIFT ROD
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
12	19151216		WASHER
13	74550412		BOLT.1/4-28.W/PAT
14	10040400		LOCKWASHER
15	74490544		BOLT.HX.FLG.5/16
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	71673		PLUNGER CAP T
30	130807		TRANSAXLE MTG BKT
31	127275X		"KEEPER,BELT LH T"
32	74760512		BOLT
34	149001		SHAFT.PEDAL.FOOT
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
78	130801		SUB= 138255
58	127274X		"KEEPER,BELT RH T"
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	129921		KEEPER BELT ENGL
70	134683		KEEPER BELT ENG

Ref #	Part Number	Qty	Description
72	19132012		WASHER
74	109502X		SPACER LT
75	121749X		WASHER
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER
112	19091210		WASHER LT



# TRACTOR - - MODEL NUMBER AYP1184A69

## ELECTRICAL






Ref #	Part Number	Qty	Description
1	146139		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	109238X		TUBE T
8	144940		SUB= 156417
9	109596X		HOSE CLAMP T
15	147688		FASTNER.SNAP-IN
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4206J		CABLE-BATTERY T
25	146147		CABLE.BTRY.6GA.RD
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
35	108236X		BRACKET LT
36	17021008		SCREW
38	140336		BRACKET SWITCH IN
39	109553X		SWITCH INTERLOCKT
40	151212		HARNES.IGNITION
471	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
48	140844		ADAPTER AMMETER
52	141940		PROTECTION LOOP
70	140712		HARNES.ENG.LT.

# TRACTOR - - MODEL NUMBER AYP1184A69


## ENGINE



Ref #	Part Number	Qty	Description
1	141295		CONTROL THRT 35.5
2	17720410		SCREW LT
3			REFER TO IMAGE
4	149723		MUFFLER.TW.LOTONE
5	144069		EXHAUST.B&S.18.LH
6	144068		EXHAUST.B&S.18.RH
7	138129		CLAMP.TUBE.DBL.EN
8	150176		BOLT.5/16-18.UNC
10	145552		SHIELD.HEAT.
11	10040400		LOCKWASHER
12	74780412		SUB= 74780414
13	272250		GASKET MUFFLER
14	13280336		PIPE NIPPLE LT
15	13200300		ELBOW
16	11050600		LOCKWASHER
17	17490624		SCREW LT
23	128953X		SUB= 128953
24	17021008		SCREW
25	145996		CONTROL.CHOKE.37
26	73920600		"NUT,KEPS 3/8-24IM"
27	17541008		SCREW.10-24X1/2
29	137180		SUB= 532137180
31	140280		SUB= 161911
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
37	137040		LINE FUEL
38			REFER TO IMAGE
40	124028X		SUB= 532124028
44	17490412		SCREW HEX CRT
46	19091416		WASHER
81	128861		NUT

# TRACTOR - - MODEL NUMBER AYP1184A69

## BRIGGS & STRATTON ENGINE - MODEL NUMBER 422707, TYPE NUMBER 1529-01




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	491756		BEARING, CYLINDER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
	271188		GASKET, CRANKCASE COVER,.005"
	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
	394956		PISTON ASSEMBLY,.010" OVERSIZE
	394957		PISTON ASSEMBLY,.020" OVERSIZE
	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
	394960		RING SET, PISTON,.010" OVERSIZE
	394961		RING SET, PISTON,.020" OVERSIZE
	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94834		SCREW, SEMS
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR
93	231209		BUSHING, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	495588		HOUSING, BLOWER
305	94786		SCREW
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER
307	93343		SCREW, SEMS
308-1	224774		COVER, AIR GUIDE
308-2	224775		COVER, AIR GUIDE
309	497287		MOTOR, STARTER

Ref #	Part Number	Qty	Description
310	497602		BOLT, THRU
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	495868		IN GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	272638		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494927		CAP AND DIPSTICK, OIL FILLER
524	280860		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
534	94823		SCREW ROUND HEAD
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262694		GEAR, TIMING
801	394860		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING


Ref #	Part Number	Qty	Description
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491262		DECAL KIT
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER





# TRACTOR -- MODEL NUMBER AYP1184A69

BRIGGS & STRATTON ENGINE - MODEL NUMBER 422707, TYPE NUMBER 1529-01




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	491756		BEARING, CYLINDER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
	271188		GASKET, CRANKCASE COVER,.005"
	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
	394956		PISTON ASSEMBLY,.010" OVERSIZE
	394957		PISTON ASSEMBLY,.020" OVERSIZE
	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
	394960		RING SET, PISTON,.010" OVERSIZE
	394961		RING SET, PISTON,.020" OVERSIZE
	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94834		SCREW, SEMS
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR
93	231209		BUSHING, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	495588		HOUSING, BLOWER
305	94786		SCREW
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER
307	93343		SCREW, SEMS
308-1	224774		COVER, AIR GUIDE
308-2	224775		COVER, AIR GUIDE
309	497287		MOTOR, STARTER






Ref #	Part Number	Qty	Description
310	497602		BOLT, THRU
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	495868		IN GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	272638		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494927		CAP AND DIPSTICK, OIL FILLER
524	280860		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
534	94823		SCREW ROUND HEAD
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262694		GEAR, TIMING
801	394860		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING

Ref #	Part Number	Qty	Description
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491262		DECAL KIT
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER



### TRACTOR - - MODEL NUMBER AYP1184A69

BRIGGS & STRATTON ENGINE - MODEL NUMBER 422707, TYPE NUMBER 1529-01




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	491756		BEARING, CYLINDER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
	271188		GASKET, CRANKCASE COVER,.005"
	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
	394956		PISTON ASSEMBLY,.010" OVERSIZE
	394957		PISTON ASSEMBLY,.020" OVERSIZE
	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
	394960		RING SET, PISTON,.010" OVERSIZE
	394961		RING SET, PISTON,.020" OVERSIZE
	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94834		SCREW, SEMS
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR
93	231209		BUSHING, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK, THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	495588		HOUSING, BLOWER
305	94786		SCREW
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER
307	93343		SCREW, SEMS
308-1	224774		COVER, AIR GUIDE
308-2	224775		COVER, AIR GUIDE
309	497287		MOTOR, STARTER




Ref #	Part Number	Qty	Description
310	497602		BOLT, THRU
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	495868		IN GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	272638		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494927		CAP AND DIPSTICK, OIL FILLER
524	280860		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
534	94823		SCREW ROUND HEAD
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262694		GEAR, TIMING
801	394860		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING

Ref #	Part Number	Qty	Description
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491262		DECAL KIT
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER




# TRACTOR -- MODEL NUMBER AYP1184A69

## LIFT




Ref #	Part Number	Qty	Description
1	136973		WIRE ASM
2	140278		HANDLE.LIFT.LH.
3	138284		PIN GROOVE
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	109413X		GRIP
8	124526X		SUB= 125925X
10	122512X		SUB= 532122512
11	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8



# TRACTOR -- MODEL NUMBER AYP1184A69

## MOWER DECK




Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	138776		SUB= 157722
31	129963		WASHER
32	129861		SUB= 153535
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	133940		SUB= 151785
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	140084		SUB= 151785
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	106933X		KNOB T (1/2-HOLE)
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND

Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	140179		LEVER ASM CLT PRM
79	127498		BUSHING
80	128759		SUB= 918128759
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	144394		SUB= 156084
85	72140618		BOLT RDHD 3/8-16
101	136420		"COVER.MULCH.42""
102	71161010		SCREW
103	19061216		WASHER #10
104	10071000		LOCKWASHER
105	130758		SUB= 160793
106	2029J		WELDNUT
111	140353		SUB= 155197
112	132262		SUB= 155198
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	4898H		BOLT M
117	105455X		WHEEL.GAGE.BLK.PL
118	73930600		LOCKNUT
119	19121414		WASHER
121	143723		BRACKET.EXTRD.GWL
	130794		MANDREL ASM
	145411		SUB= 164963

# TRACTOR - - MODEL NUMBER AYP1184A69

## SCHEMATIC






Ref #	Part Number	Qty	Description
1	146139		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	109238X		TUBE T
8	144940		SUB= 156417
9	109596X		HOSE CLAMP T
15	147688		FASTNER.SNAP-IN
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4206J		CABLE-BATTERY T
25	146147		CABLE.BTRY.6GA.RD
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
35	108236X		BRACKET LT
36	17021008		SCREW
38	140336		BRACKET SWITCH IN
39	109553X		SWITCH INTERLOCKT
40	151212		HARNES.IGNITION
471	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
48	140844		ADAPTER AMMETER
52	141940		PROTECTION LOOP
70	140712		HARNES.ENG.LT.


# TRACTOR - - MODEL NUMBER AYP1184A69

## SEAT ASSEMBLY

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.



Ref #	Part Number	Qty	Description
1	127427		SUB= 140119
2	140551		BRACKET PVT SEAT
3	74760616		BOLT
4	19131610		WASHER PM
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
8	17490616		SCREW GTV
9	19131614		WASHER
10	140552		SUB= 155925
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	139888		BOLT.SHLD.5/16-18
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER






Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	142033		AXLE ASM FRONT
3	135227		SPINDLE LH
4	135228		SPINDLE RH
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	130468		SUB= 532130468
11	10040600		LOCKWASHER
12	73610600		SUB= 7810H
13	110438X		BEARING
14	74011056		BOLT HEX 5/8-11
15	73901000		"NUT-LOC,FLANGE LT"
16	132624		AXLE PIN
17	140176		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71100410		SCREW.SCKTHD.CAP
23	127501		SUB= 918127501
24	109816X		NYLINER T
25	124036X		"BRKT,STEERING"
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	102803X		SUB= 918102803X
37	17431008		SUB= 98000165
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	104820X		ADAPTER-WHEEL LT
42	140216		BOOT SHAFT STEER
43	121749X		WASHER
44	146690		SUB= 154306
46	121232X		CAP
47	6855M		ZERK M
50	17490412		SCREW HEX CRT
51	73800500		NUT
54	74780520		BOLT
55	140285		CLIP TINNERMAN
57	140172		SUPPORT SHAFT STR
62	149686		SUB= 918149686


**TRACTOR - - MODEL NUMBER AYP1184A69**  
**DANA TRANSAXLE - MODEL NUMBER D4360-97**

**TRANSAXLE**



Ref #	Part Number	Qty	Description
1	132671		HARNESS.IGNITION
2	2274J		SUB= 74760412
3	134400		SUB= 68003
4	105904X		"SPRING, DETENT LT"
5	105905X		"SCREW, SET LT"
6	134788		SHIFTER.ASM.KIT.
7	134399		SHIFTER BOOT
8	120951X		PUCK T
9	148266		SUB= 105911X
10	2225J		RETAINING RING LT
11	134793		ASM KIT SHIM 4689
12	143679		PLUG.PLASTIC
13	120415X		WASHER T
14	142674		KEY WOODRUFF-DANA
15	106846X		SUB= 167148
16	106095X		SUB= 95-8060-6F
17	105909X		"RING,RETAINING LT"
18	105910X		"CHAIN,24 PTCH LT"
19	105911X		BEARING.FLNG.5510
20	142675		GEAR SPUR 14 TTH
21	138246		COLLAR CLUTCH
22	138238		KIT.ASM.CLTCH KEY
23	148268		BEARING.FLNG.5511
24	143673		SHAFT INTER 5404
25	2244J		WOODRUFF KEY
26	105916X		"RING,RETAINING LT"
27	120470X		SPROCKET 18T T
28	110070X		SPACER YT
29	142677		GEAR SPUR 37 TTH
30	142681		GEAR SPUR 35 TTH
31	124644X		GEAR SPUR 30T
32	108980X		GEAR 25T LT
33	120406X		GEAR SPUR 22 TT
34	134796		SPUR GEAR 19T
35	105925X		"WASHER, PLAIN LT"
36	2232J		WASHER 025
37	108978X		SPACER
38	110079X		ASSM GEAR COMB
39	124639X		SHAFT IDLER
40	120472X		SPACER T
41	105928X		SPROCKET 9T LT
42	106605X		SUB= 167148
43	134394		ASM KIT SHIM
44	120473X		SHAFT T
45	106596X		"SCREW, TAPPING LT"
46	142678		GEAR SPUR 12 TTH
47	120407X		SUB= 124641X
48	106589X		"GEAR, SPUR 25T LT"
49	120408X		GEAR 28T T
50	105937X		"GEAR, SPUR 31T LT"
51	2226J		WASHER 060
52	134401		NEOPRENE WASHER
53	2264J		WASHER 031
54	120474X		SUB= 154658
55	110081X		GEAR 15T T
56	105941X		"RING,RETAINING LT"
57	110071X		SUB= 120478X
58	120952X		SHAFT T


Ref #	Part Number	Qty	Description
59	106592X		"GEAR,MITER 15T YT"
60	120475X		SUB= 154659
61	142680		HOUSING LOWER TNS
62	120961X		PUCK T
63	7294J		BRAKE DISC. T
64	108989X		SPACER LT
65	120953X		SUB= 918120953X
66	120954X		PIN T
67	134799		TAP SCREW
68	138244		SUB= 108992X
69	108996X		WASHER LT
70	120956X		NLA
71	73810500		NUT.LOCK.5/16-24
72	148269		SEAL.OIL.DAN.5508
73	120416X		SUB= 126976X





# TRACTOR - - MODEL NUMBER AYP1184A69 DANA TRANSAXLE - MODEL NUMBER D4360-97

## TRANSAXLE




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	491756		BEARING, CYLINDER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
	271188		GASKET, CRANKCASE COVER,.005"
	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
	394956		PISTON ASSEMBLY,.010" OVERSIZE
	394957		PISTON ASSEMBLY,.020" OVERSIZE
	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
	394960		RING SET, PISTON,.010" OVERSIZE
	394961		RING SET, PISTON,.020" OVERSIZE
	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94834		SCREW, SEMS
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR
93	231209		BUSHING, THROTTLE SHAFT

Ref #	Part Number	Qty	Description
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	495588		HOUSING, BLOWER
305	94786		SCREW
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER
307	93343		SCREW, SEMS
308-1	224774		COVER, AIR GUIDE
308-2	224775		COVER, AIR GUIDE
309	497287		MOTOR, STARTER


Ref #	Part Number	Qty	Description
310	497602		BOLT, THRU
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	495868		IN GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	272638		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494927		CAP AND DIPSTICK, OIL FILLER
524	280860		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
534	94823		SCREW ROUND HEAD
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262694		GEAR, TIMING
801	394860		CAP, DRIVE
802	497605		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING

Ref #	Part Number	Qty	Description
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491262		DECAL KIT
1090	497607		P/N CONFLICT - CHECK WITH SUPPLIER



# TRACTOR - - MODEL NUMBER AYP1184A69

## WHEELS & TIRES



**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.

Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	138468		TIRE.20X8-8
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP

