


# TRACTOR - - MODEL NUMBER AYP7167A69


## CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
1	145501		CHASSIS.WLD.11GA
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
6	145206		SUB= 145206X431
8	126471X		"CLIP,INSULATOR"
9	140622		SUB= 532142467
10	72140608		SUB= 72110608
11	140311		PANEL ASM DASH
12	145660		CLIP.TINNERMAN
13	140178		SUB= 146959
14	17490608		SCREW LT
17	139394X418		HOOD.STL.PRV.LB
20	145210		PLATE.MTG.BTRY.TK
23	124028X		SUB= 532124028
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
28	140141		SUB= 157373
29	140273		LENS GRILLE
30	140002X418		FENDER.YT/GT
31	137113		BRKT.ASM.FENDER
33	145244X418		FOOTREST.LT.LT/GT
34	145243X418		FOOTREST.RH.LT/GT
35	72110606		BOLT
37	17490516		SCREW TI
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
44	140675		STRAP ASM FENDER
47	105531X		NUT-PUSH YT
48	138096		RIVET.PUSH.PLATE
49	17490412		SCREW HEX CRT
50	142779		BRACE SUPT DASH
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	17030814		SUB= 91817030814
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	140806		DUCT AIR 12-15H
68	73510400		NUT

## TRACTOR - - MODEL NUMBER AYP7167A69

### DECALS




Ref #	Part Number	Qty	Description
1	140819		SUB= 156867
2	143470		DECAL STEER WHL
3	141579		DECAL HOOD RH
4	141580		DECAL HOOD LH
5	141517		DECAL DECK WIZ +
6	143388		NAMEPLATE.HD.WIZA
7	127520		NLA
8	133796		DECAL
9	4900J		DECAL T
10	141502		DECAL CHASSIS WIZ
11	136832		DECAL
12	146698		DECAL.PNL.SIDE.VG
13	141583		DECAL DECK MULCH
14	145005		DECAL.BATRY.3-3908
15	131973		DECAL.ENG.805720
16	150218		DECAL.LENS.WIZARD
	138311		DECAL HANDLE LIFT
	133671		FOOTREST PAD
	150210		MANUAL.O.7167A69




# TRACTOR -- MODEL NUMBER AYP7167A69

## DRIVE




Ref #	Part Number	Qty	Description
1	145607		SUB= 161451
2	146682		SPRING.BRAKE.RETU
3	123666X		PULLEY TRANS
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
8	141002		ROD SHIFT FEND YT
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
12	19151216		WASHER
13	74550412		BOLT.1/4-28.W/PAT
14	10040400		LOCKWASHER
15	74780544		BOLT HEX
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	124236X		CAP
30	130807		TRANSAXLE MTG BKT
31	127275X		"KEEPER,BELT LH T"
32	74760512		BOLT
34	122424X		SUB= 149001
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	130801		SUB= 138255
58	127274X		"KEEPER,BELT RH T"
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	129921		KEEPER.BELT.ENG.L
70	134683		KEEPER BELT ENG
72	19132012		WASHER
74	109502X		SPACER LT
75	121749X		WASHER

Ref #	Part Number	Qty	Description
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER
79	2228M		SUB= 2228M1
80	131487		ARM SHIFT TRANS
81	136933		SHAFT ASM.SHIFT
82	123782X		"SPRING,TORSION"
83	19171216		WASHER
84	132183		TIE ROD
85	73530400		NUT 1/4-28
86	71208		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	139991		CONSOLE SHIFT
90	124346X		NUT
100	19111216		WASHER M
110	74760616		BOLT
112	19091210		WASHER LT



# TRACTOR - - MODEL NUMBER AYP7167A69

## ELECTRICAL






Ref #	Part Number	Qty	Description
1	144925		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	7697J		"DRAIN TU T, BATT"
8	7603J		"TRAY T, BATTERY"
9	109596X		HOSE CLAMP T
10	145211		SUB= 150177
11	145209		SUB= 150109
12	145769		SUB= 150177
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES, LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146148		CABLE.6GA.22W/16W
26	108824X		FUSE HYT
28	145491		CABLE.GRND.6GA.21
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
35	108236X		BRACKET LT
36	17021008		SCREW
38	140336		BRACKET SWITCH IN
39	109553X		SWITCH INTERLOCKT
40	151212		HARNES.IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
45	122822X		AMMETER
52	141940		PROTECTION LOOP
55	17490508		SCREW LT
70	141861		HARNES.ENG.LT.

# TRACTOR - - MODEL NUMBER AYP7167A69

## ENGINE



Ref #	Part Number	Qty	Description
1	148875		CONTROL THROT. LH
2	17720410		SCREW LT
3			REFER TO IMAGE
4	149723		MUFFLER.TW.LOTONE
5	122434X		TUBE ASSY EXH LH
6	122435X		TUBE ASSY EXH RH
7	138129		CLAMP.TUBE.DBL.EN
10	145552		SHIELD.HEAT.
11			REFER TO IMAGE
12			REFER TO IMAGE
13			REFER TO IMAGE
14	13280336		PIPE NIPPLE LT
15	13200300		ELBOW
16	11050600		LOCKWASHER
23	128953		HEAT SHIELD
24	17021008		SCREW
25	145996		CONTROL.CHOKE.37
26	73610600		SUB= 7810H
29	137180		SUB= 532137180
31	141069		SUB= 151346
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
34	106082X		PAD-SPACER LT
35	17490512		SCREW
36	19132012		WASHER
37	8543R		FUEL LINE T
38			REFER TO IMAGE
39	109227X		PAD IDLER TI
40	3645J		BUSHING OUTLET T
41	139277		STEM.TANK.FUEL
78	17490620		SCREW
81	128861		NUT



Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805107		BEARING, CYLINDER
5	807987		HEAD, CYLINDER #1
5A	807988		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	262679		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	91488		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
116A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER





Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805107		BEARING, CYLINDER
5	807987		HEAD, CYLINDER #1
5A	807988		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	262679		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	91488		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
116A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
827	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

# TRACTOR - - MODEL NUMBER AYP7167A69

BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 1032-A1



Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805107		BEARING, CYLINDER
5	807987		HEAD, CYLINDER #1
5A	807988		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	262679		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	91488		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
116A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD







Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
827	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

# TRACTOR - - MODEL NUMBER AYP7167A69

## BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 1032-A1



Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805107		BEARING, CYLINDER
5	807987		HEAD, CYLINDER #1
5A	807988		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	262679		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	91488		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
116A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
827	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

# TRACTOR - - MODEL NUMBER AYP7167A69

## LIFT






Ref #	Part Number	Qty	Description
1	136973		WIRE ASM
2	140278		HANDLE.LIFT.LH.
3	138284		PIN GROOVE
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
10	122512X		SUB= 532122512
11	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
21	19151216		WASHER
22	12000037		KLIP RING
23	110807X		NUT T
24	19131016		WASHER
25	2876H		SPRING T
26	76020308		SUB= 3145
27	126971X		SUB= 532126971
28	73350600		NUT
29	138057		KNOB INF 3/8-16
30	110810X		TRUNION LT
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8
33	140168		BRACKET STOP INF
34	17490608		SCREW LT
35	120529X		WASHER T
36	123933X505		POINTER HGT IND
37	123935X		"PLUG,HOLE"
38	17490512		SCREW
40	19112410		WASHER
41	123934X		HEIGHT INDICATOR

# TRACTOR -- MODEL NUMBER AYP7167A69

## MOWER DECK





Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	138776		SUB= 157722
31	129963		WASHER
32	129861		SUB= 153535
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	133940		SUB= 151785
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	140084		SUB= 151785
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	106933X		KNOB T (1/2-HOLE)
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND

Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	140179		LEVER ASM CLT PRM
79	127498		BUSHING
80	128759		SUB= 918128759
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	144394		SUB= 156084
85	72140620		BOLT
101	136420		"COVER.MULCH.42""
102	71161010		SCREW
103	19061216		WASHER #10
104	10071000		LOCKWASHER
105	130758		SUB= 160793
106	2029J		WELDNUT
111	140353		SUB= 155197
112	132262		SUB= 155198
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	137644		BOLT.SHOULDER
117	133957		WHEEL GAGE DONUT
118	73930600		LOCKNUT
119	19121414		WASHER
121	143723		BRACKET.EXTRD.GWL
	130794		MANDREL ASM
	145411		SUB= 164963

# TRACTOR - - MODEL NUMBER AYP7167A69

## SCHEMATIC



**IGNITION SWITCH**

POSITION	CIRCUIT	"MAKE"
OFF	G + M + L	NONE
RUN/LIGHT	B + L	A + Y
RUN	B + L	NONE
START	B + L + S	NONE

- NON-REMOVABLE CONNECTIONS
- REMOVABLE CONNECTIONS

**WIRING INSULATED CLIPS**

**NOTE:** IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING

**NOTE**


YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.

Ref #	Part Number	Qty	Description
1	144925		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	7697J		"DRAIN TU T, BATT"
8	7603J		"TRAY T, BATTERY"
9	109596X		HOSE CLAMP T
10	145211		SUB= 150177
11	145209		SUB= 150109
12	145769		SUB= 150177
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES, LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146148		CABLE.6GA.22W/16W
26	108824X		FUSE HYT
28	145491		CABLE.GRND.6GA.21
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
35	108236X		BRACKET LT
36	17021008		SCREW
38	140336		BRACKET SWITCH IN
39	109553X		SWITCH INTERLOCKT
40	151212		HARNES.IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
45	122822X		AMMETER
52	141940		PROTECTION LOOP
55	17490508		SCREW LT
70	141861		HARNES.ENG.LT.


# TRACTOR - - MODEL NUMBER AYP7167A69

## SEAT ASSEMBLY

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm




Ref #	Part Number	Qty	Description
1	140116		SEAT
2	140551		BRACKET PVT SEAT
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
8	17490508		SCREW LT
9	19131614		WASHER
10	140552		SUB= 155925
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	139888		BOLT.SHLD.5/16-18
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER
27	17490608		SCREW LT





# TRACTOR - - MODEL NUMBER AYP7167A69


## STEERING ASSEMBLY



Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	142033		AXLE ASM FRONT
3	135227		SPINDLE LH
4	135228		SPINDLE RH
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	130468		SUB= 532130468
11	10040600		LOCKWASHER
12	73610600		SUB= 7810H
13	110438X		BEARING
14	74011056		BOLT HEX 5/8-11
15	73901000		"NUT-LOC,FLANGE LT"
16	132624		AXLE PIN
17	140176		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71070410		"SCREW,SPECIAL"
23	127501		SUB= 918127501
24	109816X		NYLINER T
25	124036X		"BRKT,STEERING"
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	102803X		SUB= 918102803X
37	17431008		SUB= 98000165
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	104820X		ADAPTER-WHEEL LT
42	140216		BOOT SHAFT STEER
43	121749X		WASHER
44	146690		SUB= 154306
46	121232X		CAP
47	6855M		ZERK M
50	17490412		SCREW HEX CRT
51	73800500		NUT
54	74780520		BOLT
55	140285		CLIP TINNEMAN
57	140172		SUPPORT SHAFT STR
62	149686		SUB= 918149686


# TRACTOR - - MODEL NUMBER AYP7167A69

## DANA TRANSAXLE - MODEL NUMBER 4360-97




Ref #	Part Number	Qty	Description
1	132671		HARNES.SIGNITION
2	2274J		SUB= 74760412
3	134400		SUB= 68003
4	105904X		"SPRING, DETENT LT"
5	105905X		"SCREW, SET LT"
6	134788		SHIFTER.ASM.KIT.
7	134399		SHIFTER BOOT
8	120951X		PUCK T
9	148266		SUB= 105911X
10	2225J		RETAINING RING LT
11	134793		ASM KIT SHIM 4689
12	143679		PLUG.PLASTIC
13	120415X		WASHER T
14	142674		KEY WOODRUFF-DANA
15	106846X		SUB= 167148
16	106095X		SUB= 95-8060-6F
17	105909X		"RING,RETAINING LT"
18	105910X		"CHAIN,24 PTCH LT"
19	105911X		BEARING.FLNG.5510
20	142675		GEAR SPUR 14 TTH
21	138246		COLLAR CLUTCH
22	138238		KIT.ASM.CLTCH KEY
23	148268		BEARING.FLNG.5511
24	143673		SHAFT INTER 5404
25	2244J		WOODRUFF KEY
26	105916X		"RING,RETAINING LT"
27	120470X		SPROCKET 18T T
28	110070X		SPACER YT
29	142677		GEAR SPUR 37 TTH
30	142681		GEAR SPUR 35 TTH
31	124644X		GEAR SPUR 30T
32	108980X		GEAR 25T LT
33	120406X		GEAR SPUR 22 TT
34	134796		SPUR GEAR 19T
35	105925X		"WASHER, PLAIN LT"
36	2232J		WASHER 025
37	108978X		SPACER
38	110079X		ASSM GEAR COMB
39	124639X		SHAFT IDLER
40	120472X		SPACER T
41	105928X		SPROCKET 9T LT
42	106605X		SUB= 167148
43	134394		ASM KIT SHIM
44	120473X		SHAFT T
45	106596X		"SCREW, TAPPING LT"
46	142678		GEAR SPUR 12 TTH
47	120407X		SUB= 124641X
48	106589X		"GEAR, SPUR 25T LT"
49	120408X		GEAR 28T T
50	105937X		"GEAR, SPUR 31T LT"
51	2226J		WASHER 060
52	134401		NEOPRENE WASHER
53	2264J		WASHER 031
54	120474X		SUB= 154658
55	110081X		GEAR 15T T
56	105941X		"RING,RETAINING LT"
57	110071X		SUB= 120478X
58	120952X		SHAFT T

Ref #	Part Number	Qty	Description
59	106592X		"GEAR,MITER 15T YT"
60	120475X		SUB= 154659
61	142680		HOUSING LOWER TNS
62	120961X		PUCK T
63	7294J		BRAKE DISC. T
64	108989X		SPACER LT
65	120953X		SUB= 918120953X
66	120954X		PIN T
67	134799		TAP SCREW
68	138244		SUB= 108992X
69	108996X		WASHER LT
70	120956X		NLA
71	73810500		NUT.LOCK.5/16-24
72	148269		SEAL.OIL.DAN.5508
73	120416X		SUB= 126976X



# TRACTOR - - MODEL NUMBER AYP7167A69

## WHEELS AND TIRES



**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	122082X		SUB= 918122082X
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP
	144334		SEALANT.TIRE 10 OZ. TUBE

