


TRACTOR -- MODEL NUMBER AYP7167B79


CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
1	159530		CHASSIS ASM
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
5	155272		BUMPER-HOOD/DASH
6	155923		SADDLE
8	126741X		SUB= 142034
9	147633X011		DASH SILKSCREEN
10	72140608		SUB= 72110608
11	155927		"PANEL-DASH,LH"
12	145660		CLIP.TINNERMAN
13	155936		"PANEL-DASH,RH"
14	17490608		SCREW LT
15	74180512		SCREW
16	73510500		NUT
17	139394X418		HOOD.STL.PRIV.LB
20	156437		"PLATE-MTG,BATT/FU"
23	124028X		SUB= 532124028
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
28	157428		GRILL
29	146654		LENS.EURO.W/DECAL
30	140002X418		FENDER.YT/GT
31	137113		BRKT.ASM.FENDER
33	145244X418		FOOTREST.LT.LT/GT
34	145243X418		FOOTREST.RH.LT/GT
35	72110606		BOLT
37	17490508		SCREW LT
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
44	140675		STRAP ASM FENDER
47	105531X		NUT-PUSH YT
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	17030814		SUB= 91817030814
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	150127		AIR DUCT
71	73680400		SUB= 73690400
140	158418		BRKT SUSPENSION
145	156524		"ROD POVOT,CHASSIS"
147	74760412		BOLT LT

TRACTOR - - MODEL NUMBER AYP7167B79

DECALS




Ref #	Part Number	Qty	Description
1	156867		"DECAL DASH,OPER."
2	143470		DECAL STEER WHL
3	141579		DECAL HOOD RH
4	141580		DECAL HOOD LH
5	141517		DECAL DECK WIZ +
6	143388		NAMEPLATE.HD.WIZA
7	127520		NLA
8	157002		"DECAL DANGER,FEND"
9	4900J		DECAL T
10	141502		DECAL CHASSIS WIZ
11	136832		DECAL
12	158506		"DECAL PANEL,SIDE"
13	141583		DECAL DECK MULCH
14	145005		DECAL.BATRY.3-3908
15	273210		DECAL, ENGINE B&S
16	150218		DECAL.LENS.WIZARD
	138311		DECAL HANDLE LIFT
	133671		FOOTREST PAD
	159741		MANL.O.7167B79.E




TRACTOR - - MODEL NUMBER AYP7167B79

DRIVE




Ref #	Part Number	Qty	Description
1			REFER TO IMAGE
2	146682		SPRING.BRAKE.RETU
3	123666X		PULLEY TRANS
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
6	17490512		SCREW
8	141002		ROD SHIFT FEND YT
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
13	74550412		BOLT.1/4-28.W/PAT
14	10040400		LOCKWASHER
15	74490544		BOLT.HX.FLG.5/16
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	124236X		CAP
30	130807		TRANSAXLE MTG BKT
31	127275X		"KEEPER,BELT LH T"
32	74760512		BOLT
34	155071		SHAFT ASM-PEDAL F
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	154777		SUB= 165692
42	19131312		WASHER
47	127783		SUB= 139245
48	154604		BELLCRANK ASM
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	130801		SUB= 138255
58	127274X		"KEEPER,BELT RH T"
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	154778		KEEPER-BELT
70	134683		KEEPER BELT ENG
72	19132012		WASHER
74	137057		SPACER AXLE
75	121749X		WASHER
76	12000001		E-RING LT
77	123583X		SQUARE KEY

Ref #	Part Number	Qty	Description
78	121748X		WASHER
79	2228M		SUB= 2228M1
80	145090		"ARM.SHIFT.20""TIRE"
81	145092		SUB= 156049
82	123782X		"SPRING,TORSION"
83	19171216		WASHER
84	145643		"ROD.TIE.20""P930LT"
85	150360		NUT.CNT.LOCK.1/4
86	71208		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	139991		CONSOLE SHIFT
90	124346X		NUT
96	4497H		RETAINER M
112	19091210		WASHER LT
113	127285X		"STRAP,TORQUE"
116	72110610		BOLT RDHD 3/8-16
118	154474		SPACER BELLCRANK
121	154419		NYLINER-CLUTCHING



TRACTOR - - MODEL NUMBER AYP7167B79


ELECTRICAL



Ref #	Part Number	Qty	Description
1	144926		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	7697J		"DRAIN TU T, BATT"
8	7603J		"TRAY T, BATTERY"
9	109596X		HOSE CLAMP T
10	145211		SUB= 150177
11	150109		HOLDDOWN BATTERY
12	145769		SUB= 150177
16	153664		SWITCH INTERLOCK
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES, LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146148		CABLE.6GA.22W/16W
26	108824X		FUSE HYT
28	145491		CABLE.GRND.6GA.21
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
40	156442		HARNES-IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
45	122822X		AMMETER
52	141940		PROTECTION LOOP
55	17490508		SCREW LT
70	140422		HARNES.ENG.DUAL

TRACTOR - - MODEL NUMBER AYP7167B79


ENGINE



Ref #	Part Number	Qty	Description
1	148875		CONTROL THROT. LH
2	17720410		SCREW LT
3			REFER TO IMAGE
4	149723		MUFFLER.TW.LOTONE
5	122434X		TUBE ASSY EXH LH
6	122435X		TUBE ASSY EXH RH
7	138129		CLAMP.TUBE.DBL.EN
8	150176		BOLT.5/16-18.UNC
10	145552		SHIELD.HEAT.
11			REFER TO IMAGE
12			REFER TO IMAGE
13			REFER TO IMAGE
14	13280336		PIPE NIPPLE LT
15	13200300		ELBOW
16	11050600		LOCKWASHER
23	156123		SHIELD-HEAT
25	145996		CONTROL.CHOKE.37
26	73920600		"NUT,KEPS 3/8-24IM"
29	137180		SUB= 532137180
31	151346		TANK FUEL REAR
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
34	106082X		PAD-SPACER LT
34	17490512		SCREW
37	8543R		FUEL LINE T
38			REFER TO IMAGE
39	109227X		PAD IDLER TI
40	3645J		BUSHING OUTLET T
41	139277		STEM.TANK.FUEL
78	17490620		SCREW
81	128861		NUT

TRACTOR - - MODEL NUMBER AYP7167B79

BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 1032-A1



★REQUIRES SPECIAL TOOLS TO INSTALL.
SEE REPAIR INSTRUCTION MANUAL.

[Der Ersatzteilspezialist im Internet.](http://www.ersatzteil-service.de)


Ref #	Part Number	Qty	Description
	1		CYLINDER ASSEMBLY
	2		BEARING, CYLINDER
	3		SEAL, OIL
	5		HEAD, CYLINDER #1
	5A		HEAD, CYLINDER #2
	6		WASHER, CYLINDER HEAD
	7		GASKET, CYLINDER HEAD
	8		BREATHER ASSEMBLY
	9		GASKET, BREATHER
	10		SCREW
	11		TUBE, BREATHER
	12		GASKET, CRANKCASE COVER
	13		SCREW, CYLINDER HEAD
	15		PLUG, OIL DRAIN
	16		CRANKSHAFT
	16A		KEY, TIMING GEAR
	16B		WASHERS, THRUST
	18		COVER ASSEMBLY, CRANKCASE
	20		SEAL, OIL
	22		SCREW, CRANKCASE COVER
	23		FLYWHEEL MAGNETO
	24		KEY, FLYWHEEL
	25		PISTON ASSEMBLY, STANDARD
	25A		PISTON ASSEMBLY .010" OVERSIZE
	25B		PISTON ASSEMBLY .020" OVERSIZE
	25C		PISTON ASSEMBLY .030" OVERSIZE
	26		RING SET, PISTON, STANDARD
	26A		RING SET, PISTON .010" OVERSIZE
	26B		RING SET, PISTON .020" OVERSIZE
	26C		RING SET, PISTON .030" OVERSIZE
	27		LOCK, PISTON PIN
	28		PIN ASSEMBLY, PISTON, STANDARD
	29		ROD ASSEMBLY, CONNECTING
	32		SCREW, CONNECTING ROD
	33		VALVE, EXHAUST
	34		VALVE, INTAKE
	35		SPRING, VALVE
	40		RETAINER, VALVE SPRING
	42		RETAINER, VALVE
	45		TAPPET, VALVE
	46		GEAR, CAM
	50		MANIFOLD, INTAKE
	51		GASKET, CARBURETOR MOUNTING
	52		GASKET, INTAKE MANIFOLD
	53		SCREW, SEMS
	54		SCREW, SEMS
	75		WASHER, SPRING
	78		SCREW, SEMS
	84		PLUG, PIPE
	87		SEAL, GOVERNOR SHAFT
	94		NOZZLE, CARBURETOR
	95		SCREW, VALVE MOUNTING
	98		SCREW, THROTTLE ADJUSTING
	104		PIN, FLOAT HINGE
	105		VALVE, FUEL INLET
	108		VALVE, CHOKE
	116		O-RING, OIL PUMP
	116A		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	NOZZLE		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
187A	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
1023A	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
1026A	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

TRACTOR - - MODEL NUMBER AYP7167B79
BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 1032-A1



Ref #	Part Number	Qty	Description
	1		CYLINDER ASSEMBLY
	2		BEARING, CYLINDER
	3		SEAL, OIL
	5		HEAD, CYLINDER #1
	5A		HEAD, CYLINDER #2
	6		WASHER, CYLINDER HEAD
	7		GASKET, CYLINDER HEAD
	8		BREATHER ASSEMBLY
	9		GASKET, BREATHER
	10		SCREW
	11		TUBE, BREATHER
	12		GASKET, CRANKCASE COVER
	13		SCREW, CYLINDER HEAD
	15		PLUG, OIL DRAIN
	16		CRANKSHAFT
	16A		KEY, TIMING GEAR
	16B		WASHERS, THRUST
	18		COVER ASSEMBLY, CRANKCASE
	20		SEAL, OIL
	22		SCREW, CRANKCASE COVER
	23		FLYWHEEL MAGNETO
	24		KEY, FLYWHEEL
	25		PISTON ASSEMBLY, STANDARD
	25A		PISTON ASSEMBLY .010" OVERSIZE
	25B		PISTON ASSEMBLY .020" OVERSIZE
	25C		PISTON ASSEMBLY .030" OVERSIZE
	26		RING SET, PISTON, STANDARD
	26A		RING SET, PISTON .010" OVERSIZE
	26B		RING SET, PISTON .020" OVERSIZE
	26C		RING SET, PISTON .030" OVERSIZE
	27		LOCK, PISTON PIN
	28		PIN ASSEMBLY, PISTON, STANDARD
	29		ROD ASSEMBLY, CONNECTING
	32		SCREW, CONNECTING ROD
	33		VALVE, EXHAUST
	34		VALVE, INTAKE
	35		SPRING, VALVE
	40		RETAINER, VALVE SPRING
	42		RETAINER, VALVE
	45		TAPPET, VALVE
	46		GEAR, CAM
	50		MANIFOLD, INTAKE
	51		GASKET, CARBURETOR MOUNTING
	52		GASKET, INTAKE MANIFOLD
	53		SCREW, SEMS
	54		SCREW, SEMS
	75		WASHER, SPRING
	78		SCREW, SEMS
	84		PLUG, PIPE
	87		SEAL, GOVERNOR SHAFT
	94		NOZZLE, CARBURETOR
	95		SCREW, VALVE MOUNTING
	98		SCREW, THROTTLE ADJUSTING
	104		PIN, FLOAT HINGE
	105		VALVE, FUEL INLET
	108		VALVE, CHOKE
	116		O-RING, OIL PUMP
	116A		O-RING, CRANKCASE COVER





Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	NOZZLE		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
187A	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
1023A	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
1026A	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

TRACTOR - - MODEL NUMBER AYP7167B79

BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 1032-A1



Ref #	Part Number	Qty	Description
	1 807511		CYLINDER ASSEMBLY
	2 805107		BEARING, CYLINDER
	3 805101		SEAL, OIL
	5 807987		HEAD, CYLINDER #1
	5A 807988		HEAD, CYLINDER #2
	6 805193		WASHER, CYLINDER HEAD
	7 805111		GASKET, CYLINDER HEAD
	8 807795		BREATHER ASSEMBLY
	9 805379		GASKET, BREATHER
	10 805751		SCREW
	11 805362		TUBE, BREATHER
	12 805112		GASKET, CRANKCASE COVER
	13 805097		SCREW, CYLINDER HEAD
	15 805048		PLUG, OIL DRAIN
	16 807586		CRANKSHAFT
	16A 94196		KEY, TIMING GEAR
	16B 807625		WASHERS, THRUST
	18 807638		COVER ASSEMBLY, CRANKCASE
	20 805049		SEAL, OIL
	22 805696		SCREW, CRANKCASE COVER
	23 807531		FLYWHEEL MAGNETO
	24 805016		KEY, FLYWHEEL
	25 807619		PISTON ASSEMBLY, STANDARD
	25A 807807		PISTON ASSEMBLY .010" OVERSIZE
	25B 807809		PISTON ASSEMBLY .020" OVERSIZE
	25C 807811		PISTON ASSEMBLY .030" OVERSIZE
	26 807620		RING SET, PISTON, STANDARD
	26A 807808		RING SET, PISTON .010" OVERSIZE
	26B 807810		RING SET, PISTON .020" OVERSIZE
	26C 807812		RING SET, PISTON .030" OVERSIZE
	27 805099		LOCK, PISTON PIN
	28 807621		PIN ASSEMBLY, PISTON, STANDARD
	29 807900		ROD ASSEMBLY, CONNECTING
	32 805395		SCREW, CONNECTING ROD
	33 805089		VALVE, EXHAUST
	34 805090		VALVE, INTAKE
	35 805078		SPRING, VALVE
	40 805092		RETAINER, VALVE SPRING
	42 805161		RETAINER, VALVE
	45 262679		TAPPET, VALVE
	46 807542		GEAR, CAM
	50 805409		MANIFOLD, INTAKE
	51 805149		GASKET, CARBURETOR MOUNTING
	52 805023		GASKET, INTAKE MANIFOLD
	53 805669		SCREW, SEMS
	54 805006		SCREW, SEMS
	75 805007		WASHER, SPRING
	78 805447		SCREW, SEMS
	84 91488		PLUG, PIPE
	87 805054		SEAL, GOVERNOR SHAFT
	94 805777		NOZZLE, CARBURETOR
	95 805561		SCREW, VALVE MOUNTING
	98 807705		SCREW, THROTTLE ADJUSTING
	104 805586		PIN, FLOAT HINGE
	105 807706		VALVE, FUEL INLET
	108 805562		VALVE, CHOKE
	116 805058		O-RING, OIL PUMP
	116A 805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	NOZZLE		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
187A	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
1023A	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
1026A	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

TRACTOR - - MODEL NUMBER AYP7167B79

BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 1032-A1



Ref #	Part Number	Qty	Description
	1 807511		CYLINDER ASSEMBLY
	2 805107		BEARING, CYLINDER
	3 805101		SEAL, OIL
	5 807987		HEAD, CYLINDER #1
	5A 807988		HEAD, CYLINDER #2
	6 805193		WASHER, CYLINDER HEAD
	7 805111		GASKET, CYLINDER HEAD
	8 807795		BREATHER ASSEMBLY
	9 805379		GASKET, BREATHER
	10 805751		SCREW
	11 805362		TUBE, BREATHER
	12 805112		GASKET, CRANKCASE COVER
	13 805097		SCREW, CYLINDER HEAD
	15 805048		PLUG, OIL DRAIN
	16 807586		CRANKSHAFT
	16A 94196		KEY, TIMING GEAR
	16B 807625		WASHERS, THRUST
	18 807638		COVER ASSEMBLY, CRANKCASE
	20 805049		SEAL, OIL
	22 805696		SCREW, CRANKCASE COVER
	23 807531		FLYWHEEL MAGNETO
	24 805016		KEY, FLYWHEEL
	25 807619		PISTON ASSEMBLY, STANDARD
	25A 807807		PISTON ASSEMBLY .010" OVERSIZE
	25B 807809		PISTON ASSEMBLY .020" OVERSIZE
	25C 807811		PISTON ASSEMBLY .030" OVERSIZE
	26 807620		RING SET, PISTON, STANDARD
	26A 807808		RING SET, PISTON .010" OVERSIZE
	26B 807810		RING SET, PISTON .020" OVERSIZE
	26C 807812		RING SET, PISTON .030" OVERSIZE
	27 805099		LOCK, PISTON PIN
	28 807621		PIN ASSEMBLY, PISTON, STANDARD
	29 807900		ROD ASSEMBLY, CONNECTING
	32 805395		SCREW, CONNECTING ROD
	33 805089		VALVE, EXHAUST
	34 805090		VALVE, INTAKE
	35 805078		SPRING, VALVE
	40 805092		RETAINER, VALVE SPRING
	42 805161		RETAINER, VALVE
	45 262679		TAPPET, VALVE
	46 807542		GEAR, CAM
	50 805409		MANIFOLD, INTAKE
	51 805149		GASKET, CARBURETOR MOUNTING
	52 805023		GASKET, INTAKE MANIFOLD
	53 805669		SCREW, SEMS
	54 805006		SCREW, SEMS
	75 805007		WASHER, SPRING
	78 805447		SCREW, SEMS
	84 91488		PLUG, PIPE
	87 805054		SEAL, GOVERNOR SHAFT
	94 805777		NOZZLE, CARBURETOR
	95 805561		SCREW, VALVE MOUNTING
	98 807705		SCREW, THROTTLE ADJUSTING
	104 805586		PIN, FLOAT HINGE
	105 807706		VALVE, FUEL INLET
	108 805562		VALVE, CHOKE
	116 805058		O-RING, OIL PUMP
	116A 805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B			REFER TO IMAGE
116C			REFER TO IMAGE
117A			REFER TO IMAGE
117B	805755		JET, MAIN
118	808258		VALVE ASSY, CARBURETOR IDLE
121	808324		CARBURETOR OVERHAUL KIT
122	805770		SPACER, CARBURETOR
125	808255		CARBURETOR ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	808323		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			REFER TO IMAGE
141	807711		SHAFT, CHOKE
142	NOZZLE		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
187A	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	808195		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805964		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	808145		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308	808309		COVER, AIR GUIDE, CYLINDER #1
308A	808098		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	494439		SCREEN, ROTATING
332	805028		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	92791		WASHERLOCK
353A	806101		WASHER, LOCK, INTERNAL TOOTH
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD

Ref #	Part Number	Qty	Description
356	493792		WIRE ASSEMBLY, GROUND
358	807989		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	495878		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807989		GASKET SET
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	272490		ELEMENT, FILTER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	280470		CLIP, WIRE
741	805984		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE

Ref #	Part Number	Qty	Description
862	807859		BRACKET, AIR CLEANER
864	493880		TERMINAL, IGNITION CABLE
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495871		RETAINER KIT
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
918	393815		HOSE (CUT TO SUIT)
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	808325		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	806039		GASKET, VALVE COVER
1023	805100		COVER, VALVE
1023A	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
1026A	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	808096		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR
1054	280275		TIE, CABLE
1091	805858		CAP, LIMITER

TRACTOR -- MODEL NUMBER AYP7167B79


LIFT



Ref #	Part Number	Qty	Description
1	159460		WIRE ASM W.SPRING
2	159471		"SHAFT ASM LIFT,RH"
3	105767X		PIN-GROOVE LT
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
10	122512X		SUB= 532122512
11	139865		SUB= 918139865
12	139866		SUB= 151140
1.	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
23	110807X		NUT T
24	19131016		WASHER
25	2876H		SPRING T
26	76020308		SUB= 3145
27	126971X		SUB= 532126971
28	73350600		NUT
29	138057		KNOB INF 3/8-16
30	150233		TRUNNION
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8
36	155097		POINTER-INDICAT
37	123935X		"PLUG,HOLE"
38	17490512		SCREW
40	19112410		WASHER
41	123934X		HEIGHT INDICATOR
49	145212		NUT.HXFLG.LOCK.
50	110452X		NUT PUSH M

TRACTOR - - MODEL NUMBER AYP7167B79

MOWER DECK




Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	138776		SUB= 157722
31	129963		WASHER
32	153535		PULLEY.MANDREL.42
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
71	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	155066		ROLLER ASM-CAM
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845X900		SUB= 131845
54	133943		HARDENED WASHER
55	155046		ARM-IDLER
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	106932X		KNOB T(3/8 HOLE)
68	144959		BELT-V.SEC.46.KEL
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND

Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	154809		LEVER ASM-CLUTCH
79	127498		BUSHING
80	153701		SPRING.CLUTCH.MWR
81	7350600		NUT
82	142028		TRUNION ADJ
84	158824		BRACKET ASM IDLER
85	72140618		BOLT RDHD 3/8-16
92	73800600		NUT
101	136420		"COVER.MULCH.42""
102	71161010		SCREW
103	19061216		WASHER #10
104	10071000		LOCKWASHER
105	130758		SUB= 160793
106	2029J		WELDNUT
111	155197		BRACKET.GWHL.LH.
112	155198		BRACKET.GWHL.RH.
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	137644		BOLT.SHOULDER
117	133957		WHEEL GAGE DONUT
118	73930600		LOCKNUT
119	19121414		WASHER
121	143723		BRACKET.EXTRD.GWL
128	153390		WASHER.FELT.
132	19132203		WASHER GT
	130794		MANDREL ASM
	159481		SUB= 145411


TRACTOR - - MODEL NUMBER AYP7167B79

PEERLESS TRANSAXLE - MODEL NUMBER 930-055A




Ref #	Part Number	Qty	Description
1	772108A		TRANSAXLE COVER
2	780086		BEARING, NEEDLE
3	770102A		TRANSAXLE CASE
4	776260		SHAFT, COUNTER
5	776219B		OUTPUT SHAFT AND PINION
6	778139		GEAR, OUTPUT
7	778136		GEAR, SPUR, 15 TEETH
8	792136A		SHIFT KEY
8A	792047		KEY, WOODRUFF
9	784352		COLLAR, SHIFTER
10	784355		ROD & FORK ASSY, SHIFT
11	778229		GEAR, BEVEL, 42 TEETH
12	778113A		BEVEL PINION, INPUT
13	778221		GEAR, BEVEL
14	778068		GEAR, BEVEL, PINION
15	778260		GEAR, RING
17	786139		PIN, DRIVE
18	786102		SPACER, NEUTRAL
20	792077		BALL STEEL, 5/16" DIA.
21	792078		SCREW, 3/8-16 X 3/8"
22	792079		SPRING
23	788061		RING, SEAL
25	792073		SCREW, 1/4-20 X 1-1/4
26	792125		RING RETAINER
27	792035		RING, RETAINER
28	788040		RETAINING RING
29	780072		WASHER THRUST
30	780108		WASHER THRUST
31	780001		WASHER
32	792001		"O" RING
33	788095		SEAL, SQUARE CUT
34	780105A		BUSHING, FLANGED
35	780118A		BUSHING, FLANGED
36	790003		DISK, BRAKE
37	790007		PLATE BRAKE PAD
38	799021		BRAKE PAD
39	786026		PIN DOWEL
40	792076A		WASHER
41	790079		BRAKE LEVER
42	792073		SCREW, 1/4-20 X 1-1/4
42A	792085A		SCREW, 1/4-20 X 2-1/4
43	792075		LOCKNUT 5/16-24
44	790025		HOLDER BRAKE PAD
45	786066		SPACER
46	786086		BRKT BRAKE LEVER
47	774690		AXLE
48	774691		AXLE
49	778215		GEAR, SPUR, 37 TEETH
50	778125		GEAR, SPUR, 35 TEETH
51	778124A		GEAR, SPUR, 30 TEETH
52	778123A		GEAR, SPUR, 25 TEETH
53	778122A		GEAR, SPUR, 22 TEETH
54	778273		GEAR, SPUR, 19T
56	778230		GEAR, SPUR, 12 TEETH
57	778151		GEAR, SPUR, 15 TEETH
58	778126A		GEAR, SPUR, 20 TEETH
59	778127A		GEAR, SPUR, 25 TEETH
60	778128A		GEAR, SPUR, 28 TEETH

Ref #	Part Number	Qty	Description
61	778163		GEAR, SPUR, 31 TEETH
65	780109		WASHER, THRUST
66	776135		SHAFT, INPUT
67	776315A		SHAFT, BRAKE, 4 KEYED
68	786116A		PLUG
69	780051		WASHER THRUST
70	786118		SPACER
71	788069		SEAL SQUARE CUT
72	792165		THREADED PLUG 9/16-18
72A	788091		"O" RING
76	780090		WASHER, THRUST
77	788078A		INVERTED RETAINING RING
79	792144		SPRING
81	786081		CHAIN, ROLLER
82	786082		SPROCKET 9T
83	786123		SPROCKET 18T (REV)
90	788067B		GREASE BENTONITE, 32 OZ.
103	792166		SCREW
104	792167		LOCKNUT
150	510334		GASKET ELIMINATOR
900	794603		REPLACEMENT TRANSAXLE




TRACTOR -- MODEL NUMBER AYP7167B79

SCHEMATIC




TRACTOR - - MODEL NUMBER AYP7167B79

SEAT ASSEMBLY




NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	140116		SEAT
2	140551		BRACKET PVT SEAT
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
10	155925		PAN-SEAT
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	153236		"BOLT,SHOULDER"
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER
27	17490608		SCREW LT
28	150176		BOLT.5/16-18.UNC




TRACTOR - - MODEL NUMBER AYP7167B79

STEERING ASSEMBLY



Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	137094		SUB= 532137094
3	157479		"SPINDLE ASM,LH"
4	157478		"SPINDLE ASM,RH"
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	154432		LINK.DRAG
11	10040600		LOCKWASHER
13	154779		BEARING AXLE
15	73901000		"NUT-LOC,FLANGE LT"
17	156546		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71070410		"SCREW,SPECIAL"
23	127501		SUB= 918127501
25	154406		BRKT-STEERING
27	136874		GEAR SECTOR
29	17490612		SCREW
32	137347		ROD.ASM.TIE.BALL
36	155099		BUSHING.STEERING
37	152927		"SCREW-TT,10-32 FL"
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	100711L		ADAPTER LT
42	145054		BOOT.STEER.PL
43	121749X		WASHER
44	153720		EXT SHAFT STEERIN
46	121232X		CAP
47	6855M		ZERK M
51	73800500		NUT
54	74780520		BOLT
62	156594		KIT STEERING ASM
63	74780616		BOLT
65	154780		SPACER AXLE
66	154404		"BEARING-ARM,PITMA"
67	74781044		BOLT
68	154429		BRACE AXLE

WHEELS AND TIRES



Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	122082X		SUB= 918122082X
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP
	144334		SEALANT.TIRE 10 OZ. TUBE

