


18 HP 44" TRACTOR -- MODEL NUMBER AYP8186A49

CHASSIS AND ENCLOSURES




- A 4
- B 41
- C 86
- D 13
- E 10
- F 5
- G 11
- H 119
- J 37
- K 39
- L 74
- M 111
- N 54
- P 113
- Q 83
- R 100
- S 115
- T 83
- U 123
- V 124
- W 88
- X 125
- Y 127
- Z 128
- 1 1
- 2 2
- 3 3
- 4 4
- 5 5
- 6 6
- 7 7
- 8 8
- 9 9
- 10 10
- 11 11
- 12 12
- 13 13
- 14 14
- 15 15
- 16 16
- 17 17
- 18 18
- 19 19
- 20 20
- 21 21
- 22 22
- 23 23
- 24 24
- 25 25
- 26 26
- 27 27
- 28 28
- 29 29
- 30 30
- 31 31
- 32 32
- 33 33
- 34 34
- 35 35
- 36 36
- 37 37
- 38 38
- 39 39
- 40 40
- 41 41
- 42 42
- 43 43
- 44 44
- 45 45
- 46 46
- 47 47
- 48 48
- 49 49
- 50 50
- 51 51
- 52 52
- 53 53
- 54 54
- 55 55
- 56 56
- 57 57
- 58 58
- 59 59
- 60 60
- 61 61
- 62 62
- 63 63
- 64 64
- 65 65
- 66 66
- 67 67
- 68 68
- 69 69
- 70 70
- 71 71
- 72 72
- 73 73
- 74 74
- 75 75
- 76 76
- 77 77
- 78 78
- 79 79
- 80 80
- 81 81
- 82 82
- 83 83
- 84 84
- 85 85
- 86 86
- 87 87
- 88 88
- 89 89
- 90 90
- 91 91
- 92 92
- 93 93
- 94 94
- 95 95
- 96 96
- 97 97
- 98 98
- 99 99
- 100 100
- 101 101
- 102 102
- 103 103
- 104 104
- 105 105
- 106 106
- 107 107
- 108 108
- 109 109
- 110 110
- 111 111
- 112 112
- 113 113
- 114 114
- 115 115
- 116 116
- 117 117
- 118 118
- 119 119
- 120 120
- 121 121
- 122 122
- 123 123
- 124 124
- 125 125
- 126 126
- 127 127
- 128 128

Ref #	Part Number	Qty	Description
1	127429X		SUB= 140121
2	140552		SUB= 155925
3	140551		BRACKET PVT SEAT
4	139888		BOLT.SHLD.5/16-18
5	17490508		SCREW LT
6	73680500		SUB= 73690500
7	73680600		SUB= 73690600
8	140002X505		FENDER.PNT.
10	74780814		BOLT
11	17490612		SCREW
12	19131312		WASHER
13	74760612		SUB= 74780612
14	140675		STRAP ASM FENDER
15	19171912		WASHER
17	135029		MUFFLER GUARD
18	121246X		BRKT SWITCH
19	124181X		SPRING COMPRESSION
20	105531X		NUT-PUSH YT
21	137113		BRKT.ASM.FENDER
23	141069		SUB= 151346
24	140527		CAP ASM FUEL
25	123487X		HOSE CLAMP
26	8543R		FUEL LINE T
27	106082X		PAD-SPACER LT
28	140341		SUB= 145501
29	123785X		DRAW BAR
30	138644		PANEL.DASH.LH
31	121794X		COVER ACCESS
32	138643		PANEL.DASH.RH
33	109227X		PAD IDLER TI
34	10040800		LOCKWASHER
35	105465X505		SUB= 145244X505
36	105464X505		SUB= 145243X505
37	72110606		BOLT
38	133671		FOOTREST PAD
39	17490608		SCREW LT
40	3645J		BUSHING OUTLET T
41	73800600		NUT
42	140407		CLIP PUSH - IN
43	110436X		SUB= 9151R
44	139886		BRACKET ASM LH
45	139887		BRACKET ASM RH
50	132635X505		SUB= 150301X505
54	19091216		WASHER PM
55	131716		SUB= 532131716
58	121248X		BUSHING
59	121249X		SPACER SPLIT
60	123740X		SPRING COMPRESSED
61	137655X418		PANEL.SIDE.RH
62	132637X418		SIDE PANEL LH
63	104618X		SUB= 155013
64	106784X		SUB= 155013
67	106395X		LENS LT
68	124392X417		SUB= 147717
74	74760612		SUB= 74780612
75	139227		SUB= 139277
85	19131614		WASHER
86	124346X		NUT

Ref #	Part Number	Qty	Description
87	105419X418		STRAP.GRILLE
88	132644		SUB= 532132644
91	72050411		SUB= 872050411
93	127018X		"BOLT,SHOULDER"
95	123976X		SUB= 73900400
96	72140608		SUB= 72110608
97	74760614		SUB= 74760616
99	139991		CONSOLE SHIFT
110	109808X		HOOD LATCH T
111	17211010		SCREW LT
112	104755X		""J"" FASTENER LT"
113	74191008		SCREW
114	10071000		LOCKWASHER
115	2029J		WELDNUT
116	123481X		SUB= 7605J
117	73680400		SUB= 73690400
118	73220400		SUB= 50675
119	74981020		SCREW
120	7206J		SPACER LT
121	19070818		WASHER
122	73731000		NUT
123	17490512		SCREW
124	19131210		WASHER
125	17490412		SCREW HEX CRT
126	19091016		WASHER
127	73510400		NUT
128	123198X		SUB= 146525
129	142992		STOP.OVER.CENTER
130	72240608		BOLT
131	73800600		NUT
132	19131612		WASHER GT

18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49


DECALS



Ref #	Part Number	Qty	Description
1	138955		DECAL.DASH.INST.
2	141557		DECAL HD LH WIZ +
3	141556		DECAL HD RH WIZ +
4	141558		DECAL PANEL SIDE
5	106202X		REFLECTOR-TAIL YT
6	133796		DECAL
7	4900J		DECAL T
8	141561		DECAL CHASSIS
9	140837		DECAL BRAK PARK
10	141517		DECAL DECK WIZ +
11	141654		DECAL STEER WHL
13	133780		NLA
14	127520		NLA
15	139346		"DECAL.V.BELT.44""
	138311		DECAL HANDLE LIFT
	141937		MANUAL.O.8186A49
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	278H		FITTING LT
4	106230X		SUB= 122075X
4	124106X		SUB= 138756
5	59904		TUBE.5.3/4.5/6
5	7154J		TUBE.23X8/10-12
6	106228X427		"RIM ASM 8"" FRT"
6	106277X427		"RIM ASM 12"" REAR"
7	104757X		HUB CAP
8	9040H		"FLANGE, BEARING"
9	121748X		WASHER

18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49

DRIVE




- | A | B | C | D | E | F | H | J | K | L | M | N | P |
|----|----|----|----|-----|----|----|----|-----|----|----|----|----|
| 26 | 24 | 47 | 52 | 101 | 75 | 84 | 8 | 101 | 89 | 11 | 24 | 11 |
| 27 | 27 | | 82 | 100 | | | 5 | | 97 | 94 | | |
| 97 | | | 51 | | | | 51 | | | | | |

Ref #	Part Number	Qty	Description
1	121327X		PULLEY TRANSAXLE
2	12000004		RING
3	2228M		SUB= 2228M1
4	138788		TRANSAX. PRLES.
5	72140506		BOLT
6	19111012		WASHER T
7	71208		BUSHING
8			REFER TO IMAGE
9	126197X		WASHER
11	17490628		SCREW LT
13			CHECK WITH SUPPLIER
14	137978		SUB= 149723
15	122434X		TUBE ASSY EXH LH
16	122435X		TUBE ASSY EXH RH
17	123796X		BELT.GRDRV.94.75
19	106933X		KNOB T (1/2-HOLE)
20	123781X		SUB= 141002
21	105701X		WASH-SHFT PLT LT
22	19171216		WASHER
23	76020416		PIN COTTER 1/8
24	17490612		SCREW
25	121218X		KEEPER BELT ENGLH
26	74760616		BOLT
27	19131312		WASHER
28	73680600		SUB= 73690600
29	8883R		PEDAL COVER T
30	122424X		SUB= 149001
31	1572H		SUB= 2882J
32	19211616		WASHER LT
33	122439X		BRACKET MUFFLER
34	123792X		"KEEPER,BELT RH"
35	137140		SUB= 142600
36	140312		KEEPER BELT CNTSP
37	109070X		BELT KEEPER LT
38	4470J		SPACER T
39	123674X		PULLEY.IDLER.FLAT
40	74760644		BOLT
41	136906		PULLEY ENGINE
42	10040700		LOCKWASHER
43	71170768		SUB= 150280
44	123791X		KEEPER BELT LH
45	17190408		SCREW ST
46	123776X		BRKT TRANS RH
47	120183X		NYLON BEARING
48	71040412		SUB= 74550412
49	19091216		WASHER PM
50	143600		SHIELD HEAT LT
51	73680500		SUB= 73690500
52	74780544		BOLT HEX
53	123787X		STRAP TORQUE
54	123780X		BRKT TRANS LH
55	123794X		"ARM,SHIFT"
56	76020412		COTTER PIN
57	133261		BRAKE PARK ROD
58	123786X		ROD BRAKE
59	124236X		CAP
60	126909X		"SPRING ROD BRAKE"
61	19131316		WASHER

Ref #	Part Number	Qty	Description
62	123800X		WASHER
63	19132012		WASHER
64	128953		HEAT SHIELD
65	127783		SUB= 139245
66	123789X		ARM IDLER
67	123205X		RETAIN BELT
68	74760624		SUB= 74930624
69	110812X		WASHER LT
70	12000039		KLIP RING
71	105709X		"SPRING, RETURN LT"
72	105710X		"LINK, CLUTCH T"
73	73530400		NUT 1/4-28
74	132747		SUB= 532132748
75	17720410		SCREW LT
76	123650X		STUD.1/4.TURN
77	133746		HEAT SHIELD
78	105838X		RETAINER LT
79	105839X		RECEPTACLE LT
80	105730X		"KEEPER,BLT ENG LT"
81	108097X		SPACER HYT
82	19111216		WASHER M
83	12000053		E RING HYT
84	73800600		NUT
85	9396E		SQ KEY STD
88	19212016		WASHER D
89	74760612		SUB= 74780612
90	105706X		"LY, BEARING"
91	12000008		KLIP RING
92	123772X		"SHAFT,SHIFTER"
93	123782X		"SPRING,TORSION"
94	11050600		LOCKWASHER
97	73800600		NUT
98	137141		BRACKET.ASM.MTG
100	19132012		WASHER
101	17490512		SCREW
102	2751R		CLIP T
103	123793X		"ROD,TIE "
104	137180		SUB= 532137180
105	110422X		SUB= 146682
106	4497H		RETAINER M
108	13280336		PIPE NIPPLE LT
112	13200300		ELBOW
116	17021008		SCREW
117	73350600		NUT





18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49

ELECTRICAL



Ref #	Part Number	Qty	Description
1	121537X		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
5	121264X		"CAP,BATTERY "
6	73220400		SUB= 50675
7	7697J		"DRAIN TU T, BATT"
8	7603J		"TRAY T, BATTERY"
9	109596X		HOSE CLAMP T
10	72240460		BOLT
11	102476X		SUB= 150109
12	123198X		SUB= 146525
14	19121618		WASHER.3/4X1X18GA
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
23	11150400		LOCKWASHER
24	4206J		CABLE-BATTERY T
25	4206J		CABLE-BATTERY T
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	140399		SUB= 163088
31	140400		SUB= 145774
32	123620X		SUB= 141226
33	140401		KEY MLD GEN DELTA
34	110712X		SWITCH LT
35	108236X		BRACKET LT
36	17021008		SCREW
37	104445X		SWITCH-INTER. GT
40	140420		HARNES IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	138406		SUB= 146154
44	73680400		SUB= 73690400
45	122822X		AMMETER
46	141940		PROTECTION LOOP
50	140404		SUB= 154959
51	140405		RING RETAIN PTO
70	140424		HARNES ENGINE

**18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49
ENGINE BRIGGS & STRATTON - - MODEL NUMBER 350777, TYPE 0034-01**




Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	80790		ROD, ASSEMBLY
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	807802		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	907806		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL

Ref #	Part Number	Qty	Description
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	399172		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT

Ref #	Part Number	Qty	Description
	879 805636		COVER, CARBURETOR
	883 805024		GASKET, EXHAUST MANIFOLD
	896 94288		ROLL PIN
	947 494312		SOLENOID
	975 807913		BOWL, FUEL ASSEMBLY
	977 807916		GASKET SET, CARBURETOR
	978 805250		GASKET, OIL FILTER ADAPTOR
	982 805030		SCREW, SEMS
	985 398525		INSULATOR ASSEMBLY
	1003 490316		BRUSH SPRING SET
	1004 805632		TUBE, AIR INLET
	1005 807863		FAN, FLYWHEEL
	1006 224413		RETAINER, FAN
	1014 807797		DEFLECTOR, BREATHER, A.C.
	1022 805028		NUT, HEX
	1023 805100		COVER, VALVE
	807665		COVER, VALVE
	1024 807546		OIL PUMP ASSEMBLY
	1025 805313		SLIDER, GOVERNOR
	1026 805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
	1027 492932		FILTER, OIL
	1028 805292		ADAPTER, OIL FILTER
	1029 807557		ARM, ROCKER
	1030 805342		SHAFT, ROCKER ARM
	1031 805341		SUPPORT, ROCKER ARM
	1033 807910		OVERHAUL KIT, VALVE
	1036 807688		BREATHER GASKET SET
	1037 807915		BALL, CHOKE LOCATOR

18 HP 44" TRACTOR -- MODEL NUMBER AYP8186A49
ENGINE BRIGGS & STRATTON -- MODEL NUMBER 350777, TYPE 0034-01




Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	80790		ROD, ASSEMBLY
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	807802		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	907806		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL

Ref #	Part Number	Qty	Description
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	399172		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT

Ref #	Part Number	Qty	Description
	879 805636		COVER, CARBURETOR
	883 805024		GASKET, EXHAUST MANIFOLD
	896 94288		ROLL PIN
	947 494312		SOLENOID
	975 807913		BOWL, FUEL ASSEMBLY
	977 807916		GASKET SET, CARBURETOR
	978 805250		GASKET, OIL FILTER ADAPTOR
	982 805030		SCREW, SEMS
	985 398525		INSULATOR ASSEMBLY
	1003 490316		BRUSH SPRING SET
	1004 805632		TUBE, AIR INLET
	1005 807863		FAN, FLYWHEEL
	1006 224413		RETAINER, FAN
	1014 807797		DEFLECTOR, BREATHER, A.C.
	1022 805028		NUT, HEX
	1023 805100		COVER, VALVE
	807665		COVER, VALVE
	1024 807546		OIL PUMP ASSEMBLY
	1025 805313		SLIDER, GOVERNOR
	1026 805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
	1027 492932		FILTER, OIL
	1028 805292		ADAPTER, OIL FILTER
	1029 807557		ARM, ROCKER
	1030 805342		SHAFT, ROCKER ARM
	1031 805341		SUPPORT, ROCKER ARM
	1033 807910		OVERHAUL KIT, VALVE
	1036 807688		BREATHER GASKET SET
	1037 807915		BALL, CHOKE LOCATOR

18 HP 44" TRACTOR -- MODEL NUMBER AYP8186A49
ENGINE BRIGGS & STRATTON -- MODEL NUMBER 350777, TYPE 0034-01




Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	80790		ROD, ASSEMBLY
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	807802		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	907806		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL

Ref #	Part Number	Qty	Description
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	399172		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT

Ref #	Part Number	Qty	Description
	879 805636		COVER, CARBURETOR
	883 805024		GASKET, EXHAUST MANIFOLD
	896 94288		ROLL PIN
	947 494312		SOLENOID
	975 807913		BOWL, FUEL ASSEMBLY
	977 807916		GASKET SET, CARBURETOR
	978 805250		GASKET, OIL FILTER ADAPTOR
	982 805030		SCREW, SEMS
	985 398525		INSULATOR ASSEMBLY
	1003 490316		BRUSH SPRING SET
	1004 805632		TUBE, AIR INLET
	1005 807863		FAN, FLYWHEEL
	1006 224413		RETAINER, FAN
	1014 807797		DEFLECTOR, BREATHER, A.C.
	1022 805028		NUT, HEX
	1023 805100		COVER, VALVE
	807665		COVER, VALVE
	1024 807546		OIL PUMP ASSEMBLY
	1025 805313		SLIDER, GOVERNOR
	1026 805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
	1027 492932		FILTER, OIL
	1028 805292		ADAPTER, OIL FILTER
	1029 807557		ARM, ROCKER
	1030 805342		SHAFT, ROCKER ARM
	1031 805341		SUPPORT, ROCKER ARM
	1033 807910		OVERHAUL KIT, VALVE
	1036 807688		BREATHER GASKET SET
	1037 807915		BALL, CHOKE LOCATOR

18 HP 44" TRACTOR -- MODEL NUMBER AYP8186A49 ENGINE BRIGGS & STRATTON -- MODEL NUMBER 350777, TYPE 0034-01



* REQUIRES SPECIAL TOOLS TO INSTALL
(SEE REPAIR INSTRUCTION MANUAL)

Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	80790		ROD, ASSEMBLY
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	807802		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	907806		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL

Ref #	Part Number	Qty	Description
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	399172		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT

Ref #	Part Number	Qty	Description
879	805636		COVER, CARBURETOR
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	494312		SOLENOID
975	807913		BOWL, FUEL ASSEMBLY
977	807916		GASKET SET, CARBURETOR
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1005	807863		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807910		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807915		BALL, CHOKE LOCATOR

18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49


LIFT ADJUSTMENT



Ref #	Part Number	Qty	Description
1	121006X		LEVER ROD LT
2	131926		SUB= 532131926
3	121002X		SUB= 123096X
4	12000022		E-RING
5	19292016		WASHER
6	74780624		"BOLT,HEX"
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
9	122364X		SUB= 125925X
11	141047		LINK LIFT LH
12	141048		LINK LIFT RH
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
21	19151216		WASHER
22	12000037		KLIP RING
23	110807X		NUT T
24	19131016		WASHER
25	2876H		SPRING T
26	76020308		SUB= 3145
27	110729X		ROD LIFT LT
28	73350600		NUT
29	138057		KNOB INF 3/8-16
30	110810X		TRUNION LT
31	140302		BEARING PVT LH
32	73810600		NUT.LOCK.3/8-24
42	120529X		WASHER T
43	123933X505		POINTER HGT IND
44	123935X		"PLUG,HOLE"
45	74780516		SUB= 77394
46	10040500		LOCKWASHER
47	19112410		WASHER
48	123934X		HEIGHT INDICATOR

18 HP 44" TRACTOR - MODEL NUMBER AYP8186A49

44" MOWER DECK





Ref #	Part Number	Qty	Description
1	136471		SUB= 140579
2	73800500		NUT
3	72110506		SUB= 72270506
4	7631J		RUNNER-LH M
5	138457		BRKT.ASM.SW.44/50
6	4939M		SUB= 85902
7	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	130652		"BLADE.44"" HIPERF"
12	129895		BEARING.BALL
13	137553		SHAFT.ASM.W/BRNG
14	137152		HOUSING.MAND.44.V
15	110485X		BEARING
16	136929		SUB= 140329
17	106735X		ROD-HINGE T
18	19111016		WASHER
19	105304X		CAP-SLEEVE LT
20	123713X		SPRING TORSION
21	137607		BRKT DEFLECTOR
22	110452X		NUT PUSH M
23	109785X		DEFLECTOR SHIELD
24	136321		RUNNER.RH
25	19111216		WASHER M
26	72110614		BOLT
27	19131316		WASHER
28	132823		SUB= 532132823
29	73800600		NUT
30	138776		SUB= 157722
31	137266		SUB= 139729
32	129861		SUB= 153535
33	129963		WASHER
34	72140610		BOLT.3/8-14X1.25
35	72110616		BOLT
36	72110608		BOLT D
37	137166		STIFFENER.ARM.IDL
38	137554		SUB= 918137554
39	131494		FLAT IDLER PULLEY
40	136572		"PULLEY.DRIVEN.44"""
42	72140506		BOLT
43	136460		"ARM.IDLER.SEC.44"""
44	122052X		SPACER RETAINER
45	73680600		SUB= 73690600
46	74760628		BOLT
47	137200		"COVER.MAND.RH.44"""
48	137729		SCREW.1/4-20X5/8
49	136574		COVER.MANDREL.LH
50	137272		ARM.IDLER.PRIMARY
51	137273		"SPRING.SEC.44""VEN"
52	139245		PULLEY.IDLER.VGRO
53	137789		SHIELD.IDLER.44.V
54	131264		V-BELT.PRIM.78.5.
55	131290		BELT-V.88.12.MW
56	138687		SPRING.EXT.DECK.
57	136577		BAR.ASM.GUAGE.WHL
58	133957		WHEEL GAGE DONUT
59	137644		BOLT.SHOULDER

Ref #	Part Number	Qty	Description
60	139031		PIN.CLEVIS
61	136573		BRACKET.GUAGE.WHL
62	133943		HARDENED WASHER
63	72110612		BOLT.3/8-16X1.50
64	19121414		WASHER
67	73930600		LOCKNUT
	130794		MANDREL ASM
	138660		SUB= 144075



18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49

SCHEMATIC



IGNITION SWITCH


POSITION	CIRCUIT
OFF	M + G
ON	B + L
START	B + S + L

● NON-REMOVABLE CONNECTIONS

○ REMOVABLE CONNECTIONS

WIRING INSULATED CLIPS

NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING




PTO SWITCH

POSITION	CIRCUIT
OFF	C + G
ON	C + F, B + E, A + D


18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49

STEERING ASSEMBLY




Ref #	Part Number	Qty	Description
1	121749X		WASHER
2	133742		ST WHL INSERT CAP
3	73940800		SUB= 73360800
4	100712K		WASHER
5	133741		SUB= 150547
6	100711L		ADAPTER LT
7	126471X		"CLIP,INSULATOR"
8	140398		DASHBOARD BLACK
9	140299X016		PLATE DASH SILKSC
10	109816X		NYLINER T
11	17490608		SCREW LT
12	121748X		WASHER
13	128758		STEERING SHAFT
14	8022J		PLUG-DASH T
15	73510500		NUT
16	124036X		"BRKT,STEERING"
18	17490612		SCREW
19	127501		SUB= 918127501
20	12000029		RING
21	6266H		WASHER .T
22	136874		GEAR SECTOR
24	104783X		DASH ASSY LT
25	74180512		SCREW
26	73800500		NUT
27	127543		SUB= 127543X011
28	73680600		SUB= 73690600
29	74760532		BOLT
30	121236X		SPACER
31	140181		PLATE.SUPT.BATTER
32	74760612		SUB= 74780612
33	57079		THRUST WASHER
34	124035X		SUPPORT.SHAFT
35	126684X		SUB= 532126684
36	132781		CHOKE CONTROL
38	11050600		LOCKWASHER
39	141052		BUSHING SPIN STOP
40	133988		SUB= 142033
41	105663X		SUPPORT-SADDL T
42	74761060		BOLT LT
43	105664X		SUPPORT.SADDLE.FT
45	110438X		BEARING
46	73901000		"NUT-LOC,FLANGE LT"
47	17490508		SCREW LT
48	135227		SPINDLE LH
49	135228		SPINDLE RH
51	130467		TIE ROD
52	10040500		LOCKWASHER
53	73810500		NUT.LOCK.5/16-24
54	3366R		COL. SRTG. BEAR.
55	130468		SUB= 532130468
56	10040600		LOCKWASHER
57	73610600		SUB= 7810H
58	1554J		SUB= 155108
59	17431008		SUB= 98000165
61	2751R		CLIP T
63	121232X		CAP
66	6855M		ZERK M
77	74180512		SCREW

Ref #	Part Number	Qty	Description
78	19111116		WASHER
79	73510500		NUT
80	19272016		WASHER
82	122819X		SCREW SPECIAL
84	19111216		WASHER M
86	10040400		LOCKWASHER
87	71070410		"SCREW,SPECIAL"
88	132624		AXLE PIN
89	19131316		WASHER
90	124130X		SUPPORT ASSY
91	74760612		SUB= 74780612
94	19091216		WASHER PM
95	73220400		SUB= 50675
97	19131312		WASHER



18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49 PEERLESS TRANSAXLE - - MODEL NUMER 820-016B

TRANSAXLE




Ref #	Part Number	Qty	Description
	794513		TRANSAXLE, COMPLETE
1	772098A		COVER TRANSAXLE
2	780155		BEARING NEEDLE
3	770088		CASE TRANSAXLE
4	776291		SHAFT COUNTER
5	776275		SHAFT, OUTPUT, 9T
6	778247		GEAR, OUTPUT, 35T
7	778253		GEAR, SPUR, 15T
8	792138		KEY
9	784216		COLLAR SHIFT
10	784342		ROD AND FORK ASSY SHIFT
11	778246		GEAR BEVEL, 33T
12	778245		BEVEL PINION, 13T
13	778198		GEAR BEVEL
14	778197		PINION, 10T
15	778248		GEAR, RING, 31T
16	786027		BLOCK DRIVE
17	786019		PIN DRIVE
18	786121		SPACER, .350/.340 THICK
18A	786122		SPACER, .276/.268 THICK
20	792077		BALL STEEL, 5/16" DIA.
21	792078		SCREW, 3/8-16 X 3/8"
22	792079		SPRING
24	780071		THRUST BEARING
25	792129		SCREW HEX HD 5/16-18 X 1-1/4
25A	792073		SCREW, 1/4-20 X 1-1/4
26	792018		RING STRAP
27	792018		RING STRAP
28	788040		RETAINING RING
29	780072		WASHER THRUST
30	780108		WASHER THRUST
31	780128		WASHER THRUST
31A	780107		WASHER
31B	780042		WASHER THRUST
36	790043		DISK BRAKE
37	790007		PLATE BRAKE PAD
38	799021		BRAKE PAD
39	786026		PIN DOWEL
40	792076A		WASHER
41	790047		LEVER BRAKE
42	792073		SCREW, 1/4-20 X 1-1/4
42A	792085A		SCREW, 1/4-20 X 2-1/4
43	792075		LOCKNUT 5/16-24
44	790025		HOLDER BRAKE PAD
45	786067		SPACER
46	786086		BRKT BRAKE LEVER
47	774832		AXLE, 12-5/16" LONG
48	774831		AXLE, 16-3/16" LONG
49	778216A		GEAR, SPUR, 41T
50	778206A		GEAR, SPUR, 35T
51	778205A		GEAR, SPUR, 30T
52	778204A		GEAR, SPUR, 25T
53	778203A		GEAR, SPUR, 22T
54	778273		GEAR, SPUR, 19T
57	778199		GEAR, SPUR, 15T
58	778200		GEAR, SPUR, 20T
59	778201		GEAR, SPUR, 25T
60	778202		GEAR, SPUR, 28T

Ref #	Part Number	Qty	Description
61	778208		GEAR, SPUR, 31T
65	780139		WASHER
66	776274		SHAFT INPUT
67	776313		SHAFT BRAKE
71	788069		SEAL SQUARE CUT
71A	792145		PUSHNUT
72	792074		PLUG, THRDED, 9/16-18
79	792144		SPRING
81	786081		CHAIN, ROLLER
82	786082		SPROCKET 9T
83	786123		SPROCKET 18T (REV)
84	786131		BEARING CAP
87	788042		OIL SEAL 3/4
88	780119		BEARING BALL
89	780050		BEARING BALL
90	788067B		GREASE BENTONITE, 32 OZ.
96	780084		BEARING THRUST
97	780051		WASHER THRUST
98	780165		WASHER
99	788077		"O" RING
100	780166		WASHER CUPPED
101	774833		CARRIER DIFF THREADED HOLES
102	774834		CARRIER DIFF
103	792020		SCREW, 1/4-20 X 2-1/4
104	792006		WASHER LOCK 1/4
105	780153		WASHER
106	786144		SLEEVE
107	780152		BEARING NEEDLE
108	780150		BEARING NEEDLE
109	792001		"O" RING
110	786142		SLEEVE STEPPED
111	788071		RING SQ CUT
112	780168		BEARING NEEDLE CAPPED
113	786143		SLEEVE STEPPED
114	780151		BEARING NEEDLE CAPPED
115	786145		SLEEVE STEPPED
116	788070		RING SQ CUT
117	780031		BEARING NEEDLE
150	510334		GASKET ELIMINATOR

18 HP 44" TRACTOR - - MODEL NUMBER AYP8186A49

WHEELS AND TIRES



Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	278H		FITTING LT
4	106230X		SUB= 122075X
4	124106X		SUB= 138756
5	59904		TUBE.5.3/4.5/6
5	7154J		TUBE.23X8/10-12
6	106228X427		"RIM ASM 8" FRT"
6	106277X427		"RIM ASM 12" REAR"
7	104757X		HUB CAP
8	9040H		"FLANGE, BEARING"
9	121748X		WASHER

