


# TRACTOR -- MODEL NUMBER AYP8186A59

## CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
1	145501		CHASSIS.WLD.11GA
2	123785X		DRAW BAR
3	17490612		SCREW
6	145206		SUB= 145206X431
7	136800		"BAFFLE,HOOD"
8	126471X		"CLIP,INSULATOR"
9	140398		DASHBOARD BLACK
10	72140608		SUB= 72110608
11	145222		PANEL.DASH.LH.PNT
13	145221		PANEL.DASH.RH.PNT
14	17490608		SCREW LT
15	74180512		SCREW
16	73510500		NUT
17	132635X505		SUB= 150301X505
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
27	17030814		SUB= 91817030814
28	131716		SUB= 532131716
29	146459		LENS.BAR.CLEAR
30	140002X505		FENDER.PNT.
31	137113		BRKT.ASM.FENDER
33	145244X505		FOOTREST.LH.LT/GT
34	145243X505		FOOTREST.RH.LT/GT
35	72110606		BOLT
36	108067X		PAL NUT LT
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
43	17490616		SCREW GTV
44	140675		STRAP ASM FENDER
45	124392X417		SUB= 147717
47	105531X		NUT-PUSH YT
50	145205		DASH.SUPT.YP/HUSQ
51	73800400		NUT
56	145151		DASH.EXT.PNT.
59	110436X		SUB= 9151R
64	145095		SUB= 150272
66	140299X016		PLATE DASH SILKSC
67	19111116		WASHER
69	106784X		SUB= 155013
70	104618X		SUB= 155013
71	73510400		NUT
72	144916X418		STRAP.GRILL
73	17580408		SCREW CRT
74	73680600		SUB= 73690600
75	123481X		SUB= 7605J
77	74191008		SCREW
78	10071000		LOCKWASHER
79	2029J		WELDNUT
80	109808X		HOOD LATCH T
81	123198X		SUB= 146525
82	74981020		SCREW
83	7206J		SPACER LT
84	19070818		WASHER
85	73731000		NUT
86	137655X418		PANEL.SIDE.RH
87	132637X418		SIDE PANEL LH
90	19091216		WASHER PM

Ref #	Part Number	Qty	Description
91	73220400		SUB= 50675
92	10040400		LOCKWASHER
100	105037X		FOAM-STRIP LT
108	74760612		SUB= 74780612
	8022J		PLUG-DASH T
	121794X		COVER ACCESS




# TRACTOR - - MODEL NUMBER AYP8186A59

## DRIVE




Ref #	Part Number	Qty	Description
1	138788		TRANSAX. PRLES.
2	110422X		SUB= 146682
3	121327X		PULLEY TRANSAXLE
4	12000004		RING
5	123787X		STRAP TORQUE
6	17490512		SCREW
8	123781X		SUB= 141002
9	137140		SUB= 142600
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
13	74550412		BOLT.1/4-28.W/PAT
14	19091216		WASHER PM
15	74780544		BOLT HEX
17	126197X		WASHER
19	73800600		NUT
20	71170768		SUB= 150280
21	106933X		KNOB T (1/2-HOLE)
22	145340		ROD.ASM.BK.44.MWR
23	137141		BRACKET.ASM.MTG
24	73350600		NUT
25	126909X		"SPRING,ROD BRAKE"
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	124236X		CAP
30	123780X		BRKT TRANS LH
31	123791X		KEEPER BELT LH
33	72140506		BOLT
34	149001		SHAFT.PEDAL.FOOT
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
43	19111012		WASHER T
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
54	2751R		CLIP T
55	105709X		"SPRING, RETURN LT"
57	123796X		BELT.GRDRV.94.75
58	123792X		"KEEPER,BELT RH"
59	140312		KEEPER BELT CNTSP
60	121218X		KEEPER BELT ENGLH
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	136906		PULLEY ENGINE
65	136906		PULLEY ENGINE

Ref #	Part Number	Qty	Description
65	10040700		LOCKWASHER
67	74760616		BOLT
68	105730X		"KEEPER,BLT ENG LT"
74	108097X		SPACER HYT
75	123800X		WASHER
76	12000053		E RING HYT
77	9396E		SQ KEY STD
79	2228M		SUB= 2228M1
80	123794X		"ARM,SHIFT"
81	123772X		"SHAFT,SHIFTER"
82	123782X		"SPRING,TORSION"
83	19171216		WASHER
84	123793X		"ROD,TIE "
85	73530400		NUT 1/4-28
86	71208		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	139992		CONSOLE SHIFTER
90	124346X		NUT
96	4497H		RETAINER M
100	19111216		WASHER M
110	74760612		SUB= 74780612
111	123776X		BRKT TRANS RH



# TRACTOR - - MODEL NUMBER AYP8186A59

## ELECTRICAL




Ref #	Part Number	Qty	Description
1	144926		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	7697J		"DRAIN TU T, BATT"
8	7603J		"TRAY T, BATTERY"
9	109596X		HOSE CLAMP T
10	145211		SUB= 150177
11	145209		SUB= 150109
12	145769		SUB= 150177
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES, LIGHT SOC"
22	4152J		HEADLAMP BULB
24	146136		CABLE.BTRY.6GA.RD
25	146148		CABLE.6GA.22W/16W
26	108824X		FUSE HYT
28	145491		CABLE.GRND.6GA.21
29	121305X		SWITCH SEAT
30	144921		SUB= 163088
31	140400		SUB= 145774
32	141226		COVER KEY SWITCH
33	140401		KEY MLD GEN DELTA
34	110712X		SWITCH LT
35	108236X		BRACKET LT
36	17021008		SCREW
39	109553X		SWITCH INTERLOCKT
40	145493		HARNES.ING.ELEC.
41	71110412		BOLT.HX.1/4-20
42	131563		SUB= 154336
44	73510400		NUT
45	122822X		AMMETER
46	141940		PROTECTION LOOP
49	11151000		LOCKWASHER
50	140404		SUB= 154959
51	140405		RING RETAIN PTO
55	17490508		SCREW LT
70	140424		HARNES ENGINE




# TRACTOR - - MODEL NUMBER AYP8186A59

## ENGINE



Ref #	Part Number	Qty	Description
1	132748		SUB= 532132748
2	17720410		SCREW LT
3			REFER TO IMAGE
4	137978		SUB= 149723
5	122434X		TUBE ASSY EXH LH
6	122435X		TUBE ASSY EXH RH
7	2751R		CLIP T
8	122439X		BRACKET MUFFLER
9	17190408		SCREW ST
10	145552		SHIELD.HEAT.
11			REFER TO IMAGE
12			REFER TO IMAGE
13			REFER TO IMAGE
14	13280336		PIPE NIPPLE LT
15	13200300		ELBOW
16	11050600		LOCKWASHER
18	133747		HEAT SHIELD
19	105839X		RECEPTACLE LT
20	105838X		RETAINER LT
21	110436X		SUB= 9151R
22	123650X		STUD.1/4.TURN
23	128953		HEAT SHIELD
24	17021008		SCREW
25	132781		CHOKE CONTROL
26	73610600		SUB= 7810H
29	137180		SUB= 532137180
31	141069		SUB= 151346
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
34	106082X		PAD-SPACER LT
35	17490512		SCREW
36	19132012		WASHER
37	8543R		FUEL LINE T
38			REFER TO IMAGE
39	109227X		PAD IDLER TI
40	3645J		BUSHING OUTLET T
41	139277		STEM.TANK.FUEL
78	17490620		SCREW
81	73510400		NUT

# TRACTOR -- MODEL NUMBER AYP8186A59 ENGINE BRIGGS & STRATTON -- MODEL NUMBER 350777, TYPE 0034-01



\* REQUIRES SPECIAL TOOLS TO INSTALL  
(SEE REPAIR INSTRUCTION MANUAL)


Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805772		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	807906		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94004		BOLT
510	495878		STARTER DRIVE GROUP
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER

Ref #	Part Number	Qty	Description
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	494988		CAP ASSEMBLY
803	494205		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495877		RETAINER AND PIN
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	494312		SOLENOID

Ref #	Part Number	Qty	Description
975	807913		BOWL, FUEL ASSEMBLY
977	807916		GASKET SET, CARBURETOR
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
1004	805632		TUBE, AIR INLET
1005	807863		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805100		COVER, VALVE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807910		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807915		BALL, CHOKE LOCATOR

**TRACTOR -- MODEL NUMBER AYP8186A59**  
**ENGINE BRIGGS & STRATTON -- MODEL NUMBER 350777, TYPE 0034-01**






Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805772		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	807906		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94004		BOLT
510	495878		STARTER DRIVE GROUP
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER

Ref #	Part Number	Qty	Description
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	494988		CAP ASSEMBLY
803	494205		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495877		RETAINER AND PIN
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	494312		SOLENOID

Ref #	Part Number	Qty	Description
975	807913		BOWL, FUEL ASSEMBLY
977	807916		GASKET SET, CARBURETOR
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
1004	805632		TUBE, AIR INLET
1005	807863		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805100		COVER, VALVE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807910		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807915		BALL, CHOKE LOCATOR

# TRACTOR - - MODEL NUMBER AYP8186A59 ENGINE BRIGGS & STRATTON - - MODEL NUMBER 350777, TYPE 0034-01




Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805772		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	807906		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94004		BOLT
510	495878		STARTER DRIVE GROUP
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER





Ref #	Part Number	Qty	Description
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	494988		CAP ASSEMBLY
803	494205		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495877		RETAINER AND PIN
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	494312		SOLENOID



Ref #	Part Number	Qty	Description
975	807913		BOWL, FUEL ASSEMBLY
977	807916		GASKET SET, CARBURETOR
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
1004	805632		TUBE, AIR INLET
1005	807863		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805100		COVER, VALVE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807910		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807915		BALL, CHOKE LOCATOR



**TRACTOR - - MODEL NUMBER AYP8186A59**  
**ENGINE BRIGGS & STRATTON - - MODEL NUMBER 350777, TYPE 0034-01**




Ref #	Part Number	Qty	Description
1	807787		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807821		HEAD, CYLINDER, CYLINDER #1
5.2	807822		HEAD, CYLINDER 2
6	805193		WASHER, CYLINDER HEAD
7	805653		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807779		CRANKSHAFT
	94196		KEY, TIMING GEAR
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805696		SCREW, CRANKCASE COVER
23	807790		FLYWHEEL, MAGNETO
24	805016		KEY, FLYWHEEL
25	807888		PISTON ASSEMBLY, STANDARD SIZE
	807991		PISTON ASSEMBLY
	807992		PISTON ASSEMBLY
	807993		PISTON ASSEMBLY
26	807889		RING SET, PISTON, STANDARD SIZE
	807994		RING SET, PISTON
	807995		RING SET, PISTON
	807996		RING SET, PISTON
27	805099		LOCK, PISTON PIN
28	807886		PIN ASSEMBLY, PISTON, STANDARD
29	807900		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
37	805506		COVER, STARTER
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805772		MANIFOLD, INTAKE
51	805700		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805669		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	805059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
95	94457		SCREW, VALVE MOUNTING
95A	94466		SCREW, VALVE MOUNTING
98	494690		SCREW, THROTTLE ADJUSTMENT
104	231652		PIN, FLOAT HINGE
105	808023		FUEL INLET ASSEMBLY
108	224534		VALVE CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B	224531		WASHER, BOWL
117	231780		JET, MAIN
117A	231779		JET, PILOT
117B	231823		JET, SHUT-OFF
118	494923		VALVE, IDLE ADJUSTING NEEDLE
121	807917		CARBURETOR OVERHAUL KIT
122	805674		SPACER, CARBURETOR
125	807906		CARBURETOR ASSEMBLY
130	224533		VALVE, THROTTLE
131	807909		SHAFT, THROTTLE ASSEMBLY
133	492283		FLOAT, BOWL
137			REFER TO IMAGE
139	805449		LOCK WASHER
141	807911		SHAFT, CHOKE
147	231781		NOZZLE, CARBURETOR
161	807857		BASE ASSEMBLY, AIR CLEANER
166	805343		STUD, ROCKER ARM
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	93535		SCREW, HEX HEAD
188A	805247		SCREW, STARTER MOUNTING
192	307623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
243	805312		SCREEN, OIL
254	492274		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807773		HOUSING, BLOWER, BLACK
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	494990		MOTOR, STARTING
310	94004		BOLT
510	495878		STARTER DRIVE GROUP
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
351	805169		SCREW
353	94791		WASHER, LOCK
354	90576		NUT, HEX
356	493792		WIRE ASSEMBLY, GROUND
358	807887		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS
445	394018		CARTRIDGE, AIR CLEANER


Ref #	Part Number	Qty	Description
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	807663		BACK PLATE ASSEMBLY
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	808022		SHAFT SEAL KIT
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
729A	224356		CLIP, DEBRIS
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	494988		CAP ASSEMBLY
803	494205		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	270920		SEAL, OIL FILLER CAP
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE
871	805084		GUIDE, VALVE
876	495877		RETAINER AND PIN
879	805841		COVER
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	494312		SOLENOID

Ref #	Part Number	Qty	Description
975	807913		BOWL, FUEL ASSEMBLY
977	807916		GASKET SET, CARBURETOR
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
1004	805632		TUBE, AIR INLET
1005	807863		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805100		COVER, VALVE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807910		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807915		BALL, CHOKE LOCATOR



# TRACTOR - MODEL NUMBER AYP8186A59

## MOWER DECK



Ref #	Part Number	Qty	Description
1	140579		"DECK ASM WELD44""
2	73680500		SUB= 73690500
3	72110506		SUB= 72270506
4	7631J		RUNNER-LH M
5	138457		BRKT.ASM.SW.44/50
6	4939M		SUB= 85902
7	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	130652		"BLADE.44"" HIPERF"
12	129895		BEARING.BALL
13	137553		SHAFT.ASM.W/BRNG
14	137152		HOUSING.MAND.44.V
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	106735X		ROD-HINGE T
18	19111016		WASHER
19	105304X		CAP-SLEEVE LT
20	123713X		SPRING TORSION
21	137607		BRKT DEFLECTOR
22	110452X		NUT PUSH M
23	109785X		DEFLECTOR SHIELD
24	136321		RUNNER.RH
25	19111216		WASHER M
27	19131316		WASHER
28	132823		SUB= 532132823
30	138776		SUB= 157722
31	137266		SUB= 139729
32	129861		SUB= 153535
33	129963		WASHER
34	72140610		BOLT.3/8-14X1.25
35	72110616		BOLT
36	72110608		BOLT D
37	137166		STIFFENER.ARM.IDL
38	137554		SUB= 918137554
39	131494		FLAT IDLER PULLEY
40	136572		"PULLEY.DRIVEN.44""
42	72140506		BOLT
43	136460		"ARM.IDLER.SEC.44""
44	122052X		SPACER RETAINER
45	73680600		SUB= 73690600
46	74760628		BOLT
47	137200		"COVER.MAND.RH.44""
48	137729		SCREW.1/4-20X5/8
49	136574		COVER.MANDREL.LH
50	137272		ARM.IDLER.PRIMARY
51	137273		"SPRING.SEC.44""VEN"
52	139245		PULLEY.IDLER.VGRO
53	137789		SHIELD.IDLER.44.V
54	131264		V-BELT.PRIM.78.5.
55	131290		BELT-V.88.12.MW
56	138687		SPRING.EXT.DECK.
57	136577		BAR.ASM.GUAGE.WHL
58	133957		WHEEL GAGE DONUT
59	137644		BOLT.SHOULDER
60	139031		PIN CLEVIS
61	136573		BRACKET.GUAGE.WHL




Ref #	Part Number	Qty	Description
62	133943		HARDENED WASHER
63	72110612		BOLT.3/8-16X1.50
64	19121414		WASHER
67	73930600		LOCKNUT
99	72110614		BOLT
	143651		MANDREL SERV ASM
	138660		SUB= 144075



# TRACTOR - - MODEL NUMBER AYP8186A59


## MOWER LIFT




Ref #	Part Number	Qty	Description
1	121006X		LEVER ROD LT
2	140673		SHAFT LIFT W/IND
6	74780624		"BOLT,HEX"
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
9	122364X		SUB= 125925X
10	2876H		SPRING T
11	145537		LINK.LIFT.LH.GTV
12	145536		LINK.LIFT.RH.GTV.
13	4939M		SUB= 85902
14	121002X		SUB= 123096X
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
21	19151216		WASHER
22	12000037		KLIP RING
23	110807X		NUT T
24	19131016		WASHER
25	137150		SPRING.COMP.INF.H
26	76020308		SUB= 3145
27	137167		ROD.ADJ.LIFT
28	73350600		NUT
29	138057		KNOB INF 3/8-16
30	110810X		TRUNION LT
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8
35	120529X		WASHER T
36	123933X505		POINTER HGT IND
37	123935X		"PLUG,HOLE"
38	17490512		SCREW
39	142992		STOP.OVER.CENTER
40	19112410		WASHER
41	123934X		HEIGHT INDICATOR
42	73680600		SUB= 73690600
43	19131612		WASHER GT
44	72240608		BOLT
46	12000022		E-RING
47	19292016		WASHER

# TRACTOR - - MODEL NUMBER AYP8186A59

## SEAT ASSEMBLY



Ref #	Part Number	Qty	Description
1	127429X		SUB= 140121
2	140551		BRACKET PVT SEAT
5	145006		CLIP.PUSH-IN.HING
7	124181X		SPRING COMPRESSIO
8	17490508		SCREW LT
9	19131614		WASHER
10	140552		SUB= 155925
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	121249X		SPACER SPLIT
16	123740X		SPRING COMPRESSED
17	123976X		SUB= 73900400
21	139888		BOLT.SHLD.5/16-18
22	73680500		SUB= 73690500
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER
27	17490608		SCREW LT
28	73680600		SUB= 73690600






Ref #	Part Number	Qty	Description
1	133741		SUB= 150547
2	142033		AXLE ASM FRONT
3	145410		SUB= 145410X431
4	145413		SUB= 145413X431
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	130468		SUB= 532130468
11	10040600		LOCKWASHER
12	73610600		SUB= 7810H
13	110438X		BEARING
14	74761060		BOLT LT
15	73901000		"NUT-LOC,FLANGE LT"
16	132624		AXLE PIN
17	128758		STEERING SHAFT
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71070410		"SCREW,SPECIAL"
23	127501		SUB= 918127501
24	109816X		NYLINER T
25	124036X		"BRKT,STEERING"
27	136874		GEAR SECTOR
29	17490612		SCREW
32	130467		TIE ROD
33	19111216		WASHER M
34	10040500		LOCKWASHER
35	73810500		NUT.LOCK.5/16-24
36	145207		BUSHING.STRG.3/4
37	17541008		SCREW.10-24X1/2
38	133742		ST WHL INSERT CAP
39	100712K		WASHER
40	73940800		SUB= 73360800
41	100711L		ADAPTER LT
43	121749X		WASHER
46	121232X		CAP
47	6855M		ZERK M
56	19131210		WASHER
58	17490508		SCREW LT
59	105663X		SUPPORT-SADDL T
60	105664X		SUPPORT.SADDLE.FT

# TRACTOR - - MODEL NUMBER AYP8186A59

## PEERLESS TRANSAXLE - MODEL NUMBER 820-016B





Ref #	Part Number	Qty	Description
	794513		TRANSAXLE, COMPLETE
1	772098A		COVER TRANSAXLE
2	780155		BEARING NEEDLE
3	770088		CASE TRANSAXLE
4	776291		SHAFT COUNTER
5	776275		SHAFT, OUTPUT, 9T
6	778247		GEAR, OUTPUT, 35T
7	778253		GEAR, SPUR, 15T
8	792138		KEY
9	784216		COLLAR SHIFT
10	784342		ROD AND FORK ASSY SHIFT
11	778246		GEAR BEVEL, 33T
12	778245		BEVEL PINION, 13T
13	778198		GEAR BEVEL
14	778197		PINION, 10T
15	778248		GEAR, RING, 31T
16	786027		BLOCK DRIVE
17	786019		PIN DRIVE
18	786121		SPACER, .350/.340 THICK
18A	786122		SPACER, .276/.268 THICK
20	792077		BALL STEEL, 5/16" DIA.
21	792078		SCREW, 3/8-16 X 3/8"
22	792079		SPRING
24	780071		THRUST BEARING
25	792129		SCREW HEX HD 5/16-18 X 1-1/4
25A	792073		SCREW, 1/4-20 X 1-1/4
26	792018		RING STRAP
27	792018		RING STRAP
28	788040		RETAINING RING
29	780072		WASHER THRUST
30	780108		WASHER THRUST
31	780128		WASHER THRUST
31A	780107		WASHER
31B	780042		WASHER THRUST
36	790043		DISK BRAKE
37	790007		PLATE BRAKE PAD
38	799021		BRAKE PAD
39	786026		PIN DOWEL
40	792076A		WASHER
41	790047		LEVER BRAKE
42	792073		SCREW, 1/4-20 X 1-1/4
42A	792085A		SCREW, 1/4-20 X 2-1/4
43	792075		LOCKNUT 5/16-24
44	790025		HOLDER BRAKE PAD
45	786067		SPACER
46	786086		BRKT BRAKE LEVER
47	774832		AXLE, 12-5/16" LONG
48	774831		AXLE, 16-3/16" LONG
49	778216A		GEAR, SPUR, 41T
50	778206A		GEAR, SPUR, 35T
51	778205A		GEAR, SPUR, 30T
52	778204A		GEAR, SPUR, 25T
53	778203A		GEAR, SPUR, 22T
54	778273		GEAR, SPUR, 19T
57	778199		GEAR, SPUR, 15T
58	778200		GEAR, SPUR, 20T
59	778201		GEAR, SPUR, 25T
60	778202		GEAR, SPUR, 28T

Ref #	Part Number	Qty	Description
61	778208		GEAR, SPUR, 31T
65	780139		WASHER
66	776274		SHAFT INPUT
67	776313		SHAFT BRAKE
71	788069		SEAL SQUARE CUT
71A	792145		PUSHNUT
72	792074		PLUG, THRDED, 9/16-18
79	792144		SPRING
81	786081		CHAIN, ROLLER
82	786082		SPROCKET 9T
83	786123		SPROCKET 18T (REV)
84	786131		BEARING CAP
87	788042		OIL SEAL 3/4
88	780119		BEARING BALL
89	780050		BEARING BALL
90	788067B		GREASE BENTONITE, 32 OZ.
96	780084		BEARING THRUST
97	780051		WASHER THRUST
98	780165		WASHER
99	788077		"O" RING
100	780166		WASHER CUPPED
101	774833		CARRIER DIFF THREADED HOLES
102	774834		CARRIER DIFF
103	792020		SCREW, 1/4-20 X 2-1/4
104	792006		WASHER LOCK 1/4
105	780153		WASHER
106	786144		SLEEVE
107	780152		BEARING NEEDLE
108	780150		BEARING NEEDLE
109	792001		"O" RING
110	786142		SLEEVE STEPPED
111	788071		RING SQ CUT
112	780168		BEARING NEEDLE CAPPED
113	786143		SLEEVE STEPPED
114	780151		BEARING NEEDLE CAPPED
115	786145		SLEEVE STEPPED
116	788070		RING SQ CUT
117	780031		BEARING NEEDLE
150	510334		GASKET ELIMINATOR