



## 12 HP 38" TRACTOR -- MODEL NUMBER AYP9120B49 BRAKE / REAR MOWER LIFT ASSEMBLY



Ref #	Part Number	Qty	Description
1	71673		PLUNGER CAP T
2	123436X		"ROD,PARK BRAKE"
3	123437X		"BRKT,PARK BRAKE"
4	8156H		FOOT PEDAL COVER
5	132205		BRK ASM CLUT LH
6	76020312		SUB= 3145
7	19131016		WASHER
8	17490508		SCREW LT
9	76020412		COTTER PIN
10	19131316		WASHER
11	123543X		"ROD,FRT BRAKE"
12	139934		PEDAL ASM CLU/BRK
13	123394X		"ROD,CLUTCH"
14	121978X		"BRKT,LIFT SHAFT"
15	133332		PVT BRAKE ARM ASM
16	19251816		WASHER T
17	12000034		KLIP RING
18	106888X		SPRING ROD LT
19	73350600		NUT
20	73800600		NUT
21	131460		SUB= 532131460
27	136780		LINK LIFT REAR LR
28	140777		LIFT.ASM.REAR.LR
29	72110506		SUB= 72270506
30	73510500		NUT
31	133095		COUNTER SPRING
32	133721		LINK LIFT LEVER
33	4939M		SUB= 85902

### 12 HP 38" TRACTOR -- MODEL NUMBER AYP9120B49

#### DASHBOARD






Ref #	Part Number	Qty	Description
1	141523		CAP BLK FUEL LR
2	138393		TANK.ASM.DASH.LR
3	123487X		HOSE CLAMP
4	8544R		SUB= 295J
5	8548R		FUEL LINE T
6	73510400		NUT
7	2751R		CLIP T
8	19091216		WASHER PM
17	72110404		BOLT
18	131886		SUPT ASM DASH
19	134744		CROSS BRACE
20	17060408		SCREW.1/4-20X1/2
21	134014		PLUG DOME



## 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

### DECALS




Ref #	Part Number	Qty	Description
1	138272		DECAL.INST.OPER
3	141493		DECAL STRIPE HOOD
4	141491		DECAL STRIPE HOOD
5	135073		DECAL
6	141496		DECAL CHASSIS
7	126860X		"DECAL,LIGHT BOX"
10	133796		DECAL
13	141497		DECAL.GRILLE
17	133870		NLA
19	127520		NLA
20	136832		DECAL
21	141495		DECAL.INST.HD.WIZ
	142197		MANUAL.O.9120B49



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49


## ELECTRICAL



Ref #	Part Number	Qty	Description
1	73510400		NUT
2	108423X		CABLE ASM.
3	133909		SUB= 123899X
5	108236X		BRACKET LT
6	109553X		SWITCH INTERLOCKT
7	104445X		SWITCH-INTER. GT
8	17021008		SCREW
9	140402		KEY STEEL DELTA
10	141226		COVER KEY SWITCH
11	140400		SUB= 145774
12	140399		SUB= 163088
15	121305X		SWITCH SEAT
17	108824X		FUSE HYT
18	128353		CABLE ASSY
19	143131		HARNESS IGNITION
20	73350400		NUT
21	10090400		SUB= 10040400
22	74780408		BOLT
24	131563		SUB= 154336
25	138406		SUB= 146154
26	74760412		BOLT LT
27	19091016		WASHER
28	10040400		LOCKWASHER
29	121264X		"CAP,BATTERY "
30	73220400		SUB= 50675
35	11050500		LOCKWASHER.5/16.E
36	11150400		LOCKWASHER
38	140660		ADAPTER.HARN.SERV
39	141735		BRACKET SWT CLUTC
55	17490508		SCREW LT
70	140413		HARNESS ENG DUAL



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49 BRIGGS & STRATTON ENGINE - MODEL NUMBER 282707, TYPE NUMBER 0113-01



Ref #	Part Number	Qty	Description
1	496414		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12A	271997		GASKET, CRANKCASE COVER .005"
12B	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	391285		PISTON ASSEMBLY, STANDARD
25A	391287		PISTON ASSEMBLY
25B	391288		PISTON ASSEMBLY
25C	391289		PISTON ASSEMBLY
26	391780		RING SET, PISTON, STANDARD
26A	392331		RING SET, PISTON, STANDARD SIZE
26B	391781		RING SET, PISTON .010" OVERSIZE
26C	391782		RING SET, PISTON .020" OVERSIZE
26D	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
29A	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	494553		KEEPER VALVE
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	270872		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT

Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
121	495799		IN CARBURETOR OVERHAUL KIT
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
142A	494499		HIGH ALTITUDE KIT
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
284A	94073		SCREW, HEX HEAD
304	496319		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309			REFER TO IMAGE
	394805		MOTER AND DRIVE ASSY.
	94003		BOLT
	395538		BRUSH ASSEMBLY
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	493944		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER

Ref #	Part Number	Qty	Description
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
468	222562		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	495878		STARTER DRIVE GROUP
523	495230		CAP AND DIPSTICK, OIL FILLER
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
537	281106		O-RING, AIR CLEANER
544	390837		ARRMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	493496		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	490324		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	224723		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
	394856		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
872	281104		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1005	280687		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD


Ref #	Part Number	Qty	Description
	398003		CLUTCH ASSEMBLY
	280104		GEAR, STARTER
	495877		RETAINER AND PIN
	94288		ROLL PIN



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## BRIGGS & STRATTON ENGINE - MODEL NUMBER 282707, TYPE NUMBER 0113-01

### 121 CARBURETOR OVERHAUL KIT



Ref #	Part Number	Qty	Description
1	496414		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12A	271997		GASKET, CRANKCASE COVER .005"
12B	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	391285		PISTON ASSEMBLY, STANDARD
25A	391287		PISTON ASSEMBLY
25B	391288		PISTON ASSEMBLY
25C	391289		PISTON ASSEMBLY
26	391780		RING SET, PISTON, STANDARD
26A	392331		RING SET, PISTON, STANDARD SIZE
26B	391781		RING SET, PISTON .010" OVERSIZE
26C	391782		RING SET, PISTON .020" OVERSIZE
26D	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
29A	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	494553		KEEPER VALVE
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	270872		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT



Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
121	495799		IN CARBURETOR OVERHAUL KIT
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
142A	494499		HIGH ALTITUDE KIT
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
284A	94073		SCREW, HEX HEAD
304	496319		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309			REFER TO IMAGE
	394805		MOTER AND DRIVE ASSY.
	94003		BOLT
	395538		BRUSH ASSEMBLY
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	493944		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER




Ref #	Part Number	Qty	Description
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
468	222562		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	495878		STARTER DRIVE GROUP
523	495230		CAP AND DIPSTICK, OIL FILLER
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
537	281106		O-RING, AIR CLEANER
544	390837		ARRMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	493496		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	490324		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	224723		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
	394856		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
872	281104		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1005	280687		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD

Ref #	Part Number	Qty	Description
	398003		CLUTCH ASSEMBLY
	280104		GEAR, STARTER
	495877		RETAINER AND PIN
	94288		ROLL PIN



**12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49**  
**BRIGGS & STRATTON ENGINE - MODEL NUMBER 282707, TYPE NUMBER 0113-01**



Reference Number	309	310	311	510	544	801	802	803
	Motor and Drive Ass'y.	Thru Bolt Assembly	Brush Assembly	Drive Assembly	Armature Assembly	Drive End Cap Assembly	End Cap Assy. Commutator	Housing Assembly
Briggs & Stratton								
12V								
Housing Length								
3-21/32"	394805	94003	365536	495878**	390897	394856	395537*	398159

\*Includes Brush Set  
 \*\*Includes #398003 Clutch Assembly (Ref. No. 513)  
 #280104 Gear (Ref. No. 783)  
 #495877 Retainer and Pin (Ref. No. 878)  
 #94289 Roll Pin (Ref. No. 896)

Ref #	Part Number	Qty	Description
1	496414		CYLINDER ASSY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5	494240		HEAD, CYLINDER
7	271866		GASKET, CYLINDER HEAD
8	495735		BREATHER ASSY
9	27803		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	280100		TUBE, BREATHER
12	271916		GASKET, CRANKCASE COVER 1/64"
12A	271997		GASKET, CRANKCASE COVER .005"
12B	271996		GASKET, CRANKCASE COVER .009"
13	94622		SCREW, CYLINDER HEAD 3"
15	94239		PLUG, OIL DRAIN
16	495162		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	494238		BASE, ENGINE
20	291675		SEAL, OIL
22	94624		SCREW, SEMS, BASE MOUNTING
23	492326		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	391285		PISTON ASSEMBLY, STANDARD
25A	391287		PISTON ASSEMBLY
25B	391288		PISTON ASSEMBLY
25C	391289		PISTON ASSEMBLY
26	391780		RING SET, PISTON, STANDARD
26A	392331		RING SET, PISTON, STANDARD SIZE
26B	391781		RING SET, PISTON .010" OVERSIZE
26C	391782		RING SET, PISTON .020" OVERSIZE
26D	391783		RING SET, PISTON .030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	490348		ROD ASSEMBLY, CONNECTING
29A	490469		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
32	94671		SCREW, CONNECTING ROD
33	262246		VALVE, EXHAUST
34	262247		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
37	224502		GUARD, FLYWHEEL
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	494553		KEEPER VALVE
45	262248		TAPPET-VALVE
46	212897		GEAR, CAM
51	272465		GASKET, CARBURETOR (CARBURETOR TO ELBOW)
52	270872		GASKET, CARBURETOR
53	94637		STUD, CARBURETOR MOUNTING
75	224061		WASHER, SPRING
78	94626		SCREW, SEMS
95	94098		SCREW, THROTTLE
98	495800		SCREW, IDLE SPEED
104	231789		PIN, FLOAT HINGE
105	231855		VALVE ASSY, INLET NEEDLE
106	231854		INLET VALVE SEAT

Ref #	Part Number	Qty	Description
108	224540		VALVE, CHOKE
118	494383		VALVE, NEEDLE
121	495799		IN CARBURETOR OVERHAUL KIT
123	94616		SCREW, ELBOW MOUNTING
125	495706		CARBURETOR ASSEMBLY
127			REFER TO IMAGE
130	224539		VALVE, THROTTLE
131	494379		SHAFT & LEVER, THROTTLE
133	494381		FLOAT, CARBURETOR
137	281165		GASKET, FLOAT BOWL
138	281164		WASHER, FLOAT BOWL SCREW
141	495931		SHAFT & LEVER, CHOKE
142	494537		NOZZLE/JET, CARBURETOR
142A	494499		HIGH ALTITUDE KIT
147	231794		PILOT, JET
164	213819		ELBOW, INTAKE
171	281051		P/N CONFLICT - CHECK WITH SUPPLIER
187	393815		HOSE (CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262767		LINK, GOVERNOR
209	260871		SPRING, GOVERNOR
216	262766		LINK, CHOKE
219	490815		GOVERNOR GEAR
222	495611		PLATE, GOVERNOR CONTROL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
224	94729		SCREW, SEMS, HEX HEAD
225	231058		CRANK, GOVERNOR
227	493935		LEVER ASSY, GOVERNOR
230	94742		WASHER, GOVERNOR CRANK, 1/4" I.D.
232	262785		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
265	221535		CLAMP
284	94704		SCREW, AIR CLEANER
284A	94073		SCREW, HEX HEAD
304	496319		HOUSING, BLOWER
305	94729		SCREW, SEMS, HEX HEAD
306	224545		SHIELD, CYLINDER
307	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
308	491490		COVER, CYLINDER HEAD
309			REFER TO IMAGE
	394805		MOTER AND DRIVE ASSY.
	94003		BOLT
	395538		BRUSH ASSEMBLY
333	492341		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	493944		PLUG, SPARK
346	93705		SUB= 69485
356	494328		WIRE, GROUND
358	494241		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
423	94073		SCREW, HEX HEAD
445	493909		CARTRIDGE, AIR CLEANER


Ref #	Part Number	Qty	Description
455	222561		CUP, SCREEN MOUNTING
467	493903		KNOB, AIR CLEANER
468	222562		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	495878		STARTER DRIVE GROUP
523	495230		CAP AND DIPSTICK, OIL FILLER
524	68838		SEAL, FILLER TUBE
525	496113		TUBE, OIL FILLER
537	281106		O-RING, AIR CLEANER
544	390837		ARRMATURE ASSEMBLY
552	231597		BUSHING, GOVERNOR CRANK, 1/4" I.D.
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
611	493496		ELBOW, FUEL PIPE
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
618	262803		SPRING, CHOKE RETURN
634	281168		SEAL, CHOKE SHAFT
634A	491323		SEAL, GOVERNOR
634B	398970		SEAL, THROTTLE SHAFT
635	66538		ELBOW, SPARK PLUG
646	224546		BRACE, AIR CLEANER
657	93496		SCREW, SEMS
663	94620		SCREW, HEX HEAD
668	280848		SPACER
726	392134		GEAR, RING
727	490324		COVER, STARTER
728	94627		SCREW, SEMS 3/4"
729	281159		CLIP, LEAD WIRE
729A	224723		RETAINER, WIRE
741	262932		GEAR, TIMING
757	213998		LINK, COUNTERWEIGHT
758	399891		COUNTERWEIGHT ASSY
759	298909		PIN ASSY, PISTON, STD
761	94593		SCREW, COUNTERWEIGHT
	394856		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	398159		HOUSING ASSEMBLY
842	270920		SEAL, OIL FILLER CAP
847	496415		P/N CONFLICT - CHECK WITH SUPPLIER
851	221798		TERMINAL, IGNITION CABLE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
872	281104		COVER, AIR CLEANER
875	494237		BODY, AIR CLEANER
877	393456		DIODE & CONNECTOR ASSY
955	94642		SCREW, FUEL BOWL
965	94010		LOCKNUT, AIR CLEANER MOUNTING
975	494378		BOWL ASSEMBLY, CARBURETOR
977	494385		CARBURETOR GASKET KIT
987	281166		SEAL, THROTTLE SHAFT
1005	280687		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1044	94673		SCREW, SHOULDER, HEX HEAD

Ref #	Part Number	Qty	Description
	398003		CLUTCH ASSEMBLY
	280104		GEAR, STARTER
	495877		RETAINER AND PIN
	94288		ROLL PIN




# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## ENGINE / THROTTLE






Ref #	Part Number	Qty	Description
1	17060408		SCREW.1/4-20X1/2
2	132752		"CONTROL,THROTTLE"
3			REFER TO IMAGE
4	71070512		SCREW
5	10040500		LOCKWASHER
6	125593X		SUB= 272293
8	121094X		BOLT T
9	19101216		WASHER
10	10040400		LOCKWASHER
11			CHECK WITH SUPPLIER
12	137437		MUFFLER
15	137180		SUB= 532137180
17	17490624		SCREW LT
23	11050600		LOCKWASHER



## 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49


### FENDER / CHASSIS




Ref #	Part Number	Qty	Description
1	129965		SUB= 156417
2	19132012		WASHER
3	17490612		SCREW
4	124181X		SPRING COMPRESSIO
5	127115X505		BTRY FENDER PLATE
6	109596X		HOSE CLAMP T
7	124144X		PAD FOOTREST
8	17490512		SCREW
9	126993X		CONSOLE SHFT 4SP
10	139783		PLATE LOCK SHIFT
11	124346X		NUT
12	140784		SUB= 145424
13	109238X		TUBE T
14	73800500		NUT
15	73510400		NUT
16	74760512		BOLT
17	140782		DRAWBAR ASM LR
18	126470X		"CLIP,INSULATOR"
19	140956X505		FENDER/FOOT MS505
20	19091413		WASHER
21	140297		BRACKET STOP DEPT
22	17490508		SCREW LT
23	72110506		SUB= 72270506
25	17490516		SCREW TI
31	141736		SUB= 146613

# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## FRONT AXLE




Ref #	Part Number	Qty	Description
1	121232X		CAP
2	12000029		RING
3	121748X		WASHER
4	3366R		COL. SRTG. BEAR.
5	142033		AXLE ASM FRONT
6	6266H		WASHER .T
7	137062		SPINDLE ASM RH
8	121749X		WASHER
9	76020412		COTTER PIN
10	19131316		WASHER
11	126847X		BUSHING.DRAGLINK
12	130465		TIE ROD
13	137061		SPINDLE ASM LH
14	74011056		BOLT HEX 5/8-11
15	73901000		"NUT-LOC,FLANGE LT"
16	110438X		BEARING
17	6855M		ZERK M
18	19272016		WASHER




# 12 HP 38" TRACTOR -- MODEL NUMBER AYP9120B49

## GROUND DRIVE




Ref #	Part Number	Qty	Description
1	73800500		NUT
2	74760512		BOLT
3	141341		KEEPER.BELT.FRT.
4	138029		PULLEY.ENGINE.LR
5	10040700		LOCKWASHER
6	71170744		HEX BOLT
7	124525X		BELT
8	123405X		"KEEPER,DRIVE BELT"
9	72140612		BOLT
10	123396X		"KEEP,IDLER DR BEL"
11	140911		ARM IDLER CLUT GD
12	123674X		PULLEY.IDLER.FLAT
13	19131316		WASHER
14	73930600		LOCKNUT
15	73800600		NUT
16	126472X		CLIP INSULATOR
17	122052X		SPACER RETAINER
18	131459		SUB= 532131459
19	73510500		NUT
20	139919		KEEPER.BELT.T/A
21	19111016		WASHER
22	123404X		"KEEPER,FRA DR BEL"
23	142240		KEEPER.BELT.FRT.L




## 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

### HOOD






Ref #	Part Number	Qty	Description
1	124657X		EXT SPRING
2	73510400		NUT
3	19091416		WASHER
4	74780412		SUB= 74780414
5	126675X		SUB= 139888
6	122549X		BRKT HOOD RH
7	122548X		BRKT HOOD LH
8	17521312		SCREW SLTD HXHD
9	73800400		NUT
10	123693X		"BRACE,HOOD"
11	132918X505		HOOD
12	122035X		LENS
13	127029X		GRILL
18	19111116		WASHER
19	11030400		LOCKWASHER GT
20	131319		SUB= 532131319



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## MOWER DECK




Ref #	Part Number	Qty	Description
1	142830		MOWER.WELD.LR.38
2	73800500		NUT
3	72140506		BOLT
4	7631J		RUNNER-LH M
5	110485X		BEARING
6	128774		HSG ASM MANDREL
7	129895		BEARING.BALL
8	137645		SUB= 137646
9	134148		"BLADE.38""V.MULCH"
10	140296		WASHER.HARD.BLADE
11	10030600		SUB= 10040600
12	850857		BLADE BOLT
13	140329		STRIPPER RND MWR
14	106736X		DEFLECTOR-SHLD T
15	106735X		ROD-HINGE T
16	137607		BRKT DEFLECTOR
17	110452X		NUT PUSH M
18	123713X		SPRING TORSION
19	19111016		WASHER
20	105304X		CAP-SLEEVE LT
21	128772		RUNNER RH
22	19111216		WASHER M
23	17580520		BOLT.5/16-18X1.25
24	4939M		SUB= 85902
25	74760620		SUB= 74780620
26	19131612		WASHER GT
27	139756		"LINK LIFT 38""
28	72140608		SUB= 72110608
29	139757		PLATE SLIDE LINK
30	73800600		NUT
31	140915		ROD.CLUTCH.PRIM
32	73350600		NUT
33	132559		SUSP ARM REAR
34	133604		TRUNNION
35	132554		CLUTCH ROD SEC
36	19131316		WASHER
37	76020312		SUB= 3145
38	133840		IDLER ARM ASSY
39	129963		WASHER
40	129206		SUB= 153532
41	137266		SUB= 139729
42	121316X		PULLEY IDLER
43	122052X		SPACER RETAINER
44	19131612		WASHER GT
45	73800600		NUT
46	126520X		V BELT
47	133502		RETAINER SPACER
48	133503		IDLER ARM STIFF
49	133551		PIVOT ROD
50	131289		BRAKE ROD LH
51	130840		BRAKE ASM
52	17490512		SCREW
53	131288		BRAKE ROD RH
54	72110614		BOLT
55	4921H		SPRING.RETAINER
56	136782		PLATE ADJ LINK LH
57	72140608		SUB= 72110608
58	19131212		WASHER T

Ref #	Part Number	Qty	Description
59	73800500		NUT
60	19111112		WASHER.34X.68X16
62	3146R		RETAINER.SPRING
63	4497H		RETAINER M
70	19162016		WASHER 1/2X1 1/4
71	19131610		WASHER PM
72	133943		HARDENED WASHER
	142862		"DECK.SERVICE.38""
	130794		MANDREL ASM




# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## MOWER LIFT LEVER





Ref #	Part Number	Qty	Description
1	126470X		"CLIP,INSULATOR"
2	122018X		BRKT CLUTCH
3	74780408		BOLT
4	73800600		NUT
5	132552		CLUTCH LEVER AS
6	106451X		"BOLT, SHOULDER LT"
7	141435		ARM.CLUTCH.ASM
8	74930624		BOLT
10	76020412		COTTER PIN
12	122027X		GRIP HANDLE
13	136658		LEVER LIFT LR
14	133939		COMP CLUTCH SPRNG
15	19131616		WASHER HYT
18	135107		TRUNNION
19	73680400		SUB= 73690400
20	74760644		BOLT
22	132561		LIFT LEVER BRKT
23	76020312		SUB= 3145
24	7672J		WASHER
25	121933X		TUBE SPACER
27	106932X		KNOB T(3/8 HOLE)
30	135039		ROD TENSION CLUTC
31	73930600		LOCKNUT
32	133435		SPRING EXT
33	62333		WASHER
34	73800500		NUT
35	133603		VINYL CAP RED
36	72140506		BOLT



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## SCHEMATIC



**IGNITION SWITCH**

POSITION	CIRCUIT
OFF	M + G
ON	B + L
START	B + S + L

**NOTE**

YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.


- NON-REMOVABLE CONNECTIONS
- REMOVABLE CONNECTIONS

**WIRING INSULATED CLIPS**

**NOTE:** IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.


# 12 HP 38" TRACTOR -- MODEL NUMBER AYP9120B49

## SEAT






Ref #	Part Number	Qty	Description
1	72050411		SUB= 872050411
2	134647		SUB= 140119
4	73800500		NUT
5	139888		BOLT.SHLD.5/16-18
6	140407		CLIP PUSH - IN
8	74760616		BOLT
9	140551		BRACKET PVT SEAT
11	19133210		WASHER
12	73800600		NUT
13	74780814		BOLT
14	10040800		LOCKWASHER
15	19171912		WASHER
16	127018X		"BOLT,SHOULDER"
18	123976X		SUB= 73900400
19	121248X		BUSHING
20	121250X		SPRING
21	134300		SPLIT SPACER
22	121246X		BRKT SWITCH
23	140552		SUB= 155925




# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## SECTOR GEAR / AXLE SUPPORT




Ref #	Part Number	Qty	Description
1	132566		DRAG LINK
2	74780828		"BOLT,HEX"
5	121926X		GEAR SECTOR
6	121927X		BUSHING
7	73030800		NUT
8	126472X		CLIP INSULATOR
9	73680800		NUT LTV
10	76020412		COTTER PIN
11	19131316		WASHER
12	126847X		BUSHING.DRAGLINK
13	74760512		BOLT
14	19111416		WASHER
15	72110606		BOLT
17	137096		SUPT AXLE FRONT
20	73800600		NUT
21	73800500		NUT



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## STEERING WHEEL




Ref #	Part Number	Qty	Description
1	133742		ST WHL INSERT CAP
2	7810H		GRIPCO NUT
3	19133808		WASHER T
4	133741		SUB= 150547
5	121897X		SLEEVE STEERING
6	17431008		SUB= 98000165
7	102803X		SUB= 918102803X
8	123651X		SUB= 148966
9	124210X		STEERING CLIP
10	123438X		BUSHING STEER LWR
11	12000045		RING
12	19211616		WASHER LT
13	104820X		ADAPTER-WHEEL LT




# 12 HP 38" TRACTOR -- MODEL NUMBER AYP9120B49

## TRANSAXLE




Ref #	Part Number	Qty	Description
1	123385X		PULLEY
2	12000028		SUB= 2267J
3	142594		SUB= 918142594
4	2228M		SUB= 2228M1
5	73800500		NUT
6	72140506		BOLT
7	123378X		"STRAP,TORQUE"
8	17490512		SCREW
9	110422X		SUB= 146682
10	121749X		WASHER
11	123583X		SQUARE KEY
12	74760644		BOLT
15	19171616		WASHER
16	124600X		"SUPT,HDLE SHT LH"
17	123632X		"LINK,SHIFT"
18	71040412		SUB= 74550412
19	10040400		LOCKWASHER
20	19091210		WASHER LT
21	123484X		ARM SHIFT
22	105701X		WASH-SHFT PLT LT
23	106933X		KNOB T (1/2-HOLE)
24	128215		"ROD,SHIFT"
25	76020416		PIN COTTER 1/8
26	73810500		NUT.LOCK.5/16-24
27	73510500		NUT
28	128085		"SPRING,EXT"
29	128084		"SUPT,HDLE RH"
31	109502X		SPACER LT
33	73800600		NUT
35	12000001		E-RING LT



# 12 HP 38" TRACTOR - - MODEL NUMBER AYP9120B49

## DANA TRANSAXLE - MODEL NUMBER 4360-77






Ref #	Part Number	Qty	Description
1	5305D		HOUSING, UPPER
2	1919		SCREW
3	5112		BALL, DETENT
4	3626		SPRING, DETENT
5	3623		SCREW, SET
6	4731		SHIFTER ASSEMBLY
7	5024		BOOT, SHIFTER
8	3847		LOCKNUT 5/16-24
9	5416		SEAL, OIL
10	1106		RING, RETAINING
11	4689		ASSY, KIT, SHIM .625 SHAFT
12	5415		BEARING, FLANGE
13	3876		WASHER, PLAIN .632 X 1.38 X .046
14	1746		KEY, WOODRUFF, #9
15	4551		ASSEMBLY, KIT, INPUT SHAFT
16	3590		PINION, BEVEL, 14 TEETH
17	3624		RING, RETAINING
18	3625		CHAIN, 24 PITCHES
19	1542		BEARING, FLANGE
20	5402		GEAR, SPUR, 14 TEETH
21	5303		COLLAR, CLUTCH
22	4758		ASSEMBLY, KIT, CLUTCH KEYS
23	5131		SCREW TAPPING WITH SEALER
24	5403		SHAFT, INTERMEDIATE
25	1375		KEY, WOODRUFF, #61
26	3627		RING, RETAINING
27	3830		SPROCKET, 18 TEETH
28	3841		SPACER
29	5365		GEAR, SPUR, 37 TEETH
30	3867		GEAR, SPUR, 30 TEETH
31	3783		GEAR, SPUR, 25 TEETH
32	5026		SPACER 1.133 X 1.50 X .750
33	3869		GEAR, SPUR, 22 TEETH
34	3724		SCREW TAPPING
35	3628		WASHER, PLAIN .640 X 1.37 X .061
36	1423		WASHER, PLAIN .632 X 1.00 X .026
37	3422		SPACER .630 X 1.00 X .169
38	4286		ASSY GEAR COMB 12&35 TEETH
39	3967		SHAFT, IDLER
40	3901		SPACER .635 X .875 X .755
41	3645		SPROCKET, 9 TEETH
42	3853		GEAR, BEVEL, 42 TEETH
43	4691		ASSY, KIT, SHIM .750 SHAFT
44	3882		SHAFT, DRIVE
45	5364		GEAR SPUR, 12 TEETH
46	3866		GEAR, SPUR, 20 TEETH
47	3719		GEAR, SPUR, 25 TEETH
48	3683		GEAR, SPUR, 31 TEETH
49	3684		SPACER .781 X 1.00 X .750
50	3907		PUCK, FRICTION
51	1145		WASHER, PLAIN .632 X 1.00 X .060
52	5130		WASHER, NEOPRENE
53	3184		WASHER, PLAIN .758 X 1.25 X .031
54	3880		AXLE LEFT HAND
55	3780		GEAR, MITER, 15 TEETH
56	3656		RING, RETAINING
57	3839		GEAR, SPUR, 32 TEETH
58	3919		SHAFT, CROSS

Ref #	Part Number	Qty	Description
59	3781		GEAR, MITER, 15 TEETH
60	3881		AXLE, R.H.
61	5304E		HOUSING, LOWER
62	3920		PUCK, FRICTION
63	3276		DISC, BRAKE
64	3758		SPACER
65	3916		JAW, BRAKE
66	3843		PIN, DOWEL
67	5120		SCREW, SELF-TAPPING
68	5285		LEVER ACTUATING
69	3760		WASHER, PLAIN .321 X 1.00 X .055
70	3917		BRACKET, ANTI-ROTATION
71	4300		GREASE



# WHEELS & TIRES



Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	278H		FITTING LT
4	124142X		SUB= 123410X
4A	124143X		SUB= 122075X
5	59904		TUBE.5.3/4.5/6
5A	8134H		TUBE.16X6.5/7.5-8
6	122394X427		SUB= 137237X427
6A	123412X427		"RIM REAR 8" WHITE"
7	104757X		HUB CAP
8	9040H		"FLANGE, BEARING"
9	121748X		WASHER

