


TRACTOR - - MODEL NUMBER AYP9167A59


CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
1	145501		CHASSIS.WLD.11GA
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
6	145206		SUB= 145206X431
8	126471X		"CLIP,INSULATOR"
9	140622		SUB= 532142467
10	72140608		SUB= 72110608
11	140311		PANEL ASM DASH
12	145660		CLIP.TINNERMAN
13	140178		SUB= 146959
14	17490608		SCREW LT
17	139394X418		HOOD.STL.PRIV.LB
20	145210		PLATE.MTG.BTRY.TK
23	124028X		SUB= 532124028
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
28	140141		SUB= 157373
29	140273		LENS GRILLE
30	140002X418		FENDER.YT/GT
31	137113		BRKT.ASM.FENDER
33	145244X418		FOOTREST.LT.LT/GT
34	145243X418		FOOTREST.RH.LT/GT
35	72110606		BOLT
37	17490512		SCREW
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
44	140675		STRAP ASM FENDER
47	105531X		NUT-PUSH YT
48	138096		RIVET.PUSH.PLATE
49	17490412		SCREW HEX CRT
50	142779		BRACE SUPT DASH
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	17030814		SUB= 91817030814
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	140806		DUCT AIR 12-15H
68	73510400		NUT

TRACTOR - - MODEL NUMBER AYP9167A59

DECALS




Ref #	Part Number	Qty	Description
1	140819		SUB= 156867
2	143470		DECAL STEER WHL
3	141579		DECAL HOOD RH
4	141580		DECAL HOOD LH
5	141517		DECAL DECK WIZ +
6	143388		NAMEPLATE.HD.WIZA
7	127520		NLA
8	133796		DECAL
9	4900J		DECAL T
10	143349		"DECAL.CHASSIS.42""
11	136832		DECAL
12	146698		DECAL.PNL.SIDE.VG
13	141583		DECAL DECK MULCH
14	145005		DECAL.BATRY.3-3908
15	131973		DECAL.ENG.805720
16	146615		DECAL.FENDER.WIZ
17	142336		DECAL SADLE HYDRO
18	142341		DECAL DRAWBAR LH
	138311		DECAL HANDLE LIFT
	133671		FOOTREST PAD
	146631		MANUAL.O.9167A59




TRACTOR - - MODEL NUMBER AYP9167A59

DRIVE




Ref #	Part Number	Qty	Description
1	144436		SUB= 150071
2	142431		SPRING RET BRAKE
3	143995		PULLEY.TRANSAXLE
8	141002		ROD SHIFT FEND YT
10	76020416		PIN COTTER 1/8
15	74780544		BOLT HEX
16	73800500		NUT
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	145627		ROD.BRAKE.HYDRO.
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	124236X		CAP
30	130807		TRANSAXLE MTG BKT
31	127275X		"KEEPER,BELT LH T"
32	74760512		BOLT
34	122424X		SUB= 149001
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	140294		"BELT.GD DRV 82""
58	140470		KEEPER BELT LH
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	129221		"MANUAL,OWNERS"
69	142432		SCREW HEXWSH H-L
70	134683		KEEPER BELT ENG
71	140158		STRAP TORQ LH HYD
72	19132012		WASHER
73	140157		STRAP TORQ RH HYD
74	121199X		SPACER SPLIT
75	121749X		WASHER
76	12000001		E-RING LT

Ref #	Part Number	Qty	Description
77	123583X		SQUARE KEY
78	121748X		WASHER
81	140154		SUB= 156046
82	123782X		"SPRING,TORSION"
83	19171216		WASHER
84	140548		ROD.TIE.BALL.4.75
86	71208		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	139989		SUB= 153762
91	74780536		NLA
92	74780524		HEX BOLT
93	142564		"LINE FUEL HYD 4""
94	140462		"FAN 7"" HYDRO"
95	144643		SUB= 918144643
96	4497H		RETAINER M
97	140469		BOLT KEEPER RH
98	73510600		NUT
100	19111216		WASHER M
102	141322		WASHER BELLEVILLE
103	73940800		SUB= 73360800
104	140156		ARM CONTROL HYDRO
105	71070516		SCREW CAP 5/16-18
106	74780520		BOLT



TRACTOR - - MODEL NUMBER AYP9167A59


ELECTRICAL



Ref #	Part Number	Qty	Description
1	144925		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	7697J		"DRAIN TU T, BATT"
8	7603J		"TRAY T, BATTERY"
9	109596X		HOSE CLAMP T
10	145211		SUB= 150177
11	145209		SUB= 150109
12	145769		SUB= 150177
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES, LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146148		CABLE.6GA.22W/16W
26	108824X		FUSE HYT
28	145491		CABLE.GRND.6GA.21
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
35	108236X		BRACKET LT
36	17021008		SCREW
38	140336		BRACKET SWITCH IN
39	109553X		SWITCH INTERLOCKT
40	146058		SUB= 151212
41	71110412		BOLT.HX.1/4-20
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73800400		NUT
45	122822X		AMMETER
46	141940		PROTECTION LOOP
55	17490508		SCREW LT
70	141861		HARNES.ENG.LT.

TRACTOR - - MODEL NUMBER AYP9167A59


ENGINE



Ref #	Part Number	Qty	Description
1	141295		CONTROL THRT 35.5
2	17720410		SCREW LT
3			REFER TO IMAGE
4	137978		SUB= 149723
5	122434X		TUBE ASSY EXH LH
6	122435X		TUBE ASSY EXH RH
7	2751R		CLIP T
8	122439X		BRACKET MUFFLER
9	17190408		SCREW ST
10	145552		SHIELD.HEAT.
11			CHECK WITH SUPPLIER
12			CHECK WITH SUPPLIER
13			CHECK WITH SUPPLIER
14	13280336		PIPE NIPPLE LT
15	13200300		ELBOW
16	11050600		LOCKWASHER
18	136718		SHIELD HEAT
19	105839X		RECEPTACLE LT
20	105838X		RETAINER LT
21	19091016		WASHER
22	123650X		STUD.1/4.TURN
23	128953		HEAT SHIELD
24	17021008		SCREW
25	145996		CONTROL.CHOKE.37
26	73610600		SUB= 7810H
29	137180		SUB= 532137180
30	127057X		SUB= 532127057
31	141069		SUB= 151346
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
34	106082X		PAD-SPACER LT
35	17490512		SCREW
36	19132012		WASHER
37	8543R		FUEL LINE T
38			CHECK WITH SUPPLIER
39	109227X		PAD IDLER TI
40	3645J		BUSHING OUTLET T
41	139227		SUB= 139277
78	17490620		SCREW
81	73510400		NUT

TRACTOR -- MODEL NUMBER AYP9167A59

BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 0332-01



★REQUIRES SPECIAL TOOLS TO INSTALL
SEE REPAIR INSTRUCTION MANUAL


Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807508		HEAD, CYLINDER #1
5.2	807510		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807622		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805360		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	305059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B			DECAL, OPEI
117			DECAL, OPEI
118	807707		VALVE ASSEMBLY, CARBURETOR IDLE
121	807962		CARBURETOR OVERHAUL KIT
122	805329		SPACER, CARBURETOR
125	807961		CARBURETOR, ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	807709		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			DECAL, OPEI
141	807711		SHAFT, CHOKE
147	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
353	92791		WASHERLOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807640		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS

Ref #	Part Number	Qty	Description
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	307663		BACK PLATE ASSEMBLY, BLACK
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE

Ref #	Part Number	Qty	Description
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT
879	805636		COVER, CARBURETOR
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	807716		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR

TRACTOR - - MODEL NUMBER AYP9167A59
BRIGGS & STRATTON ENGINE - MODEL NUMBER 303777, TYPE NUMBER 0332-01



Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807508		HEAD, CYLINDER #1
5.2	807510		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807622		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805360		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	305059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER





Ref #	Part Number	Qty	Description
116B			DECAL, OPEI
117			DECAL, OPEI
118	807707		VALVE ASSEMBLY, CARBURETOR IDLE
121	807962		CARBURETOR OVERHAUL KIT
122	805329		SPACER, CARBURETOR
125	807961		CARBURETOR, ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	807709		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			DECAL, OPEI
141	807711		SHAFT, CHOKE
147	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
353	92791		WASHERLOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807640		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS

Ref #	Part Number	Qty	Description
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	307663		BACK PLATE ASSEMBLY, BLACK
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE

Ref #	Part Number	Qty	Description
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT
879	805636		COVER, CARBURETOR
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	807716		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR

TRACTOR - - MODEL NUMBER AYP9167A59

BRIGGS & STRATTON ENGINE - - MODEL NUMBER 303777, TYPE NUMBER 0332-01



Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807508		HEAD, CYLINDER #1
5.2	807510		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807622		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805360		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	305059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B			DECAL, OPEI
117			DECAL, OPEI
118	807707		VALVE ASSEMBLY, CARBURETOR IDLE
121	807962		CARBURETOR OVERHAUL KIT
122	805329		SPACER, CARBURETOR
125	807961		CARBURETOR, ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	807709		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			DECAL, OPEI
141	807711		SHAFT, CHOKE
147	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
353	92791		WASHERLOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807640		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS

Ref #	Part Number	Qty	Description
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	307663		BACK PLATE ASSEMBLY, BLACK
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE

Ref #	Part Number	Qty	Description
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT
879	805636		COVER, CARBURETOR
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	807716		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR

TRACTOR - - MODEL NUMBER AYP9167A59


LIFT



Ref #	Part Number	Qty	Description
1	136973		WIRE ASM
2	140278		HANDLE.LIFT.LH.
3	138284		PIN GROOVE
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	125631X		GRIP HANDLE
8	122365X		SUB= 125925X
10	122512X		SUB= 532122512
11	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
21	19151216		WASHER
22	12000037		KLIP RING
12	110807X		NUT T
24	19131016		WASHER
25	2876H		SPRING T
26	76020308		SUB= 3145
27	126971X		SUB= 532126971
28	73350600		NUT
29	138057		KNOB INF 3/8-16
30	110810X		TRUNION LT
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8
33	140168		BRACKET STOP INF
34	17490608		SCREW LT
35	120529X		WASHER T
36	123933X505		POINTER HGT IND
37	123935X		"PLUG,HOLE"
38	17490512		SCREW
40	19112410		WASHER
41	123934X		HEIGHT INDICATOR

TRACTOR - - MODEL NUMBER AYP9167A59

MOWER DECK




Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	138776		SUB= 157722
31	129963		WASHER
32	129861		SUB= 153535
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	13351		ROD PIVOT W/NIBS
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	133940		SUB= 151785
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	140084		SUB= 151785
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	106933X		KNOB T (1/2-HOLE)
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND


Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	140179		LEVER ASM CLT PRM
79	127498		BUSHING
80	128759		SUB= 918128759
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	144394		SUB= 156084
85	72140620		BOLT
101	136420		"COVER.MULCH.42""
102	71161010		SCREW
103	19061216		WASHER #10
104	10071000		LOCKWASHER
105	130758		SUB= 160793
106	2029J		WELDNUT
111	140353		SUB= 155197
112	132262		SUB= 155198
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	137644		BOLT.SHOULDER
117	133957		WHEEL GAGE DONUT
118	73930600		LOCKNUT
119	19121414		WASHER
121	143723		BRACKET.EXTRD.GWL
	130794		MANDREL ASM
	145411		SUB= 164963

TRACTOR - - MODEL NUMBER AYP9167A59

SEAT ASSEMBLY




Ref #	Part Number	Qty	Description
1	127428		SUB= 140119
2	140551		BRACKET PVT SEAT
5	145006		CLIP.PUSH-IN.HING
7	124181X		SPRING COMPRESSIO
8	17490508		SCREW LT
9	19131614		WASHER
10	140552		SUB= 155925
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	139888		BOLT.SHLD.5/16-18
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER
27	17490608		SCREW LT
28	73680600		SUB= 73690600



TRACTOR - - MODEL NUMBER AYP9167A59


STEERING ASSEMBLY



Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	142033		AXLE ASM FRONT
3	135227		SPINDLE LH
4	135228		SPINDLE RH
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	130468		SUB= 532130468
11	10040600		LOCKWASHER
12	73610600		SUB= 7810H
13	110438X		BEARING
14	74011056		BOLT HEX 5/8-11
15	73901000		"NUT-LOC,FLANGE LT"
16	132624		AXLE PIN
17	140176		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71070410		"SCREW,SPECIAL"
23	127501		SUB= 918127501
24	109816X		NYLINER T
25	124036X		"BRKT,STEERING"
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	102803X		SUB= 918102803X
37	17431008		SUB= 98000165
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	104820X		ADAPTER-WHEEL LT
42	140216		BOOT SHAFT STEER
43	121749X		WASHER
44	140171		SHAFT EXT STEER
46	121232X		CAP
47	6855M		ZERK M
50	17490412		SCREW HEX CRT
51	73800500		NUT
54	74780520		BOLT
55	140285		CLIP TINNERMAN
57	140172		SUPPORT SHAFT STR

TRACTOR - - MODEL NUMBER AYP9167A59

TRANSAXLE HYDRO GEAR - MODEL NUMBER 310-0500




Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807508		HEAD, CYLINDER #1
5.2	807510		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807622		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805360		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	305059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER

Ref #	Part Number	Qty	Description
116B			DECAL, OPEI
117			DECAL, OPEI
118	807707		VALVE ASSEMBLY, CARBURETOR IDLE
121	807962		CARBURETOR OVERHAUL KIT
122	805329		SPACER, CARBURETOR
125	807961		CARBURETOR, ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	807709		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			DECAL, OPEI
141	807711		SHAFT, CHOKE
147	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
353	92791		WASHERLOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807640		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS

Ref #	Part Number	Qty	Description
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	307663		BACK PLATE ASSEMBLY, BLACK
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE

Ref #	Part Number	Qty	Description
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT
879	805636		COVER, CARBURETOR
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	807716		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR

TRACTOR - - MODEL NUMBER AYP9167A59
TRANSAXLE HYDRO GEAR - MODEL NUMBER 310-0750



Ref #	Part Number	Qty	Description
1	807511		CYLINDER ASSEMBLY
2	805107		BEARING, CYLINDER
3	805101		SEAL, OIL
5.1	807508		HEAD, CYLINDER #1
5.2	807510		HEAD, CYLINDER #2
6	805193		WASHER, CYLINDER HEAD
7	805111		GASKET, CYLINDER HEAD
8	807795		BREATHER ASSEMBLY
9	805379		GASKET, BREATHER
10	805751		SCREW
11	805362		TUBE, BREATHER
12	805112		GASKET, CRANKCASE COVER
13	805097		SCREW, CYLINDER HEAD
15	805048		PLUG, OIL DRAIN
16	807586		CRANKSHAFT
	94196		KEY, TIMING GEAR
	807625		WASHERS, THRUST
18	807638		COVER ASSEMBLY, CRANKCASE
20	805049		SEAL, OIL
22	805017		SCREW, CRANKCASE COVER
23	807531		FLYWHEEL MAGNETO
24	805016		KEY, FLYWHEEL
25	807619		PISTON ASSEMBLY, STANDARD
	807807		PISTON ASSEMBLY .010" OVERSIZE
	807809		PISTON ASSEMBLY .020" OVERSIZE
	807811		PISTON ASSEMBLY .030" OVERSIZE
26	807620		RING SET, PISTON, STANDARD
	807808		RING SET, PISTON .010" OVERSIZE
	807810		RING SET, PISTON .020" OVERSIZE
	807812		RING SET, PISTON .030" OVERSIZE
27	805099		LOCK, PISTON PIN
28	807621		PIN ASSEMBLY, PISTON, STANDARD
29	807622		ROD ASSEMBLY, CONNECTING
32	805395		SCREW, CONNECTING ROD
33	805089		VALVE, EXHAUST
34	805090		VALVE, INTAKE
35	805078		SPRING, VALVE
40	805092		RETAINER, VALVE SPRING
42	805161		RETAINER, VALVE
45	805354		TAPPET, VALVE
46	807542		GEAR, CAM
50	805409		MANIFOLD, INTAKE
51	805149		GASKET, CARBURETOR MOUNTING
52	805023		GASKET, INTAKE MANIFOLD
53	805360		SCREW, SEMS
54	805006		SCREW, SEMS
75	805007		WASHER, SPRING
78	805447		SCREW, SEMS
84	305059		PLUG, PIPE
87	805054		SEAL, GOVERNOR SHAFT
94	805777		NOZZLE, CARBURETOR
95	805561		SCREW, VALVE MOUNTING
98	807705		SCREW, THROTTLE ADJUSTING
104	805586		PIN, FLOAT HINGE
105	807706		VALVE, FUEL INLET
108	805562		VALVE, CHOKE
116	805058		O-RING, OIL PUMP
116A	805198		O-RING, CRANKCASE COVER


Ref #	Part Number	Qty	Description
116B			DECAL, OPEI
117			DECAL, OPEI
118	807707		VALVE ASSEMBLY, CARBURETOR IDLE
121	807962		CARBURETOR OVERHAUL KIT
122	805329		SPACER, CARBURETOR
125	807961		CARBURETOR, ASSEMBLY
127	805570		PLUG, WELCH
127A	805571		PLUG, WELCH
130	805572		VALVE, THROTTLE
131	807709		SHAFT, THROTTLE
133	807710		FLOAT ASSEMBLY, CARBURETOR
137			DECAL, OPEI
141	807711		SHAFT, CHOKE
147	807960		NOZZLE
156	805343		STUD, ROCKER ARM
161	807857		BASE ASSEMBLY, AIR CLEANER
166A	805073		STUD, OIL FILTER ADAPTER
167	805420		WASHER, VALVE COVER
171	805019		NUT, NYLOCK
187	393815		HOSE (CUT TO SUIT)
	296004		PIPE, FUEL
188	805247		SCREW, STARTER MOUNTING
189	805449		LOCK WASHER
192	807623		SCREW, VALVE ADJUSTMENT
201	805480		LINK, GOVERNOR
209	805462		SPRING, GOVERNOR
209A	805453		SPRING, GOVERNED IDLE
216	805439		LINK, CHOKE
222	807610		BRACKET, GOVERNOR CONTROL
227	807528		LEVER ASSEMBLY, GOVERNOR
232	805465		SPRING, GOVERNOR LINK
240	394358		FILTER, FUEL
243	805312		SCREEN, OIL
254	807713		DRAIN, CARBURETOR BOWL
265	221535		CLAMP
271	807609		BRACKET, CHOKE CONTROL
277	805018		WASHER
304	807899		HOUSING, BLOWER
305	805406		SCREW, SEMS
307	805025		SCREW, SEMS
308.1	807868		COVER, AIR GUIDE, CYLINDER #1
308.2	807869		COVER, AIR GUIDE, CYLINDER #2
309	399169		MOTOR, STARTING
310	94169		BOLT
311	490311		SCREEN ROTATING
324	280829		SCREEN, ROTATING
332	805021		NUT, HEX
333	492341		ARMATURE, MAGNETO
334	805407		SCREW, MOUNTING
337	491055		PLUG, SPARK
353	92791		WASHERLOCK
354	90576		NUT, HEX
354A	810078		NUT, HEX WASHER HEAD
356	493792		WIRE ASSEMBLY, GROUND
358	807640		GASKET SET
363	19203		PULLER, FLYWHEEL
387	491922		PUMP, FUEL
423	805260		SCREW, SEMS

Ref #	Part Number	Qty	Description
445	394018		CARTRIDGE, AIR CLEANER
467	491875		KNOB, AIR CLEANER
474	393295		STATOR, ALTERNATOR
501	394890		REGULATOR, ALTERNATOR
510	490421		STARTER DRIVE GROUP
513	398003		CLUTCH ASSEMBLY
520	93722		TERMINAL, SPADE
523	807516		DIPSTICK
524	805011		SEAL, FILLER TUBE
525	807611		TUBE, OIL FILLER
526	805448		SCREW, REGULATOR MOUNTING
527	223167		CLAMP, FUEL PUMP
535	271271		ELEMENT, AIR CLEANER
537	805655		GASKET, AIR CLEANER
544	490309		ARMATURE ASSEMBLY
552	805412		BUSHING, GOVERNOR SHAFT
552A	805413		BUSHING, GOVERNOR SHAFT
562	805381		BOLT
572	805197		BAFFLE, BREATHER
573	307663		BACK PLATE ASSEMBLY, BLACK
592	805383		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
613	805158		SCREW, SEMS
614	805417		PIN, COTTER
615	805578		RETAINER, CHOKE SHAFT
615A	805577		RETAINER, THROTTLE SHAFT
616	807596		FORK, GOVERNOR
634	805416		WASHER, GOVERNOR SHAFT
634A	805576		WASHER, THROTTLE
634B	805574		COLLAR, THROTTLE
634C	805580		COLLAR, CHOKE
635	805529		ELBOW, SPARK PLUG
642	807862		COVER ASSEMBLY, AIR CLEANER
643	805631		PLATE, AIR FILTER
657	805009		SCREW, SEMS
668	805402		SPACER, ROTATING SCREEN
718	805103		DOWEL, CRANKCASE
718A	805102		DOWEL, CYLINDER HEAD
722	805483		SEAL, BREATHER SCREW
726	807805		GEAR, FLYWHEEL RING
727	805505		SHIELD, STARTER
729	805641		GROMMET, IGNITION CABLE
741	805675		GEAR, TIMING
783	280104		GEAR, STARTER
788	807685		BRACKET, FUEL PUMP
801	394856		CAP, DRIVE
802	490310		CAP ASSEMBLY, COMMUTATOR END
803	398892		HOUSING ASSEMBLY
819	805057		SCREW, SEMS
823	805317		SCREW, MOUNTING
842	805012		O-RING
851	221798		TERMINAL, IGNITION CABLE
862	807859		BRACKET, AIR CLEANER
864	805083		LINER, EXHAUST PORT
866	805738		VALLEY, COVER, AIR GUIDE
868	805094		SEAL, VALVE GUIDE
869	805085		SEAT, INTAKE VALVE
870	805086		SEAT, EXHAUST VALVE

Ref #	Part Number	Qty	Description
871	805084		GUIDE, VALVE
876	490467		PINION SPRING KIT
879	805636		COVER, CARBURETOR
883	805024		GASKET, EXHAUST MANIFOLD
896	94288		ROLL PIN
947	807744		SOLENOID
955	807714		PLUG AND SEAL, CARBURETOR
975	807715		BOWL ASSEMBLY, FLOAT
977	807716		CARBURETOR GASKET SET
978	805250		GASKET, OIL FILTER ADAPTOR
982	805030		SCREW, SEMS
985	398525		INSULATOR ASSEMBLY
987	805575		SEAL, THROTTLE SHAFT
1003	490316		BRUSH SPRING SET
1004	805632		TUBE, AIR INLET
1013	805581		SEAL, CHOKE SHAFT
1014	807797		DEFLECTOR, BREATHER, A.C.
1022	805028		NUT, HEX
1023	805100		COVER, VALVE
	807665		COVER, VALVE
1024	807546		OIL PUMP ASSEMBLY
1025	805313		SLIDER, GOVERNOR
1026	805352		ROD, PUSH, INTAKE
	805617		ROD, PUSH, EXHAUST
1027	492932		FILTER, OIL
1028	805292		ADAPTER, OIL FILTER
1029	807557		ARM, ROCKER
1030	805342		SHAFT, ROCKER ARM
1031	805341		SUPPORT, ROCKER ARM
1033	807668		OVERHAUL KIT, VALVE
1036	807688		BREATHER GASKET SET
1037	807717		BALL, CHOKE LOCATOR

TRACTOR - - MODEL NUMBER AYP9167A59

WHEELS AND TIRES



NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	122082X		SUB= 918122082X
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP
	144334		SEALANT.TIRE 10 OZ. TUBE

