


ROPER LAWN TRACTOR-MODEL NUMBER LT110AR


DRIVE GROUP



Ref #	Part Number	Qty	Description
1	102485X		GUIDE, BELT - ENGINE PULLEY
3	100505C		GUIDE BELT PLY LT
4	102975X		NLA
6	19131312		WASHER
7	100640L		SPRING CLUTCH LT
8	72140620		BOLT
9	7835J		SUB= 674A308
10	7834J		SUB= 674A308
11	73680600		SUB= 73690600
12	102932X		IDLER.FLAT.GTV
13	74930644		BOLT
14	100837L		NLA
15	101383X		SPRING EXT LT
16	72240606		BOLT
17	19132012		WASHER
18	3926J		IDLER-FLAT LT
19	100681K		NLA
20	100682K		SUB= 4470J
21	100679L		ARM IDLER ASSY LT
22	74760656		BOLT
23	100677L		BRACKET SUPT LT
24	101278K		SPACER LT
25	76020412		COTTER PIN
26	100642K		LINK BELLCRANK
27	100502L		NLA
28	100613N		SUB= 136006
29	74760616		BOLT
31	17490612		SCREW
32	72140612		BOLT
33	74770720		SUB= 71130720
34	10040700		LOCKWASHER
35	73220600		NUT.HEX.3/8-16UNC
36	74760644		BOLT
37	101279K		SPACER SPLIT LTV
38	104777X		SUB= 140312

ROPER LAWN TRACTOR--MODEL NUMBER LT110AR



ELECTRICAL



Ref #	Part Number	Qty	Description
1	73490400		SUB= 146525
2	19091016		WASHER
3	102476X		SUB= 150109
4	72240460		BOLT
5	228J		SUB= 226J
6	7603J		"TRAY T, BATTERY"
7	104798X		NLA
8	100207K		CLIP GTV
9	4171R		CLIP T
10	7661J		HARNESS T
11	7662J		SUB= 4152J
12	100656K		SUB= 7697J
13	7192J		WIRE TIE
14	7755R		SWITCH T
15	2957J		"CABLE T, BATTERY"
16	4406R		SUB= STD365402
17	11151000		LOCKWASHER
18	3258J		CONDUIT NUT L
19	7552H		SUB= STD365410
20	2008J		SUB= 146154
21	4482J		LIGHT SWITCH T
23	7320R		NUT
24	5907J		SUB= 597J
26	719J		SUB= 154336
27	2955J		CABLE ASSY LT
30	17541208		NLA
31	2751R		CLIP T
32	6999R		SUB= 123487X
33	10090400		SUB= 10040400
34	73350400		NUT
35	74780408		BOLT
36	73510400		NUT
37	74760412		BOLT LT
39	73220400		SUB= 50675
40	11050400		LOCKWASHER
43	10040400		LOCKWASHER
45	6374R		FUSE-30 AMP
46	9433R		AMMETER T
47	6009J		SUB= 532131708
48	6952J		SUB= 10071000
49	6953J		NLA
50	6951J		NLA
51	102501X		SUB= 141940
52	235R		CLIPT
	101539X		SHEET INSTR LT
	104769X		OWNER'S MANUAL


ROPER LAWN TRACTOR-MODEL NUMBER LT110AR



ENCLOSURES




Ref #	Part Number	Qty	Description
2	104806X		NLA
3	104803X358		PANEL, SIDE
4	104642X		DECAL, DASH
5	104607X		SUB= 106099X
6	104783X		DASH ASSY LT
7	8497J		DECAL, INSTRUCTION
9	678H564		PLATE, SUPPORT BATTERY
10	104786X		SUPPORT ASSY LT
11	105037X		FOAM-STRIP LT
12	104643X		NLA
13	104624X		STRAP ASSY
14	104618X		SUB= 155013
15	104612X358		SUB= 150301X505
16	104613X		SUB= 147717
17	104617X		SUB= 106395X
18	104632X		SUPPORT-GRILL LT
19	104801X		NLA
20	104634X358		SUB= 105419X388
21	104633X		NLA
22	104644X		NLA
23	104626X		NLA
24	104804X358		SUB= 132636X505
25	101599X		NLA
26	100658N358		FOOTREST
27	102478X		CHASSIS
28	102481X		SUB= 145009
29	104808X		NLA
30	4910J		DECAL-CAUTION
31	102505X		NLA
32	100657N358		NLA
33	7192J		WIRE TIE
34	73680500		SUB= 73690500
35	2751R		CLIP T
36	104780X		NLA
39	1554J		SUB= 155108
40	104637X		NLA
42	104810X		NLA
43	2126J		SUB= 140119
44	677H779		SPRING SEAT
45	3407J358		FENDER
46	4900J		DECAL T
47	8022J		PLUG-DASH T
48	10090400		SUB= 10040400
49	73220400		SUB= 50675
50	74760612		SUB= 74780612
51	19131312		WASHER
52	73680600		SUB= 73690600
53	74760616		BOLT
54	19131316		WASHER
55	17211010		SCREW LT
56	104755X		"" J"" FASTENER LT"
57	17490612		SCREW
59	17490512		SCREW
60	7605J		BOLT T
61	19090816		WASHER
62	73680400		SUB= 73690400
63	74760620		SUB= 74780620
64	73510600		NUT


Ref #	Part Number	Qty	Description
65	17490608		SCREW LT
66	100663K		PIN SUSPENS. LTV
67	17490616		SCREW GTV
69	74780816		BOLT
70	10110800		SUB= 10040800
71	19171912		WASHER
72	17431008		SUB= 98000165
73	74780512		BOLT
74	73510500		NUT
75	677H778		NLA
76	74350512		BOLT LT
77	5479J		PLUG BUTTON T






Ref #	Part Number	Qty	Description
23	100662K		BOLT SHOULDER LTV
26	73680600		SUB= 73690600
38	17490620		SCREW
39	17490612		SCREW
40	72240606		BOLT
41	72140505		BOLT
42	73680500		SUB= 73690500
43	19111216		WASHER M
44	4939M		SUB= 85902
45	19171616		WASHER
46	72140506		BOLT







Ref #	Part Number	Qty	Description
10	17490516		SCREW TI
33	19111216		WASHER M
52	74760644		BOLT
53	73680600		SUB= 73690600
55	74760612		SUB= 74780612
58	17490512		SCREW



ROPER LAWN TRACTOR-MODEL NUMBER LT110AR


MOWER




Ref #	Part Number	Qty	Description
1	100670N		SUB= 106085X
2	104926X		SUB= 121687X
3	100671M		SUB= 106578X
4	100668L		SUPPORT PLATE LT
5	102669X		BELT KEEPER LT
6	100659L		BRACKET FRONT LTV
7	100675K		ROD BRAKE LTV
8	76020412		COTTER PIN
9	101992X		ROD BRAKE LTV
9A	1793H		ROLL PIN T
10	19131316		WASHER
11	73930600		LOCKNUT
12	100665L		BRACKET LIFT LTV
13	100674L		BRACKET PIVOT LTV
14	100672K		SPACER BRAKE LTV
15	100673L		BRACKET SUPT LTV
16	8417J		SUB= 128772
17	5846R		SUB= 110452X
18	100731K		ROD HINGE LTV
19	4672J		SUB= 137607
20	4897J		SPRING M
21	102512X		SUB= 127322X
22	78850		SUB= 85463
23	100662K		BOLT SHOULDER LTV
24	100661L		ARM SUSPENS. LTV
25	100660L		ARM SUSPENS. LTV
26	73680600		SUB= 73690600
27	100669K		SUB= 25036
28	74610624		BOLT.3/8-24X1-1/2
29	10040600		LOCKWASHER
30	19132012		WASHER
31	74760680		BOLT
32	72130624		BOLT
33	100836K		BRACKET GTV
34	100664L		CROSSBAR LTV
35	73220600		NUT.HEX.3/8-16UNC
36	100666M		SUB= 200236X
37	7631J		RUNNER-LH M
38	17490620		SCREW
39	17490612		SCREW
40	72240606		BOLT
41	72140505		BOLT
42	73680500		SUB= 73690500
43	19111216		WASHER M
44	4939M		SUB= 85902
45	19171616		WASHER
46	72140506		BOLT

Ref #	Part Number	Qty	Description
1	8883R		PEDAL COVER T
3	61159		KNOB
4	101336K		SUB= 132753
5	8504J		SUB= 9188504J
6	104800X		SUPPORT-TANK LT
7	3615J		SUB= 121280X
8	6999R		SUB= 123487X
9	7833R		HOSE T
10	253707		ENGINE-B&S
11	19131016		WASHER
12	101273M		MUFFLER LTV
13	1407J		SUB= 272293
14	105021X		NLA
15	13170300		SUB= 13240300
16	13090328		SUB= 13280328
17	13100300		SUB= 13200300
19	104910X		BAFFLE ASSY LT
20	102727X		"SPRING.EXT.8.5""
21	104598X		ROD ASSY-LEVER LT
23	74780560		NLA
24	101496X		SPACER LT
25	104790X		HANDLE-CLUTCH L
26	4617J		SUB= 532131861
27	104909X		CLIP-MUFFLER LT
28	10040400		LOCKWASHER
29	19292016		WASHER
31	104913X		"VERTICAL LT, BAFL"
33	17020806		SCREW
34	17490620		SCREW
35	100654K		SUB= 106662X
36	678H726		SUB= 8334J
37	1572H		SUB= 2882J
37A	100639C		NLA
38	2228M		SUB= 2228M1
39	74780408		BOLT
40	6417H		TURNBKL. M
40A	100653K		SUB= 106185X
41	102507X		SHAFT ASSY YTV
42	73350600		NUT
43	4939M		SUB= 85902
44	2895H		HANDLE GRIP T
45	8016J		SUB= 125925X
46	2876H		SPRING T
47	104597X		LEVER ASSY LT
48	104799X		BRACE-TANK LT
49	100734K		SUB= 138057
50	19131316		WASHER
51	104915X		SUB= 105037X
52	101326L		DEFLECTOR.222573
53	74780512		BOLT
54	73680500		SUB= 73690500
56	73680600		SUB= 73690600
57	100655K		LINK, LIFT
58	100735K		ROD ADJUST LT
70	74760620		SUB= 74780620
71	100644K		BUSHING LT
72	19121612		WASHER LT
73	8330H		KEY STD

Ref #	Part Number	Qty	Description
74	23180606		SCREW
84	101272K		TRUNION LT
85	19151216		WASHER
86	12000037		KLIP RING
88	17720408		SCREW
89	8680J		NLA
90	71673		PLUNGER CAP T
94	76020312		SUB= 3145
95	19252016		SUB= 121749X
99	12000029		RING




ROPER LAWN TRACTOR - MODEL NUMBER LT110AR STEERING, FRONT AXLE AND WHEELS



Ref #	Part Number	Qty	Description
1	100710L		INSERT-WHEEL LT
2	73360800		NUT
3	100712K		WASHER
4	100713N		SUB= 150547
4A	100711L		ADAPTER LT
6	12000029		RING
7	19252016		SUB= 121749X
8	9040H		"FLANGE, BEARING"
9	71651		SUB= 122073X
	4479R		SUB= 59904
10	105302X		NLA
11	65139		VALVE STEM LT
12	59192		VALVE CAP
13	102482X		AXLE ASSY YTV
14	74761052		NLA
15	100633L		NLA
16	73610500		NUT
17	10040500		LOCKWASHER
18	101005M		SUB= 100629K
19	9530R		SUB= 5142H
20	73681000		LOCKNUT M
21	10040600		LOCKWASHER
22	73610600		SUB= 7810H
23	100628N		DRAG LINK LTV
24	105008X		SHAFT ASSY LT
25	74580		SHAFT SPACER LT
26	71208		BUSHING
27	102531X		SUB= 110150X
28	4301J		GEAR-SECTOR T
29	2228M		SUB= 2228M1
30	19212016		WASHER D
31A	2882J		DRIVE PIN
32	6266H		WASHER .T
33	100627L		ROD STEERING LT
34	100630L		SPINDLE LH LTV
35	17490612		SCREW
36	6826J		TUBE T
37	156J		NLA
38	74930644		BOLT
39	73510600		NUT
40	3366R		COL. SRTG. BEAR.
41	104590X		DECAL - STEERING WHEEL
42	104757X		HUB CAP

**ROPER LAWN TRACTOR—MODEL NUMBER LT110AR
TRANSAXLE—PART NUMBER 102050X**




Ref #	Part Number	Qty	Description
1	4591J		KNOB
2	104999X		LEVER ASSY
3	3485J		CUP YTV
4	17490412		SCREW HEX CRT
5	4076J		SPRING - WAVE
6	3483J		SOCKET - LEVER, SHIFT
7	5544J		INSERT-SHIFT YT
8	74525		SWITCH
9	23180405		NLA
10	101918X		SPRING YTV
11	8127M		NLA
12	102055X		NLA
13	101908X		PLATE YTV
14	101909X		NLA
15	71011012		SCREW.HXHD.10-2
16	101913X		WASHER YTV
17	104995X		FORK - SHIFT, PRIMARY
18	101917X		PLT-SEPARATOR L
19	104997X		NLA
20	104996X		FORK-SHIFT YTV
21	101914X		NLA
22	101915X		NLA
23	3455J		BUSHING
24	3456J		WASHER
24A	101930X		WASHER YTV
24B	101931X		NLA
24C	101932X		WASHER YTV
24D	101933X		NLA
24E	101934X		NLA
24F	101935X		NLA
24G	101936X		NLA
25	6694J		GEAR-SPUR 13T Y
26	101088C		NLA
27	101942X		NLA
28	3474J		GEAR - SPUR, 27T
29	105072X		NLA
30	3473J		GEAR - SPUR, 37T
31	105071X		NLA
32	101087C		NLA
33	101930X		WASHER YTV
34	5389R		NLA
35	102364X		NLA
36	4325M		KEY YTV
37	3471J		KEY YTV
38	2228M		SUB= 2228M1
39	12000040		KLIP RING
40	1370H		"T, BEARING"
41	101907X		NLA
42	101085M		NLA
43	102054X		NLA
44	3431J		SHAFT - IDLER, REVERSE
45	17541020		SCREW YTV
46	3841J		BUSHING
47	4528J		NLA
48	76020206		SUB= 76020216
49	102052X		GEAR ASSY YTV
50	104568X		NLA
51	12000047		NLA

Ref #	Part Number	Qty	Description
52	104434X		NLA
53	101089D		GEAR LT
54	12000042		NLA
55	102051X		NLA
56	101083D		NLA
57	101929X		NLA
58	101090C		GEAR YTV
59	6691J		GEAR YTV
60	105212X		NLA
61	101922X		NLA
62	101921X		GEAR YTV
63	101927X		SHAFT PRIMARY Y
64	101084D		NLA
65	101925X		NLA
66	3452J		GEAR YTV
67	101924X		SHAFT YTV
68	105213X		AXLE RH
69	101946X		DISC YTV
70	101923X		NLA
71	101943X		NLA
72	17490420		SCREW YTV
73	3492J		PAD-BRAKE YTV
74	3491J		SHIM - BRAKE, HARDENED
75	3836J		PLATE, BEARING
76	7177J		NLA
77	3835J		CALIPER - BRAKE
78	23210806		SCREW
79	677A604		NLA
80	3487J		BOLT - SHOULDER
81	101086M		NLA
82	101948X		DISC-BRAKE YTV
83	101937X		NLA
84	102881X		LUBRICANT YTV
85	106138X		SUB= 150700
86	3807J		T NUT
87	101419X		CLAMP LT

ROPER LAWN TRACTOR-MODEL NUMBER LT110AR

TRANSAXLE AND REAR WHEEL



Ref #	Part Number	Qty	Description
1	71652		SUB= 106108X427
2	71653		SUB= 122074X
	7152J		TUBE.18X9.5-8
3	2935J		WHEEL SPACER LT
4	2703J		SUB= 123583X
5	102050X		NLA
6	1642J		BELT SNUBBER T
7	104773X		NLA
8	104771X		RETAINER, BELT
9	76020412		COTTER PIN
20	101319L		NLA
21	102506X		SUB= 105968X
22	19131316		WASHER
30	678H480		STRAP - TORQUE
31	104778X		SUB= 144200
32	678H479		SUB= 109167X
34	12000040		KLIP RING
35	19252016		SUB= 121749X
36	2228M		SUB= 2228M1
37	104902X		PULLEY-INPUT LT
38	59192		VALVE CAP
39	65139		VALVE STEM LT
41	12000001		E-RING LT
73	5320R		INSUL CLIP T
74	104797X		NLA

