


### ROPER LAWN TRACTOR--MODEL NUMBER LT120BR

#### ELECTRICAL



Ref #	Part Number	Qty	Description
1	73490400		SUB= 146525
2	19091016		WASHER
3	105371X		SUB= 150109
4	72240460		BOLT
5	228J		SUB= 226J
6	105372X		"TRAY, BATTERY LT"
7	120130X		HARNESS T
10	110859X		HARNESS T
11	7662J		SUB= 4152J
12	7604J		SUB= 7697J
13	7192J		WIRE TIE
14	109553X		SWITCH INTERLOCKT
15	2957J		"CABLE T, BATTERY"
16	4406R		SUB= STD365402
18	109787X		SUB= 147626
19	109434X		KEY MOLDED
20	109081X		SUB= 146154
21	110712X		SWITCH LT
22	73680400		SUB= 73690400
23	4171R		CLIP T
24	5907J		SUB= 597J
26	719J		SUB= 154336
27	2955J		CABLE ASSY LT
30	74681008		SCREW
32	109596X		HOSE CLAMP T
33	10090400		SUB= 10040400
34	73350400		NUT
35	74780408		BOLT
36	73510400		NUT
37	74760412		BOLT LT
39	73220400		SUB= 50675
40	11050400		LOCKWASHER
43	10040400		LOCKWASHER
45	108824X		FUSE HYT
46	9433R		AMMETER T
47	6009J		SUB= 532131708
48	10101000		SUB= 10071000
49	73911000		NUT
50	19070818		WASHER
51	102501X		SUB= 141940
52	235R		CLIPT
53	11030400		LOCKWASHER GT
54	104445X		SWITCH-INTER. GT
56	71021008		SUB= 71031008
57	73951000		"NUT,KEPS"
58	109787X		SUB= 147626
59	121064X		SWITCH T
	101539X		SHEET INSTR LT
	110667X		NLA