


# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR - MODEL NO. PP125H38B

### SCHEMATIC




# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### ELECTRICAL



Der Ersatzteilspezialist im Internet.

# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### ELECTRICAL

KEY PART NO.	KEY PART NO.	DESCRIPTION	KEY PART NO.	DESCRIPTION
1	532123198	Nut, Wing 1/4-20	23	532109748 Relay
2	819091016	Washer 9/32 x 5/8 x 16 Ga.	24	532124996 Clip
3	532102476	Guard, Terminal	25	532109596 Clamp, Hose
4	872240460	Bolt , Battery (Bolt, Carriage 1/4-20 x 7-1/2)	26	810090400 Washer, Lock 1/4
5	532121265	Battery	27	873350400 Nut, Hex, Jam 1/4-20
6	532124886	Tray, Battery	28	874780408 Bolt, Hex 1/4-20 x 1/2 Grade 5
7	532132671	Harness, Ignition	29	873510400 Nut, Hex, Keps 1/4-20
8	532127441	Harness, Light Socket	30	874760412 Bolt, Hex 1/4-20 x 3/4
9	532124893	Bulb, Light	31	873220400 Nut, Hex 1/4-20
10	532100541	Tube, Battery Tray	32	811050400 Washer, Lock, Tooth, External 1/4
11	532124756	Cable, Tie	33	810040400 Washer, Lock 1/4
12	532109553	Switch, Interlock, Clutch	34	532108824 Fuse
13	532124770	Cable, Battery	35	532124900 Ammeter
14	532125104	Ignition, Switch	36	532131708 Bracket, Ammeter
15	532124211	Nut, Ignition	37	810101000 Washer, Lock #10
16	532122147	Key	38	873911000 Nut
17	532109081	Solenoid	39	819070818 Washer 7/32 x 1/2 x 18 Gauge
18	532110712	Switch	40	532102501 Loop, Wire
19	873680400	Nut, Crownlock 1/4-20	41	532124995 Clip, Insulated
20	532131563	Terminal Cover (For Solenoid)	42	532124932 Nut, Hex
21	532124773	Cable, Battery (Battery to Ground)	43	532126016 Switch, PTO
22	817021008	Screw, Hex Tap Hd. #10-24 UNC x 1/2 Type T	44	532123620 Cover, Switch Key
			45	532121305 Switch, Seat
			46	532121264 Cap, Battery


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### CHASSIS AND ENCLOSURES



Der Ersatzteilspezialist im Internet.

# REPAIR PARTS


www.ersatzteil-service.de

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### CHASSIS AND ENCLOSURES

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532127514	Seat	55	532106965	Plate, Support, Battery
2	532131451	Pan, Seat	56	532123198	Nut, Wing 1/4-20
3	532126656	Bracket, Pivot, Seat	57	532125367	Panel, Side, R.H.
4	819091216	Washer 9/32 x 3/4 x 16 Gauge	58	532122100	Grill
5	532124998	Fender	59	532106395	Lens
7	532124392	Bezel Assembly	60	532104755	"J" Fastener
8	817211010	Screw, Hex, Washer, Tap #10-16 x 5/8	62	819131614	Washer 13/32 x 1 x 14 Gauge
9	532105511	Strap, Fender	63	532110855	Bracket, Pivot, L.H.
10	532124181	Spring, Compression	64	532110854	Bracket, Pivot, R.H.
11	532105531	Nut, Push	65	532105529	Bolt, Shoulder 5/16-18
12	532105509	Bracket, Fender	66	873680500	Nut, Crownlock 5/16-18
13	532106082	Pad, Spacer	67	811050600	Washer, Lock, External Tooth 3/8
14	532123549	Cap, Fuel	68	532124978	Strap, Grill
15	532106020	Tank, Fuel	69	819171912	Washer 17/32 x 1-3/16 x 12 Gauge
16	532124952	Bushing	70	873680600	Nut, Crownlock 3/8-16
17	532124951	Stem, Tank, Fuel	71	817490608	Screw, Hex, Washer Thrdol. 3/8-16 x 1/2
18	532123487	Clamp, Hose	72	817490612	Screw, Hex, Washer Thrdol. 3/8-16 x 3/4
19	532124953	Line, Fuel	73	532120068	Knob, Seat 1/2"
20	873951000	Nut, Keps #10	74	872110606	Bolt, Carriage 3/8-16 x 3/4
21	532124118	Panel, Dash, L.H.	75	817021008	Screw, Hex, Tap #10-24 x 1/2
22	874641008	Screw, Pan Head #10-32	76	874760616	Bolt, Hex 3/8-16 x 1
23	532123740	Spring, Compression	77	532121794	Cover, Access
24	532124888	Footrest, L.H.	78	532110852	Bracket Assembly, L.H.
25	532121251	Strip, Foam	79	873510400	Nut, Hex, Keps 1/4-20 UNC
26	872050411	Bolt, Carriage 1/4-20 x 1-1/4	80	873510500	Nut, Hex, Keps 5/16-18 UNC
27	532133671	Pad, Footrest	81	873220400	Nut, Hex, Fin 1/4-20 UNC
28	532127866	Drawbar	82	874760532	Bolt, Hex 5/16-18 x 2
29	532121249	Spacer, Split .28 x .88	83	873510500	Nut, Keps 5/16-18
30	874180512	Screw, Mach. Cr. Threaded 5/16-18 x 3/4	84	532110853	Bracket Assembly, R.H.
31	532135034	Chassis	85	532121236	Spacer
32	532124889	Footrest, R.H.	86	532127018	Bolt, Shoulder 5/16-18 x .62
33	532133748	Panel, Dash, R.H.	87	532124996	Clip, Insulated
34	532124967	Clip, Insulated	88	532123481	Bolt, Shoulder 1/4-20
35	532110436	Grommet, Split	89	873680400	Nut, Crownlock 1/4-20
36	532124934	Grommet	90	874191008	Screw, Pan, Mach. #10-24 x 1/2
37	532124766	Saddle	91	810071000	Washer, Lock #10
38	532124720	Bushing, Steering	92	819111116	Washer 11/32 x 11/16 x 16 Gauge
39	532121246	Bracket, Switch Mount	93	819131312	Washer 13/32 x 13/16 x 12 Gauge
40	532104805	Dash Assembly, Lower	94	819111212	Washer 11/32 x 3/4 x 12 Gauge
41	532124252	Dash	96	874760612	Bolt, Hex 3/8-16 x 3/4
42	532125004	Nut, Weld	97	874981020	Screw, Mach. Cr. Pan #10-24 x 1-1/4
43	532124769	Plate, Dash	98	532109808	Latch, Hood
44	532123976	Locknut, Hex, Large, Flange	99	873731000	Nut, Keps #10-24
45	532121248	Bushing, Snap	100	532007206	Spacer, Split #10 x 3/4
46	532125353	Panel, Side, L.H.	101	819070818	Washer 7/32 x 1/2 x 18 Gauge
47	817190412	Screw, Hex, Washer Thrdcut 1/4-20 x 3/4	102	819091016	Washer 9/32 x 5/8 x 16 Gauge
48	817490512	Screw, Hex, Washer Thrdol. 5/16-18 x 3/4	104	532128953	Shield, Heat, Muffler
49	811050400	Washer, Lock, External Tooth 1/4	105	532131127	Cable Tie
50	532106784	Strap Assembly, Hinge, Rear	110	532134618	Bracket Asm., Pivot LH
51	532104618	Strap Assembly, Hinge, Front	111	532134617	Bracket Asm., Pivot RH
52	532125351	Hood	112	872140506	Bolt, Rdhd Sqnk 3/8 - 16 x 3/4
53	532005479	Plug, Button	113	817431008	Screw Hex Tap #10-16 x 1/2
54	532124130	Support, Dash			


NOTE: All component dimensions given in U.S. inches  
1 inch = 25.4 mm



# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### DRIVE



- |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| A  | B  | C  | D  | E  | F  | G  | H  | I  | J  | K  | M  | N  |
| 65 | 66 | 66 | 53 | 68 | 72 | 69 | 43 | 7  | 81 | 11 | 82 | 69 |
|    |    | 67 |    | 53 |    | 38 |    | 19 |    | 10 | 83 | 88 |
|    |    |    |    |    |    | 53 |    |    |    |    | 84 | 53 |
|    |    |    |    |    |    |    |    |    |    |    | 85 |    |

# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### DRIVE


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532125610	Muffler	45	532132654	Rod, Brake
2	532124788	Clip, Hairpin	46	532124872	Cover, Pedal
3	-----	Engine, Briggs & Stratton Model #286707	47	532120183	Bearing, Nylon
4	873350600	Nut, Hex, Jam 3/8-16 UNC	48	532122424	Shaft, Assembly, Foot Pedal
6	-----	Oil Drain Plug (Order from manufacturer)	49	532124963	Pin, Roll 3/16 x 1
7	871070510	Screw, Hex, Hd Cap 5/16-18 x 5/8	50	532071673	Cap, Plunger
8	532125593	Gasket	51	532133261	Rod, Brake, Park
9	819131316	Washer 13/32 x 13/16 x 16 Gauge	52	532105710	Link, Clutch
10	873680500	Nut, Crownlock 5/16-18	53	873680600	Nut, Crownlock 3/8-16
11	872140506	Bolt, Carriage 5/16-18 x 3/4	54	532123205	Retainer, Belt
12	532132765	Control, Throttle	55	812000039	Ring, Klip
14	532123461	V-Belt, Drive	56	532110812	Washer, Hardened
15	532124996	Clip, Insulated	57	532123789	Arm Assembly, Idler
16	532121187	Bracket, Mounting, Hydro T/A	58	532105709	Spring, Return, Clutch
17	532126649	Bracket, Transaxle	59	532108236	Bracket, Switch
18	532123583	Key, Square 1/4 x 2	60	874760624	Bolt, Hex 3/8-16 x 1-1/2
19	810040500	Washer, Lock, Heavy Helical Spring	61	532127783	Pulley, Idler V.Grove
20	532121189	U-Bolt 3/8-16 x 2.83	62	532105706	Bearing
21	532121199	Spacer, Split	63	819211616	Washer 21/32 x 1 x 16 Gauge
22	532121748	Washer 1-1/32 x 1-5/8 x 16 Gauge	64	873800600	Locknut, Hex W/Washer Insert 3/8-16 UNC ZN
23	532124723	Rim, Rear	65	817720410	Screw, Hex, Thread Cut 1/4-20 x 5/8
24	812000001	E-Ring	66	817490624	Screw, Hex, Wsh. Thdrol. 3/8-16 x 1-1/2
25	532104757	Cap, Axle	67	811050600	Washer, Lock, External Tooth 3/8
27	532065139	Stem, Valve	68	874760612	Bolt, Hex 3/8-16 x 3/4
28	532059192	Cap, Valve	69	874760616	Bolt, Hex 3/8-16 x 1
29	871170768	Bolt, Hex, Fin 7/16-20 UNF x 4-1/4 Grade 5	70	532124926	Tube
31	810040700	Washer, Lock 7/16	71	876020412	Pin, Cotter 1/8 x 3/4
32	532108218	Clutch, Engine	72	817490612	Screw, Hex, Thrdrol. 3/8-16 x 3/4
33	532109841	Pulley, Engine	73	532106268	Tire, Rear
34	532110422	Spring, Brake Return	77	813280324	Nipple, Pipe 3/8 NPT x 3"
35	874760644	Bolt, Hex 3/8-16 x 2-3/4	79	813200300	Elbow, Std. 90°, 3/8-18 NPT
36	532123674	Idler, Flat	80	532101326	Deflector, Muffler
37	532124965	Spacer	81	817030808	Screw, Spiderloc Hex Hd 8 x 1/2
38	819131312	Washer 13/32 x 13/16 x 12 Gauge	82	874760416	Bolt, Fin Hex 1/4-20 x 1
39	532109070	Retainer, Belt	83	810040400	Washer, Lock Hvy Helical 1/4
41	532109169	Retainer, Clutch Assembly	84	819091016	Washer 9/32 x 5/8 x 16 Ga.
42	532129921	Keeper, Belt, Engine	85	873220500	Nut, Fin Hex 5/16-18
43	817021008	Screw, Hex, Tap #10-24 x 1/2	86	532126197	Washer 1-1/2 x 15/32 x .250
44	532106888	Spring, Rod, Brake	87	532134683	Guide, Belt, Mower Drive RH
			88	819132012	Washer 13/32 x 1-1/4 x 12 Ga.
			89	532121749	Washer 25/32 x 1-1/4 x 16 Ga.

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### STEERING AND FRONT AXLE





# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### STEERING AND FRONT AXLE


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532057079	Washer	54	532124937	Bearing
2	532126805	Insert, Steering Wheel	55	873601000	Locknut, Flange 5/8-11
3	873940800	Nut, Toplock, Jam 1/2-20	56	532133988	Axle, Front
4	532100712	Washer	57	532135228	Spindle, R.H.
5	532121472	Wheel, Steering	58	532124957	Fitting, Grease
6	532100711	Adapter, Steering Wheel	59	532065139	Stem, Valve
7	810040400	Washer, Lock 1/4	60	532059192	Cap, Valve
8	871070410	Screw, Hex, Socket 1/4-20 x 5/8	61	532124959	Bearing
9	532124961	Spring, Retainer	62	532124801	Rim, Front
10	532102670	Spring, Compression	63	532106222	Tire, Front
12	873610600	Nut, Hex, Fin 3/8-24 UNF	64	873800600	Locknut, Hex w/Washer Insert 3/8-16 UNC
13	532104757	Cap, Axle	65	532108212	Trunnion
14	532121274	Knob, Gearshift	66	532121750	Rod, Control, Adjustable
15	532110845	Rod, Control	67	532124788	Clip, Hairpin
16	532121631	Spring, Torsion	68	532059904	Tube (Optional, Service Part)
17	532108196	Bracket, Control Rod	72	532123186	Bracket, Chassis, Reinforcement, Hydro
18	532128762	Shaft, Steering	73	532124836	Fitting, Grease
20	532124035	Support, Shaft	74	532121748	Washer 25/32 x 1-5/8 x 16 Gauge
21	532126684	Washer, Shim 1/4 x 5/8 x .062	78	532109816	Nyliner, Snap In
22	532124036	Bracket, Steering	81	819131212	Washer 13/32 x 3/4 x 12 Gauge
24	812000029	Ring, Klip	82	532121749	Washer 25/32 x 1-1/4 x 16 Gauge
25	532124931	Bearing, Thrust	83	819111216	Washer 11/32 x 3/4 x 16 Gauge
26	532127501	Shaft, Pitman	84	819151516	Washer 15/32 x 15/16 x 16 Gauge
27	532108972	Washer, Phenolic	85	532110739	Washer, Spring
28	532124034	Gear, Sector	86	532121232	Cap, Spindle
30	876020412	Pin, Cotter 1/8 x 3/4	87	532121217	Guide, Control
31	873680600	Nut, Crownlock 3/8-16	88	532121216	Bracket Control Guide
32	532108200	Washer, Friction	89	817490512	Screw, Hex, Washer Thrdrol. 5/16-18 x 3/4 Type TT
33	817490612	Screw, Hex, Washer Thrdrol. 3/8-16 x 3/4	90	817021010	Screw, Hex, Tap #10-24 UNC x .625
34	532108518	Bolt, Hex, Shoulder 3/8-16 x 1-3/8	91	819070816	Washer 7/32 x 1/2 x 16 Gauge
35	819212016	Washer 21/32 x 1-1/4 x 16 Gauge	92	874561014	Screw, Hex, Socket Head #10-24 UNC
36	532108201	Spacer	93	532069180	Locknut #10-24 UNC
37	532121202	Link, Control, Pump	94	532121204	Bellcrank
38	532108844	Spring, Compression	95	532121206	Bracket, Bellcrank Pivot
39	819132012	Washer 13/32 x 1-1/4 x 12 Gauge	96	532100536	Bolt, Shoulder
40	874760648	Bolt, Hex 3/8-16 x 3	97	874760616	Bolt, Hex, Fin 3/8-16 UNC x 1
41	532121209	Lever, Pump Control	98	873680500	Nut, Crownlock 3/8-16 UNC x 1
43	874011056	Bolt, Hex 5/8-11 x 3-1/2	99	532121190	Keeper, Centerspan
45	532130468	Link, Drag	100	532132624	Pin, Axle
46	810040600	Washer, Lock 3/8			
47	810040500	Washer, Lock 5/16			
48	532130467	Rod, Tie			
49	873810500	Nut, Hex 5/16-24 UNF			
50	532135227	Spindle, L.H.			
51	819272016	Washer 27/32 x 1-1/4 x 16 Gauge			
52	532110438	Spacer, Bearing			

NOTE: All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR -- MODEL NUMBER PP125H38B

### 38" MOWER



# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - - MODEL NUMBER PP125H38B

### 38" MOWER


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532129365	Mower Asm.	40	532129206	Pulley, Mandrel, Single
2	873680500	Nut, Crownlock 5/16-18	41	873050900	Nut, Flangelock 9/16
3	872140506	Bolt, Carriage 5/16-18 x 3/4	42	532131494	Pulley, Idler, Flat
4	532125074	Runner, LH	43	532122052	Spacer, Retainer
5	532110485	Bearing, Ball, Mandrel	44	819131316	Washer 13/32 x 13/16 x 16 Ga.
6	532128774	Housing Mandrel Vented	45	873680600	Nut, Crownlock 3/8-16
7	532129895	Bearing, Ball	46	532131290	Belt
8	532133172	Shaft & Bearing Assembly (Includes key #7)	47	812000022	Ring, E
9	532127842	Blade, Mower, High Performance	48	819292016	Washer 29/32 x 1-1/4 x 16 Ga.
10	532129962	Washer, Hard, Mower, Vented	49	532131925	Shaft Asm., Lift
11	810030600	Washer, Lock Hvy 3/8	50	874780624	Bolt, Hex 3/8-16 x 1-1/2
12	532850857	Bolt, Blade 3/8-24 x 1-1/4 Gr. 8	51	532121002	Lever, Lift
13	532128961	Stripper, Mower, Vented	52	532109413	Grip, Handle
14	532106736	Shield, Deflector	53	532124526	Button, Plunger
15	532106735	Rod, Hinge	54	532122364	Plunger, Lever, Lift
16	532105896	Bracket, Deflector, Mower	55	532124874	Spring
17	532105304	Cap, Sleeve	56	532121006	Rod, Lever
18	532106734	Spring, Deflector	57	874760644	Bolt, Hex 3/8-16 x 2-3/4
19	819111016	Washer 11/32 x 5/8 x 16 Ga.	58	532132823	Spacer, Spring, Idler
20	532110452	Nut, Push	59	532131950	Spring, Extension
21	532128772	Runner, RH	60	532110810	Trunnion, Depth Stop
22	819111216	Washer 11/32 x 3/4 x 16 Ga.	61	819151216	Washer 15/32 x 3/4 x 16 Ga.
23	532078158	Bolt, Mandrel	62	812000037	Ring, Klip
24	532124670	Retainer, Spring	63	532110807	Nut, Special
25	874600636	Bolt, Carriage 3/8-16 x 2-1/4	64	819131016	Washer 13/32 x 5/8 x 16 Ga.
26	819131612	Washer	65	876020308	Pin, Cotter 3/32 x 1/2
27	532127218	Link Asm., Front	66	873350600	Nut, Hex, Jam 3/8-16 UNC
28	873350800	Nut, Jam Hex 1/2-13 UNC	67	532110729	Rod, Adjust, Lift
29	532130171	Trunnion	68	532121891	Handle, Lift Adjustment
30	873800800	Locknut W/Wsh 1/2-13 UNC	—	532133754	Mower Deck Assembly, Complete
31	532135388	Link, Lift, RH	—	532130794	Mandrel Assembly (Includes Key Nos. 5-8, 10-12, 39 and 41)
32	532135563	Pin, Roll			
33	532130833	Arm, Suspension, Rear			
34	532134619	Link, Lift, LH			
38	532133840	Idler, Arm			
39	532129963	Washer, Spacer, Mower, Vented			

**NOTE:** All component dimensions given in U. S. inches.  
1 inch = 25.4 mm

# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B


### TRANSAXLE AND PUMP ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION
1	532123634	Control, Asm., Free Wheel
4	532121188	Bracket, Mounting Differential
5	874780412	Bolt, Hex 1/4-20 UNC x 3/4
6	532121186	Fan, Hydro 8"
7	532121180	Pulley, Transaxle
8	532121211	Standoff, Fan, Hydro
9	532121182	Guard Assembly, Belt
10	532121431	Differential Assembly
11	532121430	Pump Assembly
12	874760572	Bolt, Hex, Fin 5/16-18 UNC x 4.5
13	532121323	Reservoir, Pump
14	873680500	Nut, Crownlock 5/16-18
15	532121250	Spring, Compression
16	874760612	Bolt 3/8-16 x 3/4
17	873680600	Nut, Crownlock 3/8-16 UNC

KEY NO.	PART NO.	DESCRIPTION
18	810040500	Washer, Lock
19	532071673	Cap, Plunger
20	532124815	Bolt, Shoulder 1/4-20 UNC
21	532120529	Washer, Nylon
22	873680400	Nut, Crownlock 1/4-20 UNC
23	819092016	Washer 9/32 x 1-1/4 x 16 Gauge
24	810040400	Washer, Lock

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm




# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B SUNDSTRAND PUMP ASSEMBLY - MODEL NUMBER BDU-10S

### PUMP ASSEMBLY



**KEY PART NO. DESCRIPTION**

KEY NO.	PART NO.	DESCRIPTION
1	532122756	Shaft, Pump
2	532122716	* Ring, Retaining
3	532122745	Bearing, Ball
4	532122715	* Spacer
5	532122700	* Seal, Lip
6	532122699	* Ring, Retaining
8	532122767	Bearing, Cradle
11	532122747	Bearing, Journal
12	532122717	* Seal, Lip
13	532122748	Arm, Trunnion
14	532122749	Guide, Slot
15	532127146	Housing Kit, Transmission
17	532122770	Bearing, Thrust Ball
18	532122771	Plug, Pipe
19	532127147	Center Section Kit
20	532122773	Bearing, Needle
21	532122722	* Seal, Lip
22	532122750	Shaft, Motor
25	532127148	Washplate, Variable
30	532122723	* Seal, Lip
31	532127149	Block Kit, Cylinder
36	532127151	Plug, Plastic

**KEY PART NO. DESCRIPTION**

KEY NO.	PART NO.	DESCRIPTION
37	532122786	Pin, St. Hdls.
38	532122718	* Gasket, Center Section
39	532122731	Filter
40	532122730	Washer, Thrust
41	532122728	Spring, Helical Compression
42	532127152	Check Valve Kit
46	532122787	Plug, St. Thd.
47	532122752	Screw Socket Head Cap
50	532122788	Washer, Thrust
51	532122789	Pin, Spiral
52	532122754	Plug, St. Thd.
55	532127153	Bypass Valve Kit
58	532122727	Adhesive Label, Bar Coded
59	532122790	Plug, St. Thd.
60	532127154	Overhaul Seal Kit, BDU-10 Includes: items marked with * and O-Rings for Check Valves and Bypass Valve
61	532121430	Complete Pump Assembly


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

[www.ersatzteil-service.de](http://www.ersatzteil-service.de)

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### AGRI-FAB TRANSAXLE MODEL NUMBER 121431X



# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### AGRI-FAB TRANSAXLE MODEL NUMBER 121431X

**KEY PART  
NO. NO.**

**DESCRIPTION**

1	532122614	Housing, Half L.H.
2	532122615	Housing, Half R.H.
3	532122616	Axle L.H.
4	532122620	Axle R.H.
5	532122621	Bearing, Ball
6	532122622	Washer, Flat 3/4 x 1-1/8 x .030
7	532122623	Gear, Miter
8	532122624	Gear, Miter
9	532122625	Nut, Hex Jam w/Patch 1/2-20
10	532122626	Shaft, Cross
11	532122688	Screw, Stud
12	532122629	Snap, Ring
13	532122631	Bearing, Thrust
14	532122633	Housing Assembly, Differential
15	532122634	Bearing, Flange
16	532122640	Gear, Differential 72 Tooth
17	532122641	Bolt, Torx Head 1/4-28 x 5/8"
18	532122642	Shaft, Input
19	532122643	Snap, Ring
20	532122644	Retaining Ring 7/16"
21	532122645	Housing, Input Bearing
22	532122646	Bearing, Needle
23	532122647	Bearing, Thrust
24	532122648	Washer, Flat 5/8 x 1-1/8 x .030
25	532122649	Key, Hi-Pro 3/32 x 5/8
26	532122650	Screw, Hex W/Patch 1/4-20 x 3/4
27	532122651	Gear, Input Pinion 17 Tooth
28	532123061	Washer, Flat .62 x 1 x .05
--	532122678	Washer, Flat .62 x 1.125 x .060
--	532122654	Washer, Flat .62 x 1 x .040
29	532122656	Pin, Cotter
30	532122653	Nut, Castle 5/16-24
31	532122659	Washer, Flat .343 x .88 x .062
32	532122660	Arm, Brake Actuator
33	532122662	Pin, Brake Actuating
34	532122663	Brake, Yoke

**KEY PART  
NO. NO.**

**DESCRIPTION**


35	532122664	Disc, Brake
36	532123065	Key, Hi-Pro 3/16 x 5/8"
37	532122666	Screw, Hex 1/4-20 x 1.50
38	532122667	Plate, Puck
39	532122668	Puck, Brake
40	532123066	Screw, Hex w/Patch 1/4-20 x 2.00
41	532122670	Screw, Hex Self-Tap 1/4-20 x 2.00
42	532122671	Screw, Hex Self-Tap 1/4-20 x 3.00
43	532126982	Bearing, Ball
44	532122673	Bearing, Ball
45	532122674	Shaft, Pinion W/11 Tooth Gear
46	532122675	Shaft, Drive
47	532123059	Bearing, Needle
48	532123060	Bronze Thrust Brg. 5/8 x 1-1/4 x 7/64
49	532123061	Washer, Flat .62 x 1.0 x .050
--	532122654	Washer, Flat .62 x 1.0 x .040
50	532122689	Spacer
51	532121839	Coupling
52	532126975	Gear, 60 and 17 Tooth
53	532122682	Nut, Hex 1/4-20
54	532122683	Gear, Drive Pinion 17 Tooth
55	532122684	Bolt, Square Head
56	532122685	Washer 15/16 x .265 x .125
57	532122686	Washer, Spring Lock 1/4"
58	532122687	Pin, Roll 3/16" x 1/2"
59	532122652	Washer, Flat .62 x 1.0 x .030
60	532123062	Pin, Dowel 3/32 x 1/4
61	532123063	Seal, Grease
62	532126977	Washer, Head Spring Lock 1/4"
63	532126980	Assembly, Gear, Reduction
64	532126981	Assembly, Shaft, Input
65	532126976	Shell Durina-O Grease (20 oz.)
--	532121431	Transaxle Assembly Complete

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

## 12.5 HP 38" LAWN TRACTOR - MODEL NUMBER PP125H38B

### DECALS



KEY NO.	PART NO.	DESCRIPTION
2	532121120	Decal, Air Cleaner
3	532134071	Decal, Hood, L. H.
4	532134070	Decal, Hood, R. H.
8	532133900	Decal, Logo, Fender
11	532109820	Decal, Warning, Cut Finger
13	532121549	Decal, Caution, Battery
14	532121349	Decal, Caution, Deflector
16	532108813	Decal Operating, Warning (Eng/Fr)
17	532101892	Decal, Clutch, Warning
18	532127630	Decal, Grille
19	532106202	Refelctor, Taillight
20	532133795	Decal, Caution (Eng/Fr)
21	532135013	Decal, Enviro. Deck
--	532135981	Manual, Owner's