


14 H.P. HYDROSTATIC YARD TRACTOR

CHASSIS AND ENCLOSURES




Ref #	Part Number	Qty	Description
2	121247X		SUB= 155925
3	105513X		SUB= 140551
4	120822X		DECAL
5	121642X388		FENDER
6	106202X		REFLECTOR-TAIL YT
7	123964X		NLA
9	105511X		SUB= 140675
10	124181X		SPRING COMPRESSION
12	105508X		BRKT FENDER T
13	6431J		PAD-SPACER T
14	123549X		SUB= 158990
15	106020X		SUB= 151346
16	3645J		BUSHING OUTLET T
17	8710J		FUEL TANK STEM GT
18	123487X		HOSE CLAMP
19	5277J		SUB= 8543R
21	124118X		PANEL DASH LH
24	105465X		SUB= 145244X417
25	101892X		DECAL T
26	121215X		DECAL DRIVE BELT
27	108256X		PAD FOOTREST T
28	121306X		SUB= 127866
30	74180512		SCREW
31	121277X		CHASSIS ASSY
32	105464X		SUB= 145243X417
33	110828X		SUB= 133748
34	4171R		CLIP T
35	110436X		SUB= 9151R
37	121195X		SADDLE
38	1554J		SUB= 155108
39	108813X		SUB= 138956
40	104805X		LOWER DASH
41	121312X		DASH
42	2029J		WELDNUT
43	121723X014		PLATE DASH
46	121888X388		SUB= 150302X505
47	123967X		DECAL, HOOD
49	123965X		DECAL HOOD LH
50	106784X		SUB= 155013
51	104618X		SUB= 155013
52	121886X388		SUB= 150301X505
53	5479J		PLUG BUTTON T
54	110829X		SUB= 124130X
55	106965X		SUB= 140181
57	121887X388		SUB= 140679X505
58	123966X		NLA
59	124392X		SUB= 147717
60	106395X		LENS LT
61	110853X		SUPPORT RH YTH
62	110852X		SUPPORT LH YTH
64	122100X		GRILL ASSY
65	105529X		SUB= 139888
66	73680500		SUB= 73690500
70	73680600		SUB= 73690600
71	17490608		SCREW LT
72	17490612		SCREW
74	72140606		BOLT
75	17431008		SUB= 98000165

Ref #	Part Number	Qty	Description
76	74760616		BOLT
77	121794X		COVER ACCESS
79	19091216		WASHER PM
81	73220400		SUB= 50675
82	74760532		BOLT
83	73510500		NUT
84	17211010		SCREW LT
85	104755X		""J"" FASTENER LT"
88	123481X		SUB= 7605J
89	73680400		SUB= 73690400
90	74191008		SCREW
91	10071000		LOCKWASHER
93	19131312		WASHER
96	74760612		SUB= 74780612
98	109808X		HOOD LATCH T
99	73731000		NUT
100	7206J		SPACER LT
101	19070818		WASHER
102	74981020		SCREW
104	19111116		WASHER
106	10090400		SUB= 10040400
109	2751R		CLIP T
116	121236X		SPACER
120	110855X		SUPPORT LH YTH
121	110854X		SUPPORT RH YTH
122	105419X388		NLA
126	19131614		WASHER
127	17190412		SCREW
128	19091216		WASHER PM
131	11050400		LOCKWASHER
132	19111212		WASHER
134	121248X		BUSHING
135	123976X		SUB= 73900400
136	121246X		BRKT SWITCH
137	121249X		SPACER SPLIT
138	72170410		BOLT
139	121251		SUB= 121251X
140	121250		SUB= 121250X
141	74641008		SUB= 71031008
142	73951000		"NUT,KEPS"
143	123091X		VERTICAL BAFFLE
144	109458X		FOAM STRIP T
145	108105X		SUB= 133746
146	123650X		STUD.1/4.TURN
147	105839X		RECEPTACLE LT
148	105838X		RETAINER LT


14 H.P. HYDROSTATIC YARD TRACTOR

DRIVE




Ref #	Part Number	Qty	Description
3	122436X		PIPE, EXHAUST
4	123161X		DECAL, ENGINE INSTRUCTION
5	125971X		DECAL, MAINTENANCE
9	13200300		ELBOW
10	13280336		PIPE NIPPLE LT
11	91084		PLUG OIL DRAIN
12	123072X		SUB= 132763
14	123461X		SUB= TH4H810
15	2751R		CLIP T
16	121187X		PLATE TRANS SUPT
17	121191X		SUB= 126649X
18	123583X		SQUARE KEY
19	73510600		NUT
20	121189X		U BOLT
21	121199X		SPACER SPLIT
22	121748X		WASHER
23	106108X361		SUB= 106108X417
24	12000001		E-RING LT
25	104757X		HUB CAP
26	122442X		BOLT, METRIC
27	65139		VALVE STEM LT
28	59192		VALVE CAP
29	74610764		SUB= 71130768
30	19152405		WASHER LT
31	10040700		LOCKWASHER
32	108218X		SUB= 142600
33	109841X		SUB= 136905
35	74760644		BOLT
36	123674X		PULLEY.IDLER.FLAT
37	4470J		SPACER T
38	19131312		WASHER
39	105730X		"KEEPER,BLT ENG LT"
40	121218X		KEEPER BELT ENGLH
41	109169X		SUB= 109172X
42	76020412		COTTER PIN
44	106888X		SPRING ROD LT
45	121200X		ROD BRAKE
46	8883R		PEDAL COVER T
47	122395X		ARM BRAKE
48	122409X		SUB= 149001
49	1572H		SUB= 2882J
50	71673		PLUNGER CAP T
51	105844X		SUB= 125637X
52	105710X		"LINK, CLUTCH T"
53	73680600		SUB= 73690600
54	109070X		BELT KEEPER LT
55	12000039		KLIP RING
56	110812X		WASHER LT
57	105707X		"ASS T, BELLCRAN"
58	105709X		"SPRING, RETURN LT"
59	105724X		SUB= 123102X
60	74760624		SUB= 74930624
61	106298X		SUB= 139245
62	105706X		"LY, BEARING"
63	19211616		WASHER LT
64	2228M		SUB= 2228M1
71	76020412		COTTER PIN
80	106268X		SUB= 122074X

Ref #	Part Number	Qty	Description
80A	7152J		TUBE.18X9.5-8
82	106236X		
84	110422X		SUB= 146682
91	4921H		SPRING.RETAINER
92	19131316		WASHER
97	677A223		SUB= 673A223
98	73350600		NUT
99	4497H		RETAINER M
101	73800600		NUT
102	122439X		BRACKET MUFFLER
105	122926X		SUB= 132781
107	122981X		SUB= 145552
108	101326L		DEFLECTOR.222573
110	122440X		SUB= 149723
111	122435X		TUBE ASSY EXH RH
112	122434X		TUBE ASSY EXH LH







14 H.P. LAWN TRACTOR

ELECTRICAL





Ref #	Part Number	Qty	Description
2	19091016		WASHER
3	102476X		SUB= 150109
4	72240460		BOLT
5	121537X		SUB= 123899X
6	7603J		"TRAY T, BATTERY"
7	125620X		HARNESS IGNITION
8	124108X		SUB= 110859X
9	7662J		SUB= 4152J
10	100541K		SUB= 7697J
11	7192J		WIRE TIE
12	109553X		SWITCH INTERLOCKT
13	4206J		CABLE-BATTERY T
14	102972X		SUB= 918102972X
15	109788X		SUB= 124211X
16	122147X		KEY
17	109081X		SUB= 146154
18	110712X		SWITCH LT
19	73680400		SUB= 73690400
20	719J		SUB= 154336
21	4207J		CABLE T
22	17021008		SCREW
23	109748X		RELAY ASSY T
24	2751R		CLIP T
25	109596X		HOSE CLAMP T
26	10090400		SUB= 10040400
27	73350400		NUT
28	74780408		BOLT
29	73510400		NUT
30	74760412		BOLT LT
31	73220400		SUB= 50675
32	11050400		LOCKWASHER
33	10040400		LOCKWASHER
34	108824X		FUSE HYT
35	9433R		AMMETER T
36	6009J		SUB= 532131708
37	10101000		SUB= 10071000
38	73911000		NUT
39	19070818		WASHER
40	102501X		SUB= 141940
41	235R		CLIPT
42	4022J		HEX NUT T
43	4021J		SWITCH.PTO.T
44	109787X		SUB= 147626
45	121305X		SWITCH SEAT
46	121264X		"CAP,BATTERY "
47	121549X		DECAL
48	74641008		SUB= 71031008
49	73951000		"NUT,KEPS"
50	4171R		CLIP T
	101539X		SHEET INSTR LT
	125899X		NLA
	101572X		SHEET-INSTRUCTION (FRENCH)
	125900X		OWNER'S MANUAL (FRENCH)






Ref #	Part Number	Qty	Description
31	73680600		SUB= 73690600
33	19131312		WASHER
70	17490612		SCREW
71	17490508		SCREW LT
92	74561014		SCREW
93	69180		LOCKNUT
96	100536K		SHOULDER BOLT LT
97	74760612		SUB= 74780612
98	73680500		SUB= 73690500







Ref #	Part Number	Qty	Description
6	74760416		BOLT
7	10040400		LOCKWASHER
8	17210806		SCREW
38	19131312		WASHER
43	19131316		WASHER
53	73680600		SUB= 73690600
65	17720410		SCREW LT
66	17490616		SCREW GTV
67	11050600		LOCKWASHER
68	74760612		SUB= 74780612
69	74760616		BOLT
70	72140606		BOLT
79	10040600		LOCKWASHER
83	17021008		SCREW
89	72140506		BOLT
90	73680500		SUB= 73690500
103	M010206012		BOLT, HEX
104	19090816		WASHER
109	17030808		SUB= 17030814
113	17490512		SCREW






Ref #	Part Number	Qty	Description
4	73680600		SUB= 73690600
5	19111216		WASHER M
6	72140505		BOLT
20	73680500		SUB= 73690500
23	72140506		BOLT
37	17490612		SCREW
50	72140606		BOLT
67	72140610		BOLT.3/8-14X1.25





Ref #	Part Number	Qty	Description
67	74760612		SUB= 74780612
70	73680600		SUB= 73690600
76	74760616		BOLT
96	74760612		SUB= 74780612
113	121144X		SUB= 127018X
123	120068X		"KNOB 1/2"" YT"
124	19171912		WASHER
125	11050600		LOCKWASHER
129	11030400		LOCKWASHER GT






Ref #	Part Number	Qty	Description
10	105848X		"BOLT, SHOULDER LT"
14	110739X		WASHER T
15	73980600		NUT SPECIAL T
40	74780624		"BOLT,HEX"




14 H.P. HYDROSTATIC YARD TRACTOR LIFT ADJUSTMENT



Ref #	Part Number	Qty	Description
2	73360700		NUT
3	110729X		ROD LIFT LT
4	76020308		SUB= 3145
5	2876H		SPRING T
6	19131016		WASHER
7	124526X		SUB= 125925X
8	19151216		WASHER
9	110810X		TRUNION LT
11	109413X		GRIP
12	122364X		SUB= 125925X
13	121002X		SUB= 123096X
16	4939M		SUB= 85902
17	121006X		LEVER ROD LT
18	4921H		SPRING.RETAINER
19	19171516		WASHER T
20	110029X		LIFT LINK LT
21	121001X		SHAFT LIFT
22	110448X		PIVOT PIN T
23	110447X		SUB= 132793
24	73710700		NUT LOCK YTH
25	12000037		KLIP RING
26	105864X		"BRACKET, SUSPE T"
28	121598X		RH SUSP ARM ASM
29	9135R		SPRING H
30	106308X		SUB= 130171
32	73220800		NUT
33	121599X		LH SUSP ARM ASM
34	12000022		E-RING
37	19292016		WASHER
38	110807X		NUT T
39	73350600		NUT


14 H.P. HYDROSTATIC YARD TRACTOR MOWER



Ref #	Part Number	Qty	Description
2	108672X		SUB= 144726
3	8417J		SUB= 128772
4	73680600		SUB= 73690600
5	19111216		WASHER M
7	105896X		SUB= 137607
8	110452X		NUT PUSH M
9	106734X		SUB= 123713X
10	106735X		ROD-HINGE T
11	106736X		DEFLECTOR-SHLD T
12	108682X		NLA
13	105304X		CAP-SLEEVE LT
14	105662X		LINK.PARALLEL
15	105744X		"ROD, FRT. PARAL T"
16	4921H		SPRING.RETAINER
18	109835X		HINGE PIN T
20	73680500		SUB= 73690500
21	109598X		BRACKET RH LT
22	109597X		BRACKET LH T
24	109820X		DECAL YT
25	109503X		SUPPORT ARM T
26	109504X		STOP T
27			REFER TO IMAGE
29	74760636		BOLT
30	123552X		SUB= 127162X
31	106902X		SPACER RETAINER
32	121316X		PULLEY IDLER
33	106513X		"WASHER, WEAR LT"
35	121687X		"JACKSHAFT.38""LT"
36	100668L		SUPPORT PLATE LT
39	121263X		"BLADE.38"" HI-LI"
40	19132012		WASHER
41	10030600		SUB= 10040600
42	74610624		BOLT.3/8-24X1-1/2
43	102727X		"SPRING.EXT.8.5"""
54	105857X		"BRKT,SUSP RH T"
63	19111016		WASHER
65	7631J		RUNNER-LH M
68	121349X		DECAL WARNING
69	19131316		WASHER
75	19131210		WASHER
76	110445X		SUPPORT T
76	109776X		PIVOT PIN T
78	109729X		ROLLER T
79	19151610		WASHER T
80	19161616		WASHER
81	74760512		BOLT
82	76020412		COTTER PIN
83	73680500		SUB= 73690500
84	109646X		BRACKET LH T
85	109647X		BRACKET RH T

14 H.P. HYDROSTATIC YARD TRACTOR


PUMP



Ref #	Part Number	Qty	Description
2	122716X		RETAINIANG RING-(2003016)
3	122745X		BALL BEARING
4	122715X		SPACER
5	122700X		SEAL LIP
6	122699X		RING.RET.2003052
8	122767X		CRADLE BEARING (2003023)
9	122729X		PLUG
10	122746X		O RING
11	122747X		BEARING
12	122717X		SEAL.9008000-0126
13	122748X		TRUNION ARM (2003005)
14	122749X		GUIDE.2000015.HYD
15	122768X		SUB= 121430X
16	122769X		JOURNAL BRG(2003071)
17	122770X		SUB= 142936
18	122771		SUB= 122771X
19	122772X		CENTER SECTION
20	122773X		NEEDLE BEARING
21	122722X		LIP SEAL-9008000-0127
22	122750X		SHAFT
23	122774X		WASHER
25	122775X		SUB= 121430X
26	122776X		SUB= 121430X
27	122777X		SUB= 121430X
28	122778X		SUB= 121430X
29	122779X		SUB= 121430X
30	122723X		SEAL LIP
31	122780X		CYLINDER BLOCK
32	122781X		CYLINDER BLOCK(70331)
33	122782X		PISTON
34	122784X		PISTON SPRING
35	122785X		WASHER.TR.2003019
37	122786X		PIN
38	122718X		GASKET.20030600
39	122731X		FILTER
40	122730X		WASHER (2000011)
41	122728X		SPRING
42	122706X		PLUG
43	122705X		O RING
44	122702X		BALL
45	122704X		SPRING.2003012.HY
46	122787X		PLUG
47	122752X		SCREW9007314-0808
48	122753X		SCREW
50	122788X		WASHER
51	122789X		PIN
52	122754X		PLUG
53	122711X		O RING
54	122708X		SPRING
55	122709X		SUB= 122712X
56	122712X		BYPAS KT 25130011
57	122710X		O RING (9004175-0027)
58	122727X		ADHESIVE LABEL
59	122790X		PLUG
60	122791X		SPRING
	121430X		PUMP.BDU-10S-114


14 H.P. HYDROSTATIC YARD TRACTOR

SCHEMATIC




Ref #	Part Number	Qty	Description
2	122716X		RETAINIANG RING-(2003016)
3	122745X		BALL BEARING
4	122715X		SPACER
5	122700X		SEAL LIP
6	122699X		RING.RET.2003052
8	122767X		CRADLE BEARING (2003023)
9	122729X		PLUG
10	122746X		O RING
11	122747X		BEARING
12	122717X		SEAL.9008000-0126
13	122748X		TRUNION ARM (2003005)
14	122749X		GUIDE.2000015.HYD
15	122768X		SUB= 121430X
16	122769X		JOURNAL BRG(2003071)
17	122770X		SUB= 142936
18	122771		SUB= 122771X
19	122772X		CENTER SECTION
20	122773X		NEEDLE BEARING
21	122722X		LIP SEAL-9008000-0127
22	122750X		SHAFT
23	122774X		WASHER
25	122775X		SUB= 121430X
26	122776X		SUB= 121430X
27	122777X		SUB= 121430X
28	122778X		SUB= 121430X
29	122779X		SUB= 121430X
30	122723X		SEAL LIP
31	122780X		CYLINDER BLOCK
32	122781X		CYLINDER BLOCK(70331)
33	122782X		PISTON
34	122784X		PISTON SPRING
35	122785X		WASHER.TR.2003019
37	122786X		PIN
38	122718X		GASKET.20030600
39	122731X		FILTER
40	122730X		WASHER (2000011)
41	122728X		SPRING
42	122706X		PLUG
43	122705X		O RING
44	122702X		BALL
45	122704X		SPRING.2003012.HY
46	122787X		PLUG
47	122752X		SCREW9007314-0808
48	122753X		SCREW
50	122788X		WASHER
51	122789X		PIN
52	122754X		PLUG
53	122711X		O RING
54	122708X		SPRING
55	122709X		SUB= 122712X
56	122712X		BYPAS KT 25130011
57	122710X		O RING (9004175-0027)
58	122727X		ADHESIVE LABEL
59	122790X		PLUG
60	122791X		SPRING
	121430X		PUMP.BDU-10S-114

14 H.P. HYDROSTATIC YARD TRACTOR STEERING ASSEMBLY




Ref #	Part Number	Qty	Description
3	73940800		SUB= 73360800
4	100712K		WASHER
5	121472X		SUB= 150546
6	100711L		ADAPTER LT
7	106945X		TUBE YT
8	106943X		SPACER LT
9	4921H		SPRING.RETAINER
10	102670X		SPRING GTV
12	73610600		SUB= 7810H
13	104757X		HUB CAP
14	121274X		KNOB.DUCKHEAD.1/2
15	110845X		ROD.YTH
16	121631X		SPRING TORSION
17	108196X		BRKT CONTROL HYT
18	109557X		STEERING SHAFT T
19	2882J		DRIVE PIN
20	74580		SHAFT SPACER LT
21	71208		BUSHING
22	109432X		SUB= 110150X
23	19212016		WASHER D
24	12000029		RING
25	6266H		WASHER .T
26	108683X		ROD STEERING T
27	108972X		WASHER HYT
28	108684X		GEAR.SECTOR.HYT
29	106126X		KEY-WOODRUFF LT
30	76020412		COTTER PIN
31	73680600		SUB= 73690600
32	108200X		WASHER FRIC HYT
34	108518X		BOLT HYT
35	19212016		WASHER D
36	108201X		SPACER HYT
37	121202X		LINK CONTROL
38	108844X		SPRING HYT
39	19132012		WASHER
40	74760648		BOLT - HEX 3/8 - 16 X 3
41	121209X		ARM ASM PUMP
42	105663X		SUPPORT-SADDL T
43	74761060		BOLT LT
44	105664X		SUPPORT.SADDLE.FT
45	124032X		SUB= 532130468
46	10040600		LOCKWASHER
47	10040500		LOCKWASHER
48	121334X		ROD TIE
49	73810500		NUT.LOCK.5/16-24
50	105656X		SPINDLE-LH LT
51	19272016		WASHER
52	110438X		BEARING
53	6266H		WASHER .T
54	3366R		COL. SRTG. BEAR.
55	73901000		"NUT-LOC,FLANGE LT"
56	108075X		FRONT AXLE
57	105654X		SUB= 130524
58	278H		FITTING LT
59	65139		VALVE STEM LT
60	59192		VALVE CAP
61	9040H		"FLANGE BEARING"
62	106732X361		SUB= 106732X417

Ref #	Part Number	Qty	Description
63	106222X		SUB= 122073X
63A	59904		TUBE.5.3/4.5/6
64	73800600		NUT
65	108212X		TRUNION HYT
66	121750X		ROD ADJ CONTROL
73	6855M		ZERK M
74	121748X		WASHER
75	5320R		INSUL CLIP T
77	108685X		GEAR PINION T
78	109816X		NYLINER T
79	101930X		WASHER YTV
81	19131212		WASHER T
82	121748X		WASHER
83	19111216		WASHER M
84	19151516		WASHER
85	110739X		WASHER T
86	121232X		CAP
87	121217X		GUIDE CONTROL
88	121216X		BRKT
89	17490512		SCREW
90	17021008		SCREW
91	19070816		WASHER
94	121204X		BELLCRANK
95	121206X		BRKT BELLCRANK
99	121190X		KEEPER
100	4497H		RETAINER M



**14 H.P. HYDROSTATIC YARD TRACTOR
TRANSAXLE**




Ref #	Part Number	Qty	Description
2	122615X		HSG HALF RH-44076
3	122616X		AXLE LH -44273
4	122620X		AXLE RH-44272
5	122621X		BEARING.44121.AGR
6	122622X		WASHER -44008
7	122623X		GEAR MITER -44096
8	122624X		GEAR MITER -44097
9	122625X		NUT -44133
10	122626X		SHAFT CROSS
11	122688X		SCREW-STUD -44271
12	122629X		SNAP RING -44146
13	122631X		"THRUST, BEARING -44128"
14	122633X		HOUSING.ASM.DIFF.-62590
15	122634X		"FLANGE, BEARING-44129"
16	122640X		GEAR
17	122641X		BOLT -44126
18	122642X		SHAFT INPUT-44270
19	122643X		SNAP RING -44145
20	122644X		RET RING (44144)
21	122645X		SUB= 155892
22	122646X		"NEEDLE, BEARING 44099"
23	122647X		BEARING.NEE.44139
24	122648X		WASHER-44109
25	122649X		KEY.44136.HYDRO
26	122650X		SCREW
27	122651X		SUB= 155892
28	122652X		WASHER -44125
	122653X		WASHER -44150
	122654X		WASHER-44151
29	122656X		PIN COTTER -44101
30	122658X		NUT -44142
31	122659X		WASHER FLAT -44130
32	122660X		ARM BRAKE 23710
33	122662X		PIN BRAKE ACTUATO -44127
34	122663X		BRAKE YOKE
35	122664X		DISC BRAKE -(44090)
36	123065X		KEY -44143
37	122666X		SCREW -44277
38	122667X		PLATE PUCK -44134
39	122668X		SUB= 142883
40	123066X		SCREW -44300
41	122670X		SCREW -44123
42	122671X		SCREW -44124
43	122672X		"BALL, BEARING -44147"
44	122673X		"BALL, BEARING -44232"
45	122674X		SHAFT PINION 44083
46	122672X		"BALL, BEARING -44147"
47	123059X		NEEDLE BEARING -44342
48	123060X		THRUST.BRONZE -44343
49	122654X		WASHER-44151
50	122689X		SPACER -23711
51	121839X		COUPLING- 44084
52	122681X		SUB= 126975X
53	122682X		NUT -43178
54	122683X		PINION-DR.44079
55	122684X		BOLT SQ HD
56	122685X		WASHER -44278
57	122686X		WASHER -44137

Ref #	Part Number	Qty	Description
58	122687X		PIN ROLL-44269
59	122678X		NLA
	123061X		WASHER -44371
60	123062X		DOWEL PIN -44346
61	123063X		SEAL GREASE -44394
	121431X		TRANSAXLE.AGRIFAB



14 H.P. HYDROSTATIC YARD TRACTOR TRANSAXLE AND PUMP ASSEMBLY



Ref #	Part Number	Qty	Description
3	121193X		SUB= 123634X
4	121188X		BRACKET
5	74780412		SUB= 74780414
6	121186X		FAN
7	121180X		PULLEY TRANSAXLE
8	121211X		STANDOFF
9	121182X		GUARD ASSY
10			REFER TO IMAGE
11			REFER TO IMAGE
12	74760572		BOLT
13	121323X		PUMP.2003081.
14	73680500		SUB= 73690500
15	121250X		SPRING
16	74760612		SUB= 74780612
17	73680600		SUB= 73690600
18	10040500		LOCKWASHER
19	71673		PLUNGER CAP T
20	7605J		BOLT T
21	120529X		WASHER T
22	73680400		SUB= 73690400
23	19092016		WASHER
24	10040400		LOCKWASHER

