


TILLER - - MODEL NUMBER 3355A89

BELT GUARD AND PULLEY ASSEMBLY


NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm



Ref #	Part Number	Qty	Description
1	159268		ASM.BRKT.BELT.GRD
2	9484R		CONDIUT CLIP T
3	86777		SUB= 750097
4	74770812		SCREW
5	73220600		NUT.HEX.3/8-16UNC
6	19131316		WASHER
7	2009J		PULLEY W/SPACER
8	127180X		ARM.ASM.REV.IDLER
9	74760628		BOLT
10	156705X505		"GUARD,BELT"
11	19091016		WASHER
12	104213X		NUT-CAP TI
13	72140405		BOLT T
14	133035		BELT-V
15	2614J		SUB= TH3H440
16	12000028		SUB= 2267J
17	2649M		KEY T
18	151236		"SHEAVE,TRANS."D""
19	110550X		BOLT TI
20	12000036		KLIP RING TI
21	73350600		NUT
22	161806		"PULLEY,IDLER"
23	162290		"ARM, IDLER"
24	74760620		SUB= 74780620
25	106968X		SHAFT IDLER TI
26	73350500		JAM NUT TI
27	73220400		SUB= 50675
28	10040400		LOCKWASHER
29	109227X		PAD IDLER TI
30	23200404		SET SCREW
31	101189L		ENGINE PULLEY TI
32	151223		SHEAVE.TRANS

TILLER - - MODEL NUMBER 3355A89


DECALS



Ref #	Part Number	Qty	Description
1	146348		DECAL.CNTRL.PNL.5
2	146355		DECAL.BELT.GUARD
3	121753X		DECAL REVERSE
4	273721		DECAL, 5HP
5	120431X		DECAL TI
6	162828		DECAL-SERVICE REV. PANEL WIZARD
7	271948		DECAL, BRIGGS & STRATTON
8	120075X		DECAL TI
9	127521		NLA
10	162215		DECAL.TINE.SHIELD
	162842		MANUAL.O.3355A89



TILLER - - MODEL NUMBER 3355A89 ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 137202, TYPE NO. 1116-E1




Ref #	Part Number	Qty	Description
1	497144		CYLINDER ASSEMBLY
2	399268		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
12	270125		GASKET, CRANKCASE .005" THICK
12	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	94916		PLUG, PIPE, HEX SOCKET
16	492088		CRANKSHAFT
16	94388		TIMING GEAR KEY
18	494044		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	281658		PLUG-OIL FILLER
22	94980		SCREW, COVER MOUNTING
23	393673		FLYWHEEL-MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
25	298905		PISTON ASSEMBLY .010" OVERSIZE
25	298906		PISTON ASSEMBLY .020" OVERSIZE
25	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
26	299742		RING SET, PISTON, CHROME, STANDARD
26	298983		RING SET, PISTON .010" OVERSIZE
26	298984		RING SET, PISTON .020" OVERSIZE
26	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
29	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	214726		GEAR-CAM
51	273113		GASKET, CARBURETOR MOUNTING
55	497442		HOUSING, REWIND STARTER
56	498144		PULLEY, REWIND STARTER
58	280399		ROPE, REWIND STARTER (CUT TO 88-5/8)
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94904		SCREW, SEMS
73	225176		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	498298		CARBURETOR ASSEMBLY

Ref #	Part Number	Qty	Description
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	497600		SHAFT & LEVER, THROTTLE
108	497230		VALVE & SHAFT GROUP, CHOKE
111	262715		SPRING, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94913		SCREW, TORX HEX
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
147	231955		JET-PILOT
152	260575		SPRING, THROTTLE ADJUSTMENT
154	93527		SCREW, MACHINE, ROUND HEAD
162	490589		SCREW AND COLLAR
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94924		SCREW, TORX
190A	94919		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262280		LINK, GOVERNOR
	495603		GASKET SET
	498529		VALVE OVERHAUL GASKET KIT
203	280720		BELL CRANK
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262948		SPRING-GOVERNOR
212	262270		LINK, THROTTLE
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
227	490374		LEVER ASSEMBLY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
300	493936		MUFFLER-EXHAUST
304	495759		HOUSING, BLOWER
305	94619		SCREW, SEMS, BLOWER, HOUSING MOUNTING
306	224820		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	94896		SCREW, SEMS
356	398808		WIRE, GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER

Ref #	Part Number	Qty	Description
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	225121		CUP, STARTER
456	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
467	280715		KNOB, CONTROL
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR
536	494279		AIR CLEANER KIT
542	94897		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	231068		PIPE FUEL
612	497830		STARTER ASSEMBLY, REWIND
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
616	495243		CRANK, GOVERNOR
621	396847		SWITCH, STOP
623			CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
689	263073		SPRING, RETAINER
741	262992		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	493880		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	225057		LEVER, BRACKET ASSY
1012	490507		RETAINER, LINK
1036	499345		LABEL KIT-EMISSIONS
1095	498529		VALVE OVERHAUL GASKET KIT
2500	137202-1114		ENGINE
	491145		SHORTBLOCK
	495606		CARBURETOR OVERHAUL KIT

TILLER - - MODEL NUMBER 3355A89 ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 137202, TYPE NO. 1116-E1




★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

Ref #	Part Number	Qty	Description
1	497144		CYLINDER ASSEMBLY
2	399268		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
12	270125		GASKET, CRANKCASE .005" THICK
12	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	94916		PLUG, PIPE, HEX SOCKET
16	492088		CRANKSHAFT
16	94388		TIMING GEAR KEY
18	494044		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	281658		PLUG-OIL FILLER
22	94980		SCREW, COVER MOUNTING
23	393673		FLYWHEEL-MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
25	298905		PISTON ASSEMBLY .010" OVERSIZE
25	298906		PISTON ASSEMBLY .020" OVERSIZE
25	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
26	299742		RING SET, PISTON, CHROME, STANDARD
26	298983		RING SET, PISTON .010" OVERSIZE
26	298984		RING SET, PISTON .020" OVERSIZE
26	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
29	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	214726		GEAR-CAM
51	273113		GASKET, CARBURETOR MOUNTING
55	497442		HOUSING, REWIND STARTER
56	498144		PULLEY, REWIND STARTER
58	280399		ROPE, REWIND STARTER (CUT TO 88-5/8)
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94904		SCREW, SEMS
73	225176		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	498298		CARBURETOR ASSEMBLY

Ref #	Part Number	Qty	Description
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	497600		SHAFT & LEVER, THROTTLE
108	497230		VALVE & SHAFT GROUP, CHOKE
111	262715		SPRING, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94913		SCREW, TORX HEX
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
147	231955		JET-PILOT
152	260575		SPRING, THROTTLE ADJUSTMENT
154	93527		SCREW, MACHINE, ROUND HEAD
162	490589		SCREW AND COLLAR
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94924		SCREW, TORX
190A	94919		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262280		LINK, GOVERNOR
	495603		GASKET SET
	498529		VALVE OVERHAUL GASKET KIT
203	280720		BELL CRANK
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262948		SPRING-GOVERNOR
212	262270		LINK, THROTTLE
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
227	490374		LEVER ASSEMBLY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
300	493936		MUFFLER-EXHAUST
304	495759		HOUSING, BLOWER
305	94619		SCREW, SEMS, BLOWER, HOUSING MOUNTING
306	224820		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	94896		SCREW, SEMS
356	398808		WIRE, GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER

Ref #	Part Number	Qty	Description
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	225121		CUP, STARTER
456	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
467	280715		KNOB, CONTROL
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR
536	494279		AIR CLEANER KIT
542	94897		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	231068		PIPE FUEL
612	497830		STARTER ASSEMBLY, REWIND
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
616	495243		CRANK, GOVERNOR
621	396847		SWITCH, STOP
623			CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
689	263073		SPRING, RETAINER
741	262992		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	493880		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	225057		LEVER, BRACKET ASSY
1012	490507		RETAINER, LINK
1036	499345		LABEL KIT-EMISSIONS
1095	498529		VALVE OVERHAUL GASKET KIT
2500	137202-1114		ENGINE
	491145		SHORTBLOCK
	495606		CARBURETOR OVERHAUL KIT

TILLER - - MODEL NUMBER 3355A89
ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 137202, TYPE NO. 1116-E1



Ref #	Part Number	Qty	Description
1	497144		CYLINDER ASSEMBLY
2	399268		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
12	270125		GASKET, CRANKCASE .005" THICK
12	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	94916		PLUG, PIPE, HEX SOCKET
16	492088		CRANKSHAFT
16	94388		TIMING GEAR KEY
18	494044		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	281658		PLUG-OIL FILLER
22	94980		SCREW, COVER MOUNTING
23	393673		FLYWHEEL-MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
25	298905		PISTON ASSEMBLY .010" OVERSIZE
25	298906		PISTON ASSEMBLY .020" OVERSIZE
25	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
26	299742		RING SET, PISTON, CHROME, STANDARD
26	298983		RING SET, PISTON .010" OVERSIZE
26	298984		RING SET, PISTON .020" OVERSIZE
26	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
29	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	214726		GEAR-CAM
51	273113		GASKET, CARBURETOR MOUNTING
55	497442		HOUSING, REWIND STARTER
56	498144		PULLEY, REWIND STARTER
58	280399		ROPE, REWIND STARTER (CUT TO 88-5/8)
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94904		SCREW, SEMS
73	225176		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	498298		CARBURETOR ASSEMBLY


Ref #	Part Number	Qty	Description
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	497600		SHAFT & LEVER, THROTTLE
108	497230		VALVE & SHAFT GROUP, CHOKE
111	262715		SPRING, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94913		SCREW, TORX HEX
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
147	231955		JET-PILOT
152	260575		SPRING, THROTTLE ADJUSTMENT
154	93527		SCREW, MACHINE, ROUND HEAD
162	490589		SCREW AND COLLAR
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94924		SCREW, TORX
190A	94919		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262280		LINK, GOVERNOR
	495603		GASKET SET
	498529		VALVE OVERHAUL GASKET KIT
203	280720		BELL CRANK
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262948		SPRING-GOVERNOR
212	262270		LINK, THROTTLE
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
227	490374		LEVER ASSEMBLY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
300	493936		MUFFLER-EXHAUST
304	495759		HOUSING, BLOWER
305	94619		SCREW, SEMS, BLOWER, HOUSING MOUNTING
306	224820		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	94896		SCREW, SEMS
356	398808		WIRE, GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER

Ref #	Part Number	Qty	Description
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	225121		CUP, STARTER
456	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
467	280715		KNOB, CONTROL
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR
536	494279		AIR CLEANER KIT
542	94897		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
592	231978		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	231068		PIPE FUEL
612	497830		STARTER ASSEMBLY, REWIND
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
616	495243		CRANK, GOVERNOR
621	396847		SWITCH, STOP
623			CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
689	263073		SPRING, RETAINER
741	262992		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	493880		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	225057		LEVER, BRACKET ASSY
1012	490507		RETAINER, LINK
1036	499345		LABEL KIT-EMISSIONS
1095	498529		VALVE OVERHAUL GASKET KIT
2500	137202-1114		ENGINE
	491145		SHORTBLOCK
	495606		CARBURETOR OVERHAUL KIT

TILLER - - MODEL NUMBER 3355A89

HANDLE ASSEMBLY


NOTE: All component dimensions are given in U.S. inches.
1 Inch = 25.4 mm



Ref #	Part Number	Qty	Description
1	131268X505		HANDLE BRKT
2	72140512		BOLT
3	9266R		SUB= 624A78
4	153138		HANDLE.LH TILLER
5	73680500		SUB= 73690500
6	19111116		WASHER
7	19121414		WASHER
8	74760516		SUB= 77394
9	74760512		BOLT
10	10040500		LOCKWASHER
11	73220500		NUT.HEX.5/16-18
12	98000129		NUT
13	72140506		BOLT
14	674A150505		HANDLE PANEL
16	153139		"HANDLE-RH,TILLER"
17	106932X		KNOB T(3/8 HOLE)
18	3066J		CABLE CLUTCH T
19	151229		LEVER CONTRL TIME
20	154805		"PIN PIVOT,GROOVED"
21	12000027		E-RING
22	101248K		ROD REVERSE TI
23	1778E		RIVET.RD.HD.DRILL
24	2613J		REVERSE ROD TI
25	19131316		WASHER
26	76020412		COTTER PIN
27	76020308		SUB= 3145
28	19131312		WASHER
29	12000059		RETAINER RING

TILLER - - MODEL NUMBER 3355A89

TINE ASSEMBLY




Ref #	Part Number	Qty	Description
1	156934		"TINE ASM, OUTER RH"
2	3146R		RETAINER.SPRING
3	156932		"TINE ASM.INNER,RH"
4	156931		TINE ASM.INNER LH
5	156933		"TINE ASM, OUTER LH"
6	4929H		RIVET.PAN HD.1.75




TILLER - - MODEL NUMBER 3355A89

TRANSMISSION

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm




Ref #	Part Number	Qty	Description
1	74760524		BOLT.HEX.5/16-1.5
2	74780652		BOLT HEX 3/8-16
3	19131311		WASHER
5	73800600		NUT
6	9057R505		TINE SHIELD
7	1949J		SUB= 1949J500
8	1948J		ENGINE BRKT LH TI
9	10040500		LOCKWASHER
10	73220500		NUT.HEX.5/16-18
11	74760544		SUB= 74780544
12	151222		SUB= 165808
13	19171616		WASHER
14	9173R		SPLIT SPACER RT
15	73510500		NUT
16	19091412		WASHER
17	19092016		WASHER
18	10040400		LOCKWASHER
19	74610412		BOLT
20			CHECK WITH SUPPLIER



TILLER - - MODEL NUMBER 3355A89

WHEEL AND DEPTH STAKE ASSEMBLY



Ref #	Part Number	Qty	Description
1	9194R		DRILLED RIVET RT
2	74760520		BOLT
3	74760512		BOLT
4	73220500		NUT.HEX.5/16-18
5	10040500		LOCKWASHER
6	73800600		NUT
7			CHECK WITH SUPPLIER
8	1952J		SUB= 1952J500
9	122233X		SUB= 2582J
10	326J		SUB= 4929H
11	74780628		BOLT
12	74760524		BOLT.HEX.5/16-1.5
13	1951J		SUB= 1951J500
14	120958X		WASHER
15	5388J		STAKE SPRING TI
16	121117X		BOLT SHOULDER
17	9188R		SUB= 107644X
18	19131311		WASHER
19	9190R		SUB= 9190R500
20	73680600		SUB= 73690600
21	74760516		SUB= 77394
22	73800500		NUT

