



TILLER - - MODEL NUMBER 5033-84

BELT GUARD AND PULLEY ASSEMBLY




NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	23230506		SET SCREW
2	130811		SUB= 532130811
3	122955X		BRKT ASSY
4	72140404		BOLT
5	74610812		BOLT.HEX.HEAD
6	121463X		KEEPER BELT
7	104213X		NUT-CAP TI
8	19091016		WASHER
9	131157X424		GUARD BELT
10	109227X		PAD IDLER TI
11	72140406		BOLT T
12	9179R		SUB= TH3H390
13	12000028		SUB= 2267J
14	151939		PULLEY.TRANSMISSN
15	132213		SUB= 532132213
16	12000036		KLIP RING TI
17	73350600		NUT
18	161806		"PULLEY,IDLER"
19	162290		"ARM, IDLER"
20	74760620		SUB= 74780620
21	106968X		SHAFT IDLER TI
22	105358X		SHIELD-DIRT TI
23	10040400		LOCKWASHER
24	73220400		SUB= 50675
25	73350500		JAM NUT TI



TILLER - - MODEL NUMBER 5033-84



DECALS



Ref #	Part Number	Qty	Description
1	163788		DECAL.LOGO
2	163787		DECAL.LOGO
3	110593X		SUB= 121858X
4	110594X		DECAL TI
5	120431X		DECAL TI
6	162215		DECAL.TINE.SHIELD
7	120075X		DECAL TI
8	273199		DECAL-BRIGGS AND STRATTON
9	273603		DECAL-SPEED CONTROL
10	273714		DECAL-3.5 HP
	164608		MANUAL.O.5033-84.E





TILLER - - MODEL NUMBER 5033-84
ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 94202, TYPE NO. 0115-E1



1019 LABEL KIT

★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.




Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214277		HEAD, CYLINDER
7	272694		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
12	270895		GASKET, CRANKCASE .005"
12	270896		GASKET, CRANKCASE .009"
13	94960		SCREW
15	94387		PLUG OIL DRAIN
16	495211		CRANKSHAFT
16	499047		KEY, TIMING GEAR RETAINING
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	281658		PLUG-OIL FILLER
22	94607		SCREW, SEM, MOUNTING
22A	94862		SCREW
23	496278		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	498668		PISTON ASSEMBLY, STANDARD
25	498669		PISTON ASSEMBLY, .010" OVERSIZE
25	498670		PISTON ASSEMBLY, .020" OVERSIZE
25	498671		PISTON ASSEMBLY, .030" OVERSIZE
26	498680		RING SET, STANDARD SIZE
26	498681		RING SET, .010" OVERSIZE
26	498682		RING SET, .020" OVERSIZE
26	498683		RING SET, .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
29	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94699		SCREW
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
38	94736		SCREW
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
51	273113		GASKET, CARBURETOR MOUNTING
53	94523		SCREW, EXHAUST
55	499441		HOUSING, REWIND STARTER
58	281464		ROPE, STARTER
60	393152		HANDLE, REWIND STARTER
65	94904		SCREW, SEMS
73	225381		SCREEN, ROTATING
90	499941		CARBURETOR ASSY
94	231533		VALVE, NEEDLE

Ref #	Part Number	Qty	Description
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	495313		SHAFT & LEVER, THROTTLE
109	497230		VALVE & SHAFT GROUP, CHOKE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
144	499901		PULLEY, STARTER
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
161	492797		BASE, AIR CLEANER
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94919		SCREW, TORX
190A	94924		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	263174		LINK, GOVERNOR
202	262470		LINK, CONTROL
209	260041		SPRING, GOVERNOR
216	263188		LINK, CHOKE
222	499533		BRACKET, CONTROL
257	93543		SCREW, SEMS, HEX HEAD
298	220859		LOCKNUT, MUFFLER
300	493288		MUFFLER, EXHAUST
304	499522		HOUSING, BLOWER
305	94786		SCREW
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	496914		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	497298		WIRE, GROUND
358	495605		GASKET SET
363	19203		PULLER, FLYWHEEL
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	225502		CUP, FLYWHEEL
456	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	491435		FILTER, AIR
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR

Ref #	Part Number	Qty	Description
536	494279		AIR CLEANER KIT
542	94897		SCREW
608	499706		STARTER, REWIND
609	265715		SPRING, CHOKE
611	231067		LINE, FUEL
612	391813		FUEL PIPE AND CLIP ASSEMBLY
614	93306		COTTER, HAIR PIN
616			CHECK WITH SUPPLIER
618	262803		SPRING, CHOKE RETURN
621	296110		SWITCH, STOP
621A	396847		SWITCH, STOP
623	94943		P/N CONFLICT - CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
643	280737		SPACER, AIR CLEANER
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
689	263073		SPRING, RETAINER
741	261533		GEAR, TIMING
780	225029		ANCHOR, SPRING
851	493880		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	231348		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
955	281227		PLUG
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	497195		CONTROL, THROTTLE
1036	499329		LABEL KIT, EMISSION
2500	94202-0115		ENGINE
	495914		SHORTBLOCK
	494550		GASKET SET

TILLER - - MODEL NUMBER 5033-84 ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 94202, TYPE NO. 0115-E1




Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214277		HEAD, CYLINDER
7	272694		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
12	270895		GASKET, CRANKCASE .005"
12	270896		GASKET, CRANKCASE .009"
13	94960		SCREW
15	94387		PLUG OIL DRAIN
16	495211		CRANKSHAFT
16	499047		KEY, TIMING GEAR RETAINING
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	281658		PLUG-OIL FILLER
22	94607		SCREW, SEM, MOUNTING
22A	94862		SCREW
23	496278		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	498668		PISTON ASSEMBLY, STANDARD
25	498669		PISTON ASSEMBLY, .010" OVERSIZE
25	498670		PISTON ASSEMBLY, .020" OVERSIZE
25	498671		PISTON ASSEMBLY, .030" OVERSIZE
26	498680		RING SET, STANDARD SIZE
26	498681		RING SET, .010" OVERSIZE
26	498682		RING SET, .020" OVERSIZE
26	498683		RING SET, .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
29	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94699		SCREW
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
38	94736		SCREW
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
51	273113		GASKET, CARBURETOR MOUNTING
53	94523		SCREW, EXHAUST
55	499441		HOUSING, REWIND STARTER
58	281464		ROPE, STARTER
60	393152		HANDLE, REWIND STARTER
65	94904		SCREW, SEMS
73	225381		SCREEN, ROTATING
90	499941		CARBURETOR ASSY
94	231533		VALVE, NEEDLE

Ref #	Part Number	Qty	Description
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	495313		SHAFT & LEVER, THROTTLE
109	497230		VALVE & SHAFT GROUP, CHOKE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
144	499901		PULLEY, STARTER
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
161	492797		BASE, AIR CLEANER
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94919		SCREW, TORX
190A	94924		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	263174		LINK, GOVERNOR
202	262470		LINK, CONTROL
209	260041		SPRING, GOVERNOR
216	263188		LINK, CHOKE
222	499533		BRACKET, CONTROL
257	93543		SCREW, SEMS, HEX HEAD
298	220859		LOCKNUT, MUFFLER
300	493288		MUFFLER, EXHAUST
304	499522		HOUSING, BLOWER
305	94786		SCREW
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	496914		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	497298		WIRE, GROUND
358	495605		GASKET SET
363	19203		PULLER, FLYWHEEL
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	225502		CUP, FLYWHEEL
456	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	491435		FILTER, AIR
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR

Ref #	Part Number	Qty	Description
536	494279		AIR CLEANER KIT
542	94897		SCREW
608	499706		STARTER, REWIND
609	265715		SPRING, CHOKE
611	231067		LINE, FUEL
612	391813		FUEL PIPE AND CLIP ASSEMBLY
614	93306		COTTER, HAIR PIN
616			CHECK WITH SUPPLIER
618	262803		SPRING, CHOKE RETURN
621	296110		SWITCH, STOP
621A	396847		SWITCH, STOP
623	94943		P/N CONFLICT - CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
643	280737		SPACER, AIR CLEANER
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
689	263073		SPRING, RETAINER
741	261533		GEAR, TIMING
780	225029		ANCHOR, SPRING
851	493880		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	231348		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
955	281227		PLUG
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	497195		CONTROL, THROTTLE
1036	499329		LABEL KIT, EMISSION
2500	94202-0115		ENGINE
	495914		SHORTBLOCK
	494550		GASKET SET

TILLER - - MODEL NUMBER 5033-84
ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 94202, TYPE NO. 0115-E1




Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214277		HEAD, CYLINDER
7	272694		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
12	270895		GASKET, CRANKCASE .005"
12	270896		GASKET, CRANKCASE .009"
13	94960		SCREW
15	94387		PLUG OIL DRAIN
16	495211		CRANKSHAFT
16	499047		KEY, TIMING GEAR RETAINING
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	281658		PLUG-OIL FILLER
22	94607		SCREW, SEM, MOUNTING
22A	94862		SCREW
23	496278		FLYWHEEL
24	222698		KEY, FLYWHEEL
25	498668		PISTON ASSEMBLY, STANDARD
25	498669		PISTON ASSEMBLY, .010" OVERSIZE
25	498670		PISTON ASSEMBLY, .020" OVERSIZE
25	498671		PISTON ASSEMBLY, .030" OVERSIZE
26	498680		RING SET, STANDARD SIZE
26	498681		RING SET, .010" OVERSIZE
26	498682		RING SET, .020" OVERSIZE
26	498683		RING SET, .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
29	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94699		SCREW
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
38	94736		SCREW
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
51	273113		GASKET, CARBURETOR MOUNTING
53	94523		SCREW, EXHAUST
55	499441		HOUSING, REWIND STARTER
58	281464		ROPE, STARTER
60	393152		HANDLE, REWIND STARTER
65	94904		SCREW, SEMS
73	225381		SCREEN, ROTATING
90	499941		CARBURETOR ASSY
94	231533		VALVE, NEEDLE

Ref #	Part Number	Qty	Description
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	495313		SHAFT & LEVER, THROTTLE
109	497230		VALVE & SHAFT GROUP, CHOKE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
144	499901		PULLEY, STARTER
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
161	492797		BASE, AIR CLEANER
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94919		SCREW, TORX
190A	94924		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	263174		LINK, GOVERNOR
202	262470		LINK, CONTROL
209	260041		SPRING, GOVERNOR
216	263188		LINK, CHOKE
222	499533		BRACKET, CONTROL
257	93543		SCREW, SEMS, HEX HEAD
298	220859		LOCKNUT, MUFFLER
300	493288		MUFFLER, EXHAUST
304	499522		HOUSING, BLOWER
305	94786		SCREW
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	496914		ARMATURE, MAGNETO
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	497298		WIRE, GROUND
358	495605		GASKET SET
363	19203		PULLER, FLYWHEEL
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	225502		CUP, FLYWHEEL
456	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	491435		FILTER, AIR
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR

Ref #	Part Number	Qty	Description
536	494279		AIR CLEANER KIT
542	94897		SCREW
608	499706		STARTER, REWIND
609	265715		SPRING, CHOKE
611	231067		LINE, FUEL
612	391813		FUEL PIPE AND CLIP ASSEMBLY
614	93306		COTTER, HAIR PIN
616			CHECK WITH SUPPLIER
618	262803		SPRING, CHOKE RETURN
621	296110		SWITCH, STOP
621A	396847		SWITCH, STOP
623	94943		P/N CONFLICT - CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
643	280737		SPACER, AIR CLEANER
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
689	263073		SPRING, RETAINER
741	261533		GEAR, TIMING
780	225029		ANCHOR, SPRING
851	493880		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	231348		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
955	281227		PLUG
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	497195		CONTROL, THROTTLE
1036	499329		LABEL KIT, EMISSION
2500	94202-0115		ENGINE
	495914		SHORTBLOCK
	494550		GASKET SET


TILLER - - MODEL NUMBER 5033-84

HANDLE ASSEMBLY




NOTE: All component dimensions are given in U.S. Inches.
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	137176X424		BRACKET.HANDLE
2	72140512		BOLT
3	73680500		SUB= 73690500
4	19111116		WASHER
5	151473		HANDLE LH
6	9266R		SUB= 624A78
7	74760524		BOLT.HEX.5/16-1.5
8	3069J		SUB= 164937
9	8206H		GRIP T
11	3067J		SUB= 100382K
12	3070J		SPRING EXT TI
13	19121414		WASHER
14	74760516		SUB= 77394
15	74760512		BOLT
16	10040500		LOCKWASHER
17	73220500		NUT.HEX.5/16-18
18	98000129		NUT
19	72140506		BOLT
20	9209R424		PANEL.HANDLE
22	151474		HANDLE RH
23	19131312		WASHER



TILLER - - MODEL NUMBER 5033-84

TINE ASSEMBLY




Ref #	Part Number	Qty	Description
1	106860X		TINE ASSY RH
2	4921H		SPRING.RETAINER
3	106858X		TINE ASSY RH
4	106857X		TINE INN LH TI
5	106859X		TINE ASS'Y LH
6	9194R		DRILLED RIVET RT




TILLER - - MODEL NUMBER 5033-84

TRANSMISSION




NOTE: All component dimensions given in U.S. Inches.
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	74610412		BOLT
2	10040400		LOCKWASHER
3	19092016		WASHER
4	19091412		WASHER
5	74760544		SUB= 74780544
6	2606J424		"BRKT,ENG RH"
7	9173R		SPLIT SPACER RT
8	132212X424		SUPPORT ENGINE LH
9	10040500		LOCKWASHER
10	73220500		NUT.HEX.5/16-18
11	19131311		WASHER
13	73800600		NUT
14	151937		SUB= 165810
15	73510500		NUT
16	74780652		BOLT HEX 3/8-16
17	74760524		BOLT.HEX.5/16-1.5
18			CHECK WITH SUPPLIER



TILLER - - MODEL NUMBER 5033-84

WHEEL AND DEPTH STAKE ASSEMBLY



Ref #	Part Number	Qty	Description
1	74760520		BOLT
2	73220500		NUT.HEX.5/16-18
3	10040500		LOCKWASHER
4	19121414		WASHER
5	4921H		SPRING.RETAINER
6	74780628		BOLT
7	318J		STAKE.SUPT.TILLER
8	9193R		SUB= 9193R500
9	73800600		NUT
10	9551R		DRILLED RIVET RT
11	317J		SUB= 317J500
12	74760512		BOLT
13	325J		STAKE SPRING CT
14	121117X		BOLT SHOULDER
15	9186R		SUB= STD333760
16	19131311		WASHER
17	9189R		SUB= 674H4
18	73680600		SUB= 73690600
19	73800500		NUT
20	74760524		BOLT.HEX.5/16-1.5

