


DECALS




Ref #	Part Number	Qty	Description
1	137457		DECAL.PNL.CNT.
2	137458		DECAL.SHLD.TINE
3	137459		DECAL.GD.BELT 3.5
4	136943		DECAL.INSTRUCTION
5	120431X		DECAL TI
6	102180X		DECAL CRT
7	110593X		SUB= 121858X
8	126230X		"DECAL,ENG HP"
9	120075X		DECAL TI
	137168		NLA



Engine Parts 3.5 HP Model 91202-0126-01


Specify Model and Part
Number When Ordering



Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	213942		HEAD, CYLINDER
7	272536		GASKET, CYLINDER HEAD
8	294178		BREATHER, VALVE CHAMBER
9	27549		GASKET, VALVE COVER
10	93394		SCREW, SEMS, BREATHER, MOUNTING
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
	270895		GASKET, CRANKCASE .005"
	270896		GASKET, CRANKCASE .009"
13	93111		SCREW, CYLINDER HEAD
15	94387		PLUG OIL DRAIN
	93448		PLUG, PIPE, HEX SOCKET
16	492880		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94607		SCREW, SEM, MOUNTING
23	296884		KEY, FLYWHEEL
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94404		SCREW, CONNECTING ROD
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
53	94523		SCREW, EXHAUST
56	280439		PULLEY, STARTER
57	490179		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
60	393152		HANDLE, REWIND STARTER
66	399671		CLUTCH ASSEMBLY, REWIND STARTER
67	394897		HOUSING, STARTER CLUTCH
68	63770		BALL, CLUTCH
70	298799		STARTER, REWIND


Ref #	Part Number	Qty	Description
71	394506		WASHER, CLUTCH RETAINER
73	221661		SCREEN, REWIND STARTER
74	93758		SCREW, SEMS
75	223047		WASHER, SPRING
90	492645		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490371		SHAFT AND LEVER, THROTTLE
108	490495		VALVE GROUP, CHOKE
118	231533		VALVE, NEEDLE
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
156	492905		LEVER, SPEED ADJUSTER, FIXED SPEED
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	262325		LINK, AIR VANE GOVERNOR
209	262317		SPRING, AIR VANE GOVERNOR
216	262359		LINK, CHOKE
222	490649		PANEL, CONTROL
298	220859		LOCKNUT, MUFFLER
299	493288		MUFFLER, EXHAUST
676	393756		DEFLECTOR, MUFFLER
305A	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
333	398593		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	494550		GASKET SET
363	19069		PULLEY, FLYWHEEL
383	262328		SPRING, FUEL PUMP DIAPHRAGM
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	270026		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	210959		COVER, DIAPHRAGM
467	280715		KNOB, CONTROL
526	94408		SCREW SEMS TANK BRKT MOUNT
527	223786		CLAMP BREATHER TUBE
528	231527		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
536	494279		AIR CLEANER KIT
541	22398		WASHER, SPEED ADJUSTER LEVEL
542	94269		SCREW, AIR CLEANER
608	491046		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY

Ref #	Part Number	Qty	Description
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261533		GEAR, TIMING
779	262276		LINK, CONTROL
851	221798		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	223765		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1016	490817		SPACER



Engine Parts 3.5 HP Model 91202-0126-01


Specify Model and Part
Number When Ordering



Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	213942		HEAD, CYLINDER
7	272536		GASKET, CYLINDER HEAD
8	294178		BREATHER, VALVE CHAMBER
9	27549		GASKET, VALVE COVER
10	93394		SCREW, SEMS, BREATHER, MOUNTING
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
	270895		GASKET, CRANKCASE .005"
	270896		GASKET, CRANKCASE .009"
13	93111		SCREW, CYLINDER HEAD
15	94387		PLUG OIL DRAIN
	93448		PLUG, PIPE, HEX SOCKET
16	492880		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94607		SCREW, SEM, MOUNTING
23	296884		KEY, FLYWHEEL
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94404		SCREW, CONNECTING ROD
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
53	94523		SCREW, EXHAUST
56	280439		PULLEY, STARTER
57	490179		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
60	393152		HANDLE, REWIND STARTER
66	399671		CLUTCH ASSEMBLY, REWIND STARTER
67	394897		HOUSING, STARTER CLUTCH
68	63770		BALL, CLUTCH
70	298799		STARTER, REWIND


Ref #	Part Number	Qty	Description
71	394506		WASHER, CLUTCH RETAINER
73	221661		SCREEN, REWIND STARTER
74	93758		SCREW, SEMS
75	223047		WASHER, SPRING
90	492645		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490371		SHAFT AND LEVER, THROTTLE
108	490495		VALVE GROUP, CHOKE
118	231533		VALVE, NEEDLE
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
156	492905		LEVER, SPEED ADJUSTER, FIXED SPEED
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	262325		LINK, AIR VANE GOVERNOR
209	262317		SPRING, AIR VANE GOVERNOR
216	262359		LINK, CHOKE
222	490649		PANEL, CONTROL
298	220859		LOCKNUT, MUFFLER
299	493288		MUFFLER, EXHAUST
676	393756		DEFLECTOR, MUFFLER
305A	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
333	398593		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	494550		GASKET SET
363	19069		PULLEY, FLYWHEEL
383	262328		SPRING, FUEL PUMP DIAPHRAGM
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	270026		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	210959		COVER, DIAPHRAGM
467	280715		KNOB, CONTROL
526	94408		SCREW SEMS TANK BRKT MOUNT
527	223786		CLAMP BREATHER TUBE
528	231527		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
536	494279		AIR CLEANER KIT
541	22398		WASHER, SPEED ADJUSTER LEVEL
542	94269		SCREW, AIR CLEANER
608	491046		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY

Ref #	Part Number	Qty	Description
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261533		GEAR, TIMING
779	262276		LINK, CONTROL
851	221798		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	223765		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1016	490817		SPACER



Engine Parts 3.5 HP Model 91202-0128-01

Specify Model and Part
Number When Ordering




Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	213942		HEAD, CYLINDER
7	272536		GASKET, CYLINDER HEAD
8	294178		BREATHER, VALVE CHAMBER
9	27549		GASKET, VALVE COVER
10	93394		SCREW, SEMS, BREATHER, MOUNTING
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
	270895		GASKET, CRANKCASE .005"
	270896		GASKET, CRANKCASE .009"
13	93111		SCREW, CYLINDER HEAD
15	94387		PLUG OIL DRAIN
	93448		PLUG, PIPE, HEX SOCKET
16	492880		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94607		SCREW, SEM, MOUNTING
23	296884		KEY, FLYWHEEL
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94404		SCREW, CONNECTING ROD
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
53	94523		SCREW, EXHAUST
56	280439		PULLEY, STARTER
57	490179		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
60	393152		HANDLE, REWIND STARTER
66	399671		CLUTCH ASSEMBLY, REWIND STARTER
67	394897		HOUSING, STARTER CLUTCH
68	63770		BALL, CLUTCH
70	298799		STARTER, REWIND

Ref #	Part Number	Qty	Description
71	394506		WASHER, CLUTCH RETAINER
73	221661		SCREEN, REWIND STARTER
74	93758		SCREW, SEMS
75	223047		WASHER, SPRING
90	492645		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490371		SHAFT AND LEVER, THROTTLE
108	490495		VALVE GROUP, CHOKE
118	231533		VALVE, NEEDLE
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
156	492905		LEVER, SPEED ADJUSTER, FIXED SPEED
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	262325		LINK, AIR VANE GOVERNOR
209	262317		SPRING, AIR VANE GOVERNOR
216	262359		LINK, CHOKE
222	490649		PANEL, CONTROL
298	220859		LOCKNUT, MUFFLER
299	493288		MUFFLER, EXHAUST
676	393756		DEFLECTOR, MUFFLER
305A	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
333	398593		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	494550		GASKET SET
363	19069		PULLEY, FLYWHEEL
383	262328		SPRING, FUEL PUMP DIAPHRAGM
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	270026		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	210959		COVER, DIAPHRAGM
467	280715		KNOB, CONTROL
526	94408		SCREW SEMS TANK BRKT MOUNT
527	223786		CLAMP BREATHER TUBE
528	231527		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
536	494279		AIR CLEANER KIT
541	22398		WASHER, SPEED ADJUSTER LEVEL
542	94269		SCREW, AIR CLEANER
608	491046		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY

Ref #	Part Number	Qty	Description
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261533		GEAR, TIMING
779	262276		LINK, CONTROL
851	221798		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	223765		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1016	490817		SPACER


HANDLE ASSEMBLY



NOTE: All component dimensions given in U.S. inches.
1 Inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	71091008		SCREW
2	126951X		"PANEL,CONT TI"
3	104164X		TIE CABLE CRT
4	8206H		GRIP T
5	4497H		RETAINER M
6	81328		SHOULDER BOLT ST
7	109335X		SHIFT HANDLE CRT
8	109313X		GROMMET CRT
9	109337X		SHIFT ROD CRT
10	72110608		BOLT D
11	109229X		LOCK CRT
12	73930600		LOCKNUT
13	19131611		WASHER CRT
14	109228X		LEVER LOCK CRT
15	127013X473		SUB= 155117
16	10040400		LOCKWASHER
17	73220400		SUB= 50675
18	73731000		NUT
19	102162X		CABLE.CLUTCH.CRT
20	9484R		CONDIUT CLIP T
21	86777		SUB= 750097
22	102604X		GRIP BAR CRT
23	102744X		SUB= 102744X431
24	105216X		"ASSY CONTROL, BAR"
25	127012X		"CONT,THROTTLE"
26	72140404		BOLT
27	9266R		SUB= 624A78


MAINFRAME, LEFT SIDE



NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	73510500		NUT
2	10040600		LOCKWASHER
3	73220600		NUT.HEX.3/8-16UNC
4	74930568		BOLT TI
5	1572H		SUB= 2882J
6	110111X		LEVER ASM CRT
7	72110404		BOLT
8	8700J		PANEL TI
9	86777		SUB= 750097
10	9484R		CONDIUT CLIP T
11	10040400		LOCKWASHER
12	73220400		SUB= 50675
13	23230506		SET SCREW
14	120938X		SPACER
15	19111116		WASHER
16	100473M		"SHEAVE 10" CRT"
17	73220500		NUT.HEX.5/16-18
18	110651X		SPACER CRT
19	2649M		KEY T
20	110653X		GUARD CRT
21	131691		SPLIT SPACER
22	104214X		NUT TI
23	102190X		TIRE.CHV.13X5.0-6
	124258X		RIM
	795R		SUB= 65139
24	126875X		RIVET.DRILL.1.75
25	4497H		RETAINER M
26	131159X473		"GUARD, BELT"
27	132672		BELT-V
28	104679X		PULLEY-IDLER TI
29	12000032		KLIP RING
30	105611X		SUB= 918105611X
31	102384X		BOLT CRT
32	102141X		SHIFT ARM CRT
33	74760616		BOLT
34	102383X		COUNTERWEIGHT CRT
35	74760524		BOLT.HEX.5/16-1.5
36	102331X		BRACKET LH CRT
37	130816		ENGINE SHEAVE
38	131558		BELT GUARD BRKT


MAINFRAME, RIGHT SIDE



Ref #	Part Number	Qty	Description
1	73510500		NUT
2	102332X		BRACKET RH CRT
3	74760524		BOLT.HEX.5/16-1.5
4	102173X		COUNTERWEIGHT CRT
5	10040600		LOCKWASHER
6	73220600		NUT.HEX.3/8-16UNC
7	4497H		RETAINER M
8	126875X		RIVET.DRILL.1.75
9	102190X		TIRE.CHV.13X5.0-6
	124258X		RIM
	795R		SUB= 65139
10			REFER TO IMAGE




TINE ASSEMBLY




Ref #	Part Number	Qty	Description
1	73610600		SUB= 7810H
2	10040600		LOCKWASHER
3	4460J		SUB= 6555J
4	74610616		BOLT
5	132673		PIN.CLEVIS.SHEAR
6	3146R		RETAINER.SPRING
7	132722		ASM HUB&PLATE RH
8	6555J		"TINE.RH.12""
9	6554J		"TINE.LH.12""
10	132721		ASM HUB&PLATE LH
11	4459J		SUB= 6554J




TINE SHIELD



Ref #	Part Number	Qty	Description
1	98000129		NUT
2	104086X473		SHIELD.SD.OUT.LH
3	8393J		STAKE PIN TI
4	12000036		KLIP RING TI
5	72110508		BOLT CRT
6	8394J		SPRING TI
7	8392J		LATCH BRACKET TI
8	109230X		SPRING CRT
9	102152X473		SHIELD.TINE
10	72140506		BOLT
11	73220500		NUT.HEX.5/16-18
12	10040500		LOCKWASHER
13	72110510		BOLT
14	124343X		BRKT SHIELD TINE
15	104101X473		SUB= 104101X421
16	73220400		SUB= 50675
17	10040400		LOCKWASHER
18	72040410		BOLT
19	102701X		GRIP CRT
20	73220600		NUT.HEX.3/8-16UNC
21	102156X		SUB= 102156X500
22	74930632		BOLT
23	4440J		HINGE CRT
24	72140404		BOLT
25	6712J		VINYL CAP TI
26	109227X		PAD IDLER TI
27	102686X473		SHIELD.LEVELING
28	120588X		PIN HINGE
29	104085X473		"SHIELD, SIDE"



TRANSMISSION



Ref #	Part Number	Qty	Description
1	137555		SUB= 155112
2	121147X		SUB= 150698
3	106211X		GASKET TI
4	5020J		NEEDLE BRNG LT
5	1370H		"T, BEARING"
6	102113X		PINION-INPUT CRT
7	102110X		SHAFT-INPUT CRT
8	4895H		"TI, BEARING"
9	102136X		WASHER SEAL CRT
10	7392M		SUB= 100482K
11	100371K		SPRING-SHIFT CRT
12	106160X		O-RING TI
13	102107X		ARM ASSY CRT
14	8353J		SHIFT FORK TI
15	12000039		KLIP RING
16	102109X		SHAFT SHIFT CRT
17	104159X		SPACER SPLIT CRT
18	4358J		WASHER
19	12000040		KLIP RING
20	102114X		GEAR ASSY CRT
21	102115X		GEAR-REV IDLR CRT
22	6803J		NEEDLE BEARING TI
23	102111X		SHAFT CRT
24	10040700		LOCKWASHER
25	73610700		NUT.ASF.HEX.7/16
26	102128X		O RING CRT
27	102100X		"CRT, BEARING"
28	106390X		BUSHING TI
29	102134X		CHAIN CRT
30	109204X		SUB= 150737
31	102106X		SUB= 918102106X
32	106388X		SPACER TI
33	102121X		SPRCKT 8 GEAR CRT
34	102112X		SHFT 2ND RED. CRT
35	102101X		SCRW WHIZ LOK CRT
36	137300		SPROCKET ASM.
37	4422J		BEARING
38	137301		SUB= 137300
39	105345X		GEAR TI
40	105346X		GEAR TI
41	8358J		REDUCTION SHFT TI
42	4220R		BRNG RACE
43	106146X		SPACER TI
44	9672R		CUP.FORMED.
45	102144X		RING SPIRAL CRT
46	9676R		SUB= 147344
47	9674R		SUB= 147344
48	121745X		SUB= 150700
49	132688		TINE SHAFT
50	106147X		CHAIN.50 LINK TI
51	17580408		SCREW CRT
52	73220500		NUT.HEX.5/16-18