



# TILLER - - MODEL NUMBER AYP3332A79

## BELT GUARD AND PULLEY ASSEMBLY

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm




Ref #	Part Number	Qty	Description
1	23230506		SET SCREW
2	130811		SUB= 532130811
3	122955X		BRKT ASSY
4	72140404		BOLT
5	74770812		SCREW
6	121463X		KEEPER BELT
7	104213X		NUT-CAP TI
8	19091016		WASHER
9	131157X505		BELT GUARD
10	109227X		PAD IDLER TI
11	72140406		BOLT T
12	9179R		SUB= TH3H390
13	12000028		SUB= 2267J
14	151939		PULLEY.TRANSMISSN
15	132213		SUB= 532132213
16	12000036		KLIP RING TI
17	73350600		NUT
18	9178R		SUB= 75673
19	674A30		IDLER ARM TI
20	74760620		SUB= 74780620
21	106968X		SHAFT IDLER TI
22	105358X		SHIELD-DIRT TI
23	10040400		LOCKWASHER
24	73220400		SUB= 50675
25	73350500		JAM NUT TI



## TILLER - - MODEL NUMBER AYP3332A79

### DECALS




Ref #	Part Number	Qty	Description
1	157695		DECAL PANEL CONT
2	157703		DECAL.LOGO
3	127521		NLA
4	110594X		DECAL TI
5	120431X		DECAL TI
6	110593X		SUB= 121858X
7	120075X		DECAL TI
	157732		MANL.O.3332A80.E



### TILLER - - MODEL NUMBER AYP3332A79


### ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 91202, TYPE NO. 0126-01



Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	213942		HEAD, CYLINDER
7	272536		GASKET, CYLINDER HEAD
8	294178		BREATHER, VALVE CHAMBER
9	27549		GASKET, VALVE COVER
10	93394		SCREW, SEMS, BREATHER, MOUNTING
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
12A	270895		GASKET, CRANKCASE .005"
12B	270896		GASKET, CRANKCASE .009"
13	93111		SCREW, CYLINDER HEAD
15	94387		PLUG OIL DRAIN
15A	93448		PLUG, PIPE, HEX SOCKET
16	492880		CRANKSHAFT
16A	230978		CRANKSHAFT GEAR PIN
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94607		SCREW, SEM, MOUNTING
23	296884		KEY, FLYWHEEL
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
25A	298905		PISTON ASSEMBLY .010" OVERSIZE
25B	298906		PISTON ASSEMBLY .020" OVERSIZE
25C	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
26A	298983		RING SET, PISTON .010" OVERSIZE
26B	298984		RING SET, PISTON .020" OVERSIZE
26C	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28A	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
29A	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94404		SCREW, CONNECTING ROD
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
53	94523		SCREW, EXHAUST
56	280439		PULLEY, STARTER
57	490179		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
60	393152		HANDLE, REWIND STARTER
66	399671		CLUTCH ASSEMBLY, REWIND STARTER
67	394897		HOUSING, STARTER CLUTCH
68	63770		BALL, CLUTCH
70	298799		STARTER, REWIND

Ref #	Part Number	Qty	Description
71	394506		WASHER, CLUTCH RETAINER
73	221661		SCREEN, REWIND STARTER
74	93758		SCREW, SEMS
75	223047		WASHER, SPRING
90	492645		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490371		SHAFT AND LEVER, THROTTLE
108	490495		VALVE GROUP, CHOKE
118	231533		VALVE, NEEDLE
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
156	492905		LEVER, SPEED ADJUSTER, FIXED SPEED
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	262325		LINK, AIR VANE GOVERNOR
209	262317		SPRING, AIR VANE GOVERNOR
216	262359		LINK, CHOKE
222	490649		PANEL, CONTROL
298	220859		LOCKNUT, MUFFLER
299	493288		MUFFLER, EXHAUST
305	94608		SCREW, SEMS
305A	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
333	398593		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	494550		GASKET SET
363	19069		PULLEY, FLYWHEEL
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	270026		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	210959		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
467	280715		KNOB, CONTROL
526	94408		SCREW SEMS TANK BRKT MOUNT
527	223786		CLAMP BREATHER TUBE
528	231527		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
536	494279		AIR CLEANER KIT
541	22398		WASHER, SPEED ADJUSTER LEVEL
542	94269		SCREW, AIR CLEANER
608	491046		STARTER ASSEMBLY, REWIND


Ref #	Part Number	Qty	Description
611	391813		FUEL PIPE AND CLIP ASSEMBLY
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393756		DEFLECTOR, MUFFLER
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261533		GEAR, TIMING
779	262276		LINK, CONTROL
851	221798		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
871A	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	223765		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1016	490817		SPACER





### TILLER - - MODEL NUMBER AYP3332A79

### ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 91202, TYPE NO. 0126-01




Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	213942		HEAD, CYLINDER
7	272536		GASKET, CYLINDER HEAD
8	294178		BREATHER, VALVE CHAMBER
9	27549		GASKET, VALVE COVER
10	93394		SCREW, SEMS, BREATHER, MOUNTING
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
12A	270895		GASKET, CRANKCASE .005"
12B	270896		GASKET, CRANKCASE .009"
13	93111		SCREW, CYLINDER HEAD
15	94387		PLUG OIL DRAIN
15A	93448		PLUG, PIPE, HEX SOCKET
16	492880		CRANKSHAFT
16A	230978		CRANKSHAFT GEAR PIN
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94607		SCREW, SEM, MOUNTING
23	296884		KEY, FLYWHEEL
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
25A	298905		PISTON ASSEMBLY .010" OVERSIZE
25B	298906		PISTON ASSEMBLY .020" OVERSIZE
25C	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
26A	298983		RING SET, PISTON .010" OVERSIZE
26B	298984		RING SET, PISTON .020" OVERSIZE
26C	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28A	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
29A	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94404		SCREW, CONNECTING ROD
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
53	94523		SCREW, EXHAUST
56	280439		PULLEY, STARTER
57	490179		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
60	393152		HANDLE, REWIND STARTER
66	399671		CLUTCH ASSEMBLY, REWIND STARTER
67	394897		HOUSING, STARTER CLUTCH
68	63770		BALL, CLUTCH
70	298799		SCREW, REWIND STARTER

Ref #	Part Number	Qty	Description
71	394506		WASHER, CLUTCH RETAINER
73	221661		SCREEN, REWIND STARTER
74	93758		SCREW, SEMS
75	223047		WASHER, SPRING
90	492645		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490371		SHAFT AND LEVER, THROTTLE
108	490495		VALVE GROUP, CHOKE
118	231533		VALVE, NEEDLE
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
156	492905		LEVER, SPEED ADJUSTER, FIXED SPEED
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	262325		LINK, AIR VANE GOVERNOR
209	262317		SPRING, AIR VANE GOVERNOR
216	262359		LINK, CHOKE
222	490649		PANEL, CONTROL
298	220859		LOCKNUT, MUFFLER
299	493288		MUFFLER, EXHAUST
305	94608		SCREW, SEMS
305A	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
333	398593		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	494550		GASKET SET
363	19069		PULLEY, FLYWHEEL
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	270026		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	210959		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
467	280715		KNOB, CONTROL
526	94408		SCREW SEMS TANK BRKT MOUNT
527	223786		CLAMP BREATHER TUBE
528	231527		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
536	494279		AIR CLEANER KIT
541	22398		WASHER, SPEED ADJUSTER LEVEL
542	94269		SCREW, AIR CLEANER
608	491046		STARTER ASSEMBLY, REWIND

Ref #	Part Number	Qty	Description
611	391813		FUEL PIPE AND CLIP ASSEMBLY
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393756		DEFLECTOR, MUFFLER
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261533		GEAR, TIMING
779	262276		LINK, CONTROL
851	221798		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
871A	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	223765		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1016	490817		SPACER

# TILLER - - MODEL NUMBER AYP3332A79 ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 91202, TYPE NO. 0126-01



Ref #	Part Number	Qty	Description
1	494549		CYLINDER ASSEMBLY
2	293708		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	213942		HEAD, CYLINDER
7	272536		GASKET, CYLINDER HEAD
8	294178		BREATHER, VALVE CHAMBER
9	27549		GASKET, VALVE COVER
10	93394		SCREW, SEMS, BREATHER, MOUNTING
11	66578		GROMMET, BREATHER TUBE
12	270833		GASKET, CRANKCASE, STANDARD .015"
12A	270895		GASKET, CRANKCASE .005"
12B	270896		GASKET, CRANKCASE .009"
13	93111		SCREW, CYLINDER HEAD
15	94387		PLUG OIL DRAIN
15A	93448		PLUG, PIPE, HEX SOCKET
16	492880		CRANKSHAFT
16A	230978		CRANKSHAFT GEAR PIN
18	394820		BUSHING, CRANKCASE COVER
19	293708		BUSHING, CYLINDER
20	299819		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94607		SCREW, SEM, MOUNTING
23	296884		KEY, FLYWHEEL
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
25A	298905		PISTON ASSEMBLY .010" OVERSIZE
25B	298906		PISTON ASSEMBLY .020" OVERSIZE
25C	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
26A	298983		RING SET, PISTON .010" OVERSIZE
26B	298984		RING SET, PISTON .020" OVERSIZE
26C	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28A	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	294367		ROD ASSEMBLY, CONNECTING
29A	296079		ROD ASSEMBLY, CONNECTING .020" UNDERSIZE
			CRANKPIN
30	220670		DIPPER, CONNECTING ROD
32	94404		SCREW, CONNECTING ROD
33	296676		VALVE, EXHAUST
34	296677		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
37	224557		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	230173		TAPPET, VALVE
46	493747		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
53	94523		SCREW, EXHAUST
56	280439		PULLEY, STARTER
57	490179		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
60	393152		HANDLE, REWIND STARTER
66	399671		CLUTCH ASSEMBLY, REWIND STARTER
67	394897		HOUSING, STARTER CLUTCH
68	63770		BALL, CLUTCH
70	298799		STARTER, REWIND




Ref #	Part Number	Qty	Description
71	394506		WASHER, CLUTCH RETAINER
73	221661		SCREEN, REWIND STARTER
74	93758		SCREW, SEMS
75	223047		WASHER, SPRING
90	492645		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490371		SHAFT AND LEVER, THROTTLE
108	490495		VALVE GROUP, CHOKE
118	231533		VALVE, NEEDLE
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490501		SCREW, CARBURETOR CAM AND LEVER
154	93527		SCREW, MACHINE, ROUND HEAD
156	492905		LEVER, SPEED ADJUSTER, FIXED SPEED
163	271935		GASKET, AIR CLEANER MOUNTING
180	495377		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	495213		BLADE, GOVERNOR
201	262325		LINK, AIR VANE GOVERNOR
209	262317		SPRING, AIR VANE GOVERNOR
216	262359		LINK, CHOKE
222	490649		PANEL, CONTROL
298	220859		LOCKNUT, MUFFLER
299	493288		MUFFLER, EXHAUST
305	94608		SCREW, SEMS
305A	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
306	224555		SHIELD, CYLINDER
307	93758		SCREW, SEMS
308	224556		COVER, CYLINDER HEAD
333	398593		ARMATURE, MAGNETO
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	494550		GASKET SET
363	19069		PULLEY, FLYWHEEL
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	270026		DIAPHRAGM
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	210959		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
467	280715		KNOB, CONTROL
526	94408		SCREW SEMS TANK BRKT MOUNT
527	223786		CLAMP BREATHER TUBE
528	231527		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
536	494279		AIR CLEANER KIT
541	22398		WASHER, SPEED ADJUSTER LEVEL
542	94269		SCREW, AIR CLEANER
608	491046		STARTER ASSEMBLY, REWIND

Ref #	Part Number	Qty	Description
611	391813		FUEL PIPE AND CLIP ASSEMBLY
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393756		DEFLECTOR, MUFFLER
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261533		GEAR, TIMING
779	262276		LINK, CONTROL
851	221798		TERMINAL, IGNITION CABLE
864	492232		ADAPTER ASSEMBLY, MUFFLER
869	211172		SEAT, INTAKE VALVE, STANDARD
870	211291		SEAT, EXHAUST VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
871A	63709		GUIDE, INTAKE VALVE
883	272203		GASKET, MUFFLER
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	223765		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1016	490817		SPACER




# TILLER - - MODEL NUMBER AYP3332A79

## HANDLE ASSEMBLY




NOTE: All component dimensions are given in U.S. inches.  
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	137176X505		HANDLE BRKT
2	72140512		BOLT
3	73680500		SUB= 73690500
4	19111116		WASHER
5	151473		HANDLE LH
6	9266R		SUB= 624A78
7	74760524		BOLT.HEX.5/16-1.5
8	3069J		SUB= 164937
9	8206H		GRIP T
11	3067J		SUB= 100382K
12	3070J		SPRING EXT TI
13	19121414		WASHER
14	74760516		SUB= 77394
15	74760512		BOLT
16	10040500		LOCKWASHER
17	73220500		NUT.HEX.5/16-18
18	98000129		NUT
19	72140506		BOLT
20	9209R505		PANEL. HANDLE
22	151474		HANDLE RH
23	19131312		WASHER



# TILLER - - MODEL NUMBER AYP3332A79

## TINE ASSEMBLY




Ref #	Part Number	Qty	Description
1	106860X		TINE ASSY RH
2	4921H		SPRING.RETAINER
3	106858X		TINE ASSY RH
4	106857X		TINE INN LH TI
5	106859X		TINE ASS'Y LH
6	9194R		DRILLED RIVET RT




## TILLER - - MODEL NUMBER AYP3332A79

### TRANSMISSION

NOTE: All component dimensions given in U.S. inches  
1 inch = 25.4 mm




Ref #	Part Number	Qty	Description
1	74610412		BOLT
2	10040400		LOCKWASHER
3	19092016		WASHER
4	19091412		WASHER
5	74760544		SUB= 74780544
6	2606J505		ENGINE BRKT RH
7	9173R		SPLIT SPACER RT
8	132212X505		ENGINE BRKT LH
9	10040500		LOCKWASHER
10	73220500		NUT.HEX.5/16-18
11	19131311		WASHER
13	73800600		NUT
14	151937		SUB= 165810
15	73510500		NUT
16	74780652		BOLT HEX 3/8-16
17	74760524		BOLT.HEX.5/16-1.5
18	91202		ENGINE, B&S



## TILLER - - MODEL NUMBER AYP3332A79

### WHEEL AND DEPTH STAKE ASSEMBLY

**NOTE:** All component dimensions given in U.S. Inches.  
1 inch = 25.4 mm



Ref #	Part Number	Qty	Description
1	74760520		BOLT
2	73220500		NUT.HEX.5/16-18
3	10040500		LOCKWASHER
4	19121414		WASHER
5	4921H		SPRING.RETAINER
6	74780628		BOLT
7	318J		STAKE.SUPT.TILLER
8	9193R		SUB= 9193R500
9	73800600		NUT
10	9551R		DRILLED RIVET RT
11	317J		SUB= 317J500
12	74760512		BOLT
13	325J		STAKE SPRING CT
14	121117X		BOLT SHOULDER
15	9186R		SUB= STD333760
16	19131311		WASHER
17	9189R		SUB= 674H4
18	73680600		SUB= 73690600
19	73800500		NUT
20	74760524		BOLT.HEX.5/16-1.5

