



TILLER - - MODEL NUMBER AYP3355A59

BELT GUARD AND PULLEY ASSEMBLY




NOTE: All component dimensions given in U.S. Inches.
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	123643X		SUB= 159268
2	9484R		CONDIUT CLIP T
3	86777		SUB= 750097
4	74770812		SCREW
5	73220600		NUT.HEX.3/8-16UNC
6	19131316		WASHER
7	2009J		PULLEY W/SPACER
8	127180X		ARM.ASM.REV.IDLER
9	74760628		BOLT
10	106970X021		GUARD.BELT.SILKSC
11	19091016		WASHER
12	104213X		NUT-CAP TI
13	72140405		BOLT T
14	133035		BELT-V
15	2614J		SUB= TH3H440
16	23230506		SET SCREW
17	2649M		KEY T
18	2607J		SHEAVE TI
19	110550X		BOLT TI
20	12000036		KLIP RING TI
21	73350600		NUT
22	9178R		SUB= 75673
23	674A30		IDLER ARM TI
24	74760620		SUB= 74780620
25	106968X		SHAFT IDLER TI
26	73350500		JAM NUT TI
27	73220400		SUB= 50675
28	10040400		LOCKWASHER
29	109227X		PAD IDLER TI
30	23200404		SET SCREW
31	101189L		ENGINE PULLEY TI



TILLER - - MODEL NUMBER AYP3355A59


DECALS



Ref #	Part Number	Qty	Description
1	146348		DECAL.CNTRL.PNL.5
2	146355		DECAL.BELT.GUARD
3	148371		DECAL, LOGO
4	127521		NLA
5	121753X		DECAL REVERSE
6	120431X		DECAL TI
7	110593X		SUB= 121858X
8	271948		DECAL, BRIGGS & STRATTON
9	120075X		DECAL TI
	145905		MANUAL.O.3355A59



TILLER - - MODEL NUMBER AYP3355A59
ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 135202, TYPE NO. 0119-01




Ref #	Part Number	Qty	Description
1	395990		CYLINDER ASSEMBLY
2	297565		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
	270125		GASKET, CRANKCASE .005" THICK
	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	93448		PLUG, PIPE, HEX SOCKET
	94387		PLUG OIL DRAIN
16	492088		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	297602		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94682		SCREW
23	297229		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	299742		RING SET, PISTON, CHROME, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
55	494846		HOUSING, REWIND STARTER
56	493824		PULLEY, REWIND STARTER
57	262594		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
69	280973		WASHER

Ref #	Part Number	Qty	Description
69A	224322		WASHER
73	224632		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	495426		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490048		SHAFT AND LEVER THROTTLE
108	491177		VALVE AND SHAFT GROUP, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490589		SCREW AND COLLAR
154	93527		SCREW, MACHINE, ROUND HEAD
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
190A	94677		SCREW, FUEL TANK MOUNTING 1-3/4"
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
	495603		GASKET SET
	495606		CARBURETOR OVERHAUL KIT
204	222962		BUSHING, GOVERNOR LEVER, FLAT
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262283		SPRING, GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
223	223455		LEVER, GOVERNOR CONTROL
224	93491		RIVET, GOVERNOR CONTROL LEVER MOUNTING
227	490374		LEVER ASSEMBLY, GOVERNOR
230	222450		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
257	93543		SCREW, SEMS, HEX HEAD
300	393615		MUFFLER, EXHAUST
304	495759		HOUSING, BLOWER
305	94619		SCREW, SEMS, BLOWER, HOUSING MOUNTING
306	221511		SHIELD, CYLINDER
308	224738		COVER, CYLINDER HEAD
332	92284		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
373	92987		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM

Ref #	Part Number	Qty	Description
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	214021		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	224250		CUP, STARTER
456	224321		RETAINER, REWIND STARTER
459	492833		PAWL, STARTER
461	262626		PIN, STARTER
467	280715		KNOB, CONTROL
515	262625		SPRING, TORSION
526	94659		SCREW,SEMS,TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
542	93572		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
616	231077		CRANK, GOVERNOR
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261696		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	221798		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495357		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1012	490507		RETAINER, LINK
1016	224278		COVER, REWIND STARTER

TILLER -- MODEL NUMBER AYP3355A59
ENGINE, BRIGGS & STRATTON -- MODEL NUMBER 135202, TYPE NO. 0119-01




Ref #	Part Number	Qty	Description
1	395990		CYLINDER ASSEMBLY
2	297565		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
	270125		GASKET, CRANKCASE .005" THICK
	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	93448		PLUG, PIPE, HEX SOCKET
	94387		PLUG OIL DRAIN
16	492088		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	297602		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94682		SCREW
23	297229		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	299742		RING SET, PISTON, CHROME, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
55	494846		HOUSING, REWIND STARTER
56	493824		PULLEY, REWIND STARTER
57	262594		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
69	280973		WASHER

Ref #	Part Number	Qty	Description
69A	224322		WASHER
73	224632		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	495426		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490048		SHAFT AND LEVER THROTTLE
108	491177		VALVE AND SHAFT GROUP, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490589		SCREW AND COLLAR
154	93527		SCREW, MACHINE, ROUND HEAD
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
190A	94677		SCREW, FUEL TANK MOUNTING 1-3/4"
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
	495603		GASKET SET
	495606		CARBURETOR OVERHAUL KIT
204	222962		BUSHING, GOVERNOR LEVER, FLAT
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262283		SPRING, GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
223	223455		LEVER, GOVERNOR CONTROL
224	93491		RIVET, GOVERNOR CONTROL LEVER MOUNTING
227	490374		LEVER ASSEMBLY, GOVERNOR
230	222450		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
257	93543		SCREW, SEMS, HEX HEAD
300	393615		MUFFLER, EXHAUST
304	495759		HOUSING, BLOWER
305	94619		SCREW, SEMS, BLOWER, HOUSING MOUNTING
306	221511		SHIELD, CYLINDER
308	224738		COVER, CYLINDER HEAD
332	92284		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
373	92987		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM

Ref #	Part Number	Qty	Description
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	214021		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	224250		CUP, STARTER
456	224321		RETAINER, REWIND STARTER
459	492833		PAWL, STARTER
461	262626		PIN, STARTER
467	280715		KNOB, CONTROL
515	262625		SPRING, TORSION
526	94659		SCREW,SEMS,TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
542	93572		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
616	231077		CRANK, GOVERNOR
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261696		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	221798		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495357		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1012	490507		RETAINER, LINK
1016	224278		COVER, REWIND STARTER

TILLER -- MODEL NUMBER AYP3355A59 ENGINE, BRIGGS & STRATTON -- MODEL NUMBER 135202, TYPE NO. 0119-01




Ref #	Part Number	Qty	Description
1	395990		CYLINDER ASSEMBLY
2	297565		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
	270125		GASKET, CRANKCASE .005" THICK
	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	93448		PLUG, PIPE, HEX SOCKET
	94387		PLUG OIL DRAIN
16	492088		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	297602		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94682		SCREW
23	297229		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	299742		RING SET, PISTON, CHROME, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
55	494846		HOUSING, REWIND STARTER
56	493824		PULLEY, REWIND STARTER
57	262594		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
69	280973		WASHER

Ref #	Part Number	Qty	Description
69A	224322		WASHER
73	224632		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	495426		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490048		SHAFT AND LEVER THROTTLE
108	491177		VALVE AND SHAFT GROUP, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490589		SCREW AND COLLAR
154	93527		SCREW, MACHINE, ROUND HEAD
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
190A	94677		SCREW, FUEL TANK MOUNTING 1-3/4"
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
	495603		GASKET SET
	495606		CARBURETOR OVERHAUL KIT
204	222962		BUSHING, GOVERNOR LEVER, FLAT
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262283		SPRING, GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
223	223455		LEVER, GOVERNOR CONTROL
224	93491		RIVET, GOVERNOR CONTROL LEVER MOUNTING
227	490374		LEVER ASSEMBLY, GOVERNOR
230	222450		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
257	93543		SCREW, SEMS, HEX HEAD
300	393615		MUFFLER, EXHAUST
304	495759		HOUSING, BLOWER
305	94619		SCREW, SEMS, BLOWER, HOUSING MOUNTING
306	221511		SHIELD, CYLINDER
308	224738		COVER, CYLINDER HEAD
332	92284		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
373	92987		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM

Ref #	Part Number	Qty	Description
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	214021		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	224250		CUP, STARTER
456	224321		RETAINER, REWIND STARTER
459	492833		PAWL, STARTER
461	262626		PIN, STARTER
467	280715		KNOB, CONTROL
515	262625		SPRING, TORSION
526	94659		SCREW,SEMS,TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
542	93572		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
616	231077		CRANK, GOVERNOR
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261696		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	221798		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495357		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1012	490507		RETAINER, LINK
1016	224278		COVER, REWIND STARTER

TILLER - - MODEL NUMBER AYP3355A59

TINE ASSEMBLY




Ref #	Part Number	Qty	Description
1	100746M		TINE WELDMENT TI
2	3146R		RETAINER.SPRING
3	674A43		TINE TI
4	674A42		TINE TI
5	100744M		TINE WELDMENT TI
6	4929H		RIVET.PAN HD.1.75




TILLER - - MODEL NUMBER AYP3355A59

TRANSMISSION




NOTE: All component dimensions given in U.S. inches.
1 Inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	74760524		BOLT.HEX.5/16-1.5
2	74780652		BOLT HEX 3/8-16
3	19131311		WASHER
5	73800600		NUT
6	9057R505		TINE SHIELD
7	1949J500		SUB= 9181949J500
8	110519X500		SUB= 110519X
9	10040500		LOCKWASHER
10	73220500		NUT.HEX.5/16-18
11	74760544		SUB= 74780544
12	126669X		SUB= 532126669
13	19171616		WASHER
14	9173R		SPLIT SPACER RT
15	73510500		NUT
16	19091412		WASHER
17	19092016		WASHER
18	10040400		LOCKWASHER
19	74610412		BOLT
20			REFER TO IMAGE



TILLER - - MODEL NUMBER AYP3355A59

WHEEL AND DEPTH STAKE ASSEMBLY



Ref #	Part Number	Qty	Description
1	9194R		DRILLED RIVET RT
2	74760520		BOLT
3	74760512		BOLT
4	73220500		NUT.HEX.5/16-18
5	10040500		LOCKWASHER
6	73800600		NUT
7	4921H		SPRING.RETAINER
8	1952J500		SUPPORT STAKE RH
9	122233X		SUB= 2582J
10	326J		SUB= 4929H
11	74780628		BOLT
12	74760524		BOLT.HEX.5/16-1.5
13	1951J500		SUPPORT STAKE LH
14	120958X		WASHER
15	5388J		STAKE SPRING TI
16	121117X		BOLT SHOULDER
17	9188R		SUB= 107644X
18	19131311		WASHER
19	9190R500		BRACKET.WHL.PNT.
20	73680600		SUB= 73690600
21	74760516		SUB= 77394
22	73800500		NUT

