





# Stückliste für AL-KO Motorsensen - BC 300 - 110126

|        |                              |
|--------|------------------------------|
| 402028 | SCREW OLD 88060              |
| 402029 | SILENCER FRONT PART          |
| 402030 | COVER                        |
| 402031 | SIEVE                        |
| 402032 | BUSH 98860-A                 |
| 402033 | BOSS 98783                   |
| 402034 | SILENCER REAR PART           |
| 402035 | GASKET USE UP04350           |
| 402041 | SPARK PLUG 96169-S           |
| 402045 | KEY 69250                    |
| 402046 | WASHER/GASKET USE UP04874    |
| 402047 | BUMPER USE 98792             |
| 402049 | GASKET USE UP0554            |
| 402051 | CARBURETTOR FLANGE           |
| 402052 | Screw                        |
| 402053 | Washer/Gasket 98766-A        |
| 402055 | CARB USE A-03002             |
| 402056 | USE A04707A                  |
| 402058 | SCREW                        |
| 402059 | TANK - USE UP00136           |
| 402061 | USE UP04111                  |
| 402068 | Screw 88054                  |
| 402069 | NUT                          |
| 402071 | CLUTCH USE UP04103           |
| 402072 | SCREW 10-24/875 OLD 88052    |
| 402073 | SCREW - USE 82538            |
| 402076 | USE UP04349                  |
| 402077 | HOLDING PLATE OLD 98791      |
| 402078 | SCREW USE 82541              |
| 402085 | STARTER SPRING - USE A98773  |
| 402086 | SCREW USE 82540              |
| 402087 | IGNITION COIL 94711-CS(4020  |
| 402089 | SPARK-PLUG CONNECTOR A-33055 |
| 402099 | WASHER USE 98929A            |
| 402101 | LEAD USE A-00681             |
| 402150 | AIR FILTER D-98760-A         |
| 402151 | FILTER USE 49422             |
| 402153 | CLAMP USE 98268              |
| 406059 | Washer/Gasket (406059)       |
| 406061 | COVER USE A-00858            |
| 406062 | FUEL PIPE                    |
| 406063 | TUBING - USE UP03825         |
| 406066 | FLY WHEEL                    |
| 406068 | SCREW 82568                  |
| 406070 | WASHER 95479-A               |
| 406072 | BLADE CLIP OLD 02851         |
| 406076 | STARTER BAR                  |
| 406077 | MOTOR BRACKET A-02396-A      |
| 406154 | CYLINDER KPL. A-04743        |
| 406155 | CYLINDER KIT USE A-04740-C   |
| 406157 | PISTON - USE UP03366         |
| 406158 | PISTON RING 98170            |

|        |                           |
|--------|---------------------------|
| 402091 | SCREW 88049               |
| 402118 | USE UP06567               |
| 402119 | USE UP06526               |
| 402129 | BLADE USE 988472          |
| 402132 | SCREW 88053               |
| 402133 | BLADE BOSS USE 04409      |
| 402134 | NUT L. USE UP04127        |
| 402141 | BRACKET USE A94442        |
| 402142 | WING SCREW 82260          |
| 402145 | GRIP USE A-06261          |
| 402147 | DRIVE SHAFT               |
| 402167 | TIE USE 46840             |
| 403136 | BLADE USE D-98717-B       |
| 406069 | 406069                    |
| 406078 | HOUSING DRIVE SHAFT       |
| 406079 | CRANKCASE (406079)        |
| 406080 | FLANGE USE 04168A         |
| 406081 | LOCATING PIN 98551-41     |
| 406082 | THREADSPULE               |
| 406083 | RETAINER - USE UP03209    |
| 406158 | DEFLECTOR KIT USE 406159  |
| 406159 | DEFLECTOR USE A0436203    |
| 406160 | Screw 82298               |
| 406161 | WASHER 83046(406161)      |
| 406162 | BOSS COMP. A-03404        |
| 406163 | THROTTLE CABLE USE A03005 |
| 406164 | ACCELERATOR PEDAL A-0     |
| 406165 | SWITCH A-03275            |
| 406166 | SLEEVE 00684              |
| 406167 | BRACKET COMP. A-00592-1   |
| 406168 | SCREW 00605               |
| 406170 | SCREW 00607               |
| 406171 | HANDLE ROD LH A-03268     |
| 406172 | HANDLE ROD RHS USE A03005 |
| 406461 | WASHER USE 04516          |
| 406532 | NO LONGER AVAILABLE       |