


Pos.	Part No.		Fos.	Part No.		Pos.	Part No.	
1	21.12.040	Schraube	95	37.41.260	Verchlussstopfen	1	21.12.040	Schraube
2	21.12.310	Schraube	96	37.43.100	Sicherheitshebel	2	21.12.310	Schraube
3	21.22.010	Schraube	97	37.43.110	Gashebel	3	21.22.010	Schraube
4	21.22.040	Schraube	98	37.43.120	Choke hebel	4	21.22.040	Schraube
5	21.22.060	Schraube	99	37.44.070	A.V. Einsatzstück	5	21.22.060	Schraube
6	21.22.190	Schraube	100	37.45.070	Gummiführung	6	21.22.190	Schraube
7	21.22.250	Schraube	101	37.45.160	Gummidichtung	7	21.22.250	Schraube
8	21.22.260	Schraube	102	37.45.170	Gummidichtung	8	21.22.260	Schraube
9	21.22.270	Schraube	103	37.45.180	Gummidichtung	9	21.22.270	Schraube
10	21.22.280	Schraube	104	37.45.200	Gummidichtung	10	21.22.280	Schraube
11	21.22.300	Schraube	105	37.45.210	Gummiführung	11	21.22.300	Schraube
12	21.32.040	Schraube	106	37.48.020	Filterhalter	12	21.32.040	Schraube
13	21.32.220	Schraube	107	37.48.121	Drehknopf	13	21.32.220	Schraube
14	21.42.010	Schraube	108	37.48.230	Kabelschuh	14	21.42.010	Schraube
15	21.42.020	Schraube	109	37.48.290	Distanzstück	15	21.42.020	Schraube
16	21.42.030	Schraube	110	37.48.300	Büchse	16	21.42.030	Schraube
17	21.42.060	Schraube	111	37.48.310	Handgriff	17	21.42.060	Schraube
18	21.42.130	Schraube	112	37.62.330	Typenschild	18	21.42.130	Schraube
19	21.62.110	Schraube	113	37.62.340	Typenschild	19	21.62.110	Schraube
20	23.12.080	Scheibe	114	37.62.350	Typenschild	20	23.12.080	Scheibe
21	23.12.090	Scheibe	115	37.62.360	Typenschild	21	23.12.090	Scheibe
22	23.12.150	Scheibe	116	37.81.090	Luftfilter	22	23.12.150	Scheibe
23	23.21.020	Scheibe	117	37.82.190	Kabelschutz	23	23.21.020	Scheibe
24	23.21.160	Scheibe	118	37.82.210	Brennstoffleitung	24	23.21.160	Scheibe
25	23.21.180	Scheibe	119	37.82.230	Brennstoffleitung	25	23.21.180	Scheibe
26	23.30.020	Scheibe	120	37.83.020	Filter	26	23.30.020	Scheibe
27	23.60.010	Scheibe	121	37.83.050	Filter	27	23.60.010	Scheibe
28	23.82.100	Büchse	122	37.84.020	Startschmur	28	23.82.100	Büchse
29	24.12.031	Mutter	123	41.20.310	Schraube	29	24.12.031	Mutter
30	24.32.030	Mutter	124	41.20.570	A.V. Schraube	30	24.32.030	Mutter
31	24.32.040	Mutter	125	41.20.570	A.V. Schraube	31	24.32.040	Mutter
32	24.32.050	Mutter	126	41.20.730	Zylinderdeckel	32	24.32.050	Mutter
33	24.33.010	Mutter	127	41.20.740	Schalldämpfer	33	24.33.010	Mutter
34	26.10.080	Haltebolzen	128	41.20.750	Rohr	34	26.10.080	Haltebolzen
35	26.52.050	Schraube	129	41.20.780	Handschütz	35	26.52.050	Schraube
36	26.52.190	Schraube	130	41.20.770	Starterwelle	36	26.52.190	Schraube
37	26.52.200	Schraube	131	41.50.160	Ölfilter	37	26.52.200	Schraube
38	26.52.210	Schraube	132	41.50.660	Kurbelwelle	38	26.52.210	Schraube
39	26.70.120	Mutter	133	41.50.760	Öltankdeckel	39	26.70.120	Mutter
40	31.12.040	Kugellager	134	41.50.970	Starterfeder	40	31.12.040	Kugellager
41	31.12.080	Kugellager	135	41.51.030	Welle für Bremse	41	31.12.080	Kugellager
42	31.14.070	Nadellager	136	41.51.050	Schraube	42	31.14.070	Nadellager
43	31.14.080	Nadellager	137	41.51.060	<b>Kupplung</b>	43	31.14.080	Nadellager
44	31.21.120	Simmerring	138	41.51.070	Kupplungsfeder	44	31.21.120	Simmerring
45	31.21.130	Simmerring	139	41.53.220	Kupplungstrommel	45	31.21.130	Simmerring
46	31.23.060	Kolbenring	140	41.53.240	Vergaser	46	31.23.060	Kolbenring
47	31.51.070	Haltekeil	141	41.53.260	A.V. Schraube	47	31.51.070	Haltekeil
48	31.58.080	Kolbenbolzen	142	41.54.240	Brennstoffbehälter	48	31.58.080	Kolbenbolzen
49	31.70.050	Pumpenkolben	143	41.54.320	Gehäusehälfte	49	31.70.050	Pumpenkolben
50	31.80.090	Schneckenrad	144	41.54.330	<b>Ölpumpe</b>	50	31.80.090	Schneckenrad
51	31.80.110	Zentrierbolzen	145	45.20.410	Gehäusehälfte	51	31.80.110	Zentrierbolzen
52	32.10.020	Zündkerze	146	45.20.420	Pumpengehäuse	52	32.10.020	Zündkerze
53	32.10.150	Schalter "STOP"	147	45.20.430	Platte	53	32.10.150	Schalter "STOP"
54	32.10.180	Unterbrechersatz	148	45.20.440	Startergehäuse	54	32.10.180	Unterbrechersatz
55	32.10.190	Kondensator	149	45.20.450	Starterspindel	55	32.10.190	Kondensator
56	32.10.200	Zündspule	150	45.20.510	Starterdeckel	56	32.10.200	Zündspule
57	32.10.210	Zündleitung	151	45.20.530	Luftfilterdeckel	57	32.10.210	Zündleitung
58	33.11.080	Splint	152	45.20.550	Kupplungsgehäuse	58	33.11.080	Splint
59	33.14.040	Bolzen	153	45.40.170	Kolben	59	33.14.040	Bolzen
60	33.53.030	Halterung	154	45.40.180	Schwungrad	60	33.53.030	Halterung
61	33.56.020	Sperrung	155	45.40.190	Zylinder	61	33.56.020	Sperrung
62	33.56.030	Halterung	156	45.60.250	Handgriff r.	62	33.56.030	Halterung
63	36.10.020	Scheibe	157	45.60.260	Handgriff l.	63	36.10.020	Scheibe
64	36.10.460	STOP Platte	158	45.60.290	Schalldämpferabdeckung	64	36.10.460	STOP Platte
65	36.10.530	Abdeckplatte	159	45.60.300	Deckel	65	36.10.530	Abdeckplatte
66	36.10.540	Kettenschutz	160	45.60.310	Starterfederbehälter	66	36.10.540	Kettenschutz
67	36.10.550	Greifer	161	46.10.760	Rindenhacken	67	36.10.550	Greifer
68	36.10.560	Verbindungsplatte	162	46.10.810	Luftförderplatte	68	36.10.560	Verbindungsplatte
69	36.10.640	Kettenschutz	163	46.20.160	Bügel	69	36.10.640	Kettenschutz
70	36.10.650	Kettenspanner	164	46.50.040	<b>Dichtungszat</b>	70	36.10.650	Kettenspanner
71	36.10.660	Bremse	41.51.040	<b>Kolben Komplet mit 46 - 48 - 61 - 153</b>	<b>Piston ass'y. with 46 - 48 - 61 - 153</b>	71	36.10.660	Bremse
72	36.24.150	Ölleitung	41.54.260	<b>Starter Komplet mit 6 - 110 - 111 - 115 122 - 130 - 134 - 148 149 - 150 - 160</b>	<b>Starter ass'y. with 6 - 110 - 111 - 115 122 - 130 - 134 - 148 149 - 150 - 160</b>	72	36.24.150	Ölleitung
73	36.30.030	Ansauganschluss	41.54.280	<b>Kupplungsgehäuse mit Kettenbremse mit 2 - 7 - 25 - 30 - 31 37 - 38 - 59 - 69 - 70 71 - 79 - 88 - 113 - 129 135 - 152</b>	<b>Clutch housing with chain-brake with 2 - 7 - 25 - 30 - 31 37 - 38 - 59 - 69 - 70 71 - 79 - 88 - 113 - 129 135 - 152</b>	73	36.30.030	Ansauganschluss
74	36.40.130	Knopf	41.54.300	<b>Kupplungsgehäuse ohne Kettenbremse mit 2 - 7 - 25 - 30 - 38 69 - 70 - 113 - 129 - 152</b>	<b>Clutch housing without chain-brake with 2 - 7 - 25 - 30 - 38 69 - 70 - 113 - 129 - 152</b>	74	36.40.130	Knopf
75	36.40.140	Stift	41.54.350	<b>Unterbrechersatz mit 10 - 54 - 55 - 105 121 - 147</b>	<b>Breaker point ass'y. with 10 - 54 - 55 - 105 121 - 147</b>	75	36.40.140	Stift
76	36.53.140	Feder	41.51.360	<b>Filterdecke Kompl. mit 62 - 107 - 114 - 151</b>	<b>Filter cover ass'y. with 62 - 107 - 114 - 151</b>	76	36.53.140	Feder
77	36.53.190	Feder				77	36.53.190	Feder
78	36.53.220	Feder				78	36.53.220	Feder
79	36.53.240	Feder				79	36.53.240	Feder
80	36.55.070	Tragstange				80	36.55.070	Tragstange
81	36.57.040	Klemme				81	36.57.040	Klemme
82	36.57.050	Kontaktfeder				82	36.57.050	Kontaktfeder
83	36.57.100	Klemme				83	36.57.100	Klemme
84	36.60.180	Büchse				84	36.60.180	Büchse
85	37.21.020	Dichtung				85	37.21.020	Dichtung
86	37.21.060	Dichtung				86	37.21.060	Dichtung
87	37.21.130	Scheibe				87	37.21.130	Scheibe
88	37.21.140	Distanzstück				88	37.21.140	Distanzstück
89	37.23.210	Dichtung				89	37.23.210	Dichtung
90	37.23.220	Dichtung				90	37.23.220	Dichtung
91	37.23.230	Dichtung				91	37.23.230	Dichtung
92	37.23.240	Dichtung				92	37.23.240	Dichtung
93	37.23.250	Dichtung				93	37.23.250	Dichtung
94	37.41.060	Tankdeckel				94	37.41.060	Tankdeckel



Pos.	Part No.	BEZEICHNUNG	DESCRIPTION
1	5-1509	Gehäusegruppe	Body ass'y.
2	82-26	Ventilnadel	Valve
3	21-147	Abdeckplatte	Fuel pump cover
4	96-166	Schraube	Screw
5	95-35	Brennstoffpumpe	Fuel pump diaphragm
6	92-106	Dichtung	Gasket
7	96-205	Leerlaufschraube	Idle adj. screw
8	98-188	Feder	Spring
9	102-71	Regulirnadel	Needle
10	95-520	Brennstoffmembran	Diaphragm
11	166-38	Einlasshebel	Lever
12	98-270	Feder	Spring
13	157-534	Kreislaufplatte	Plate ass'y.
14	92-180	Dichtung	Gasket
15	21-160	Abdeckplatte	Diaphragm cover
16	92-94	Dichtung	Gasket
17	96-167	Schraube	Screw
18	98-162	Feder	Spring
19	89-13	Rückhaltekuugel	Ball
20	62-40	Chokeklappe	Choke valve
21	96-142	Schraube	Screw
22	40-752	Chokeachse	Choke shaft ass'y.
23	68-15	Drosselanschlag	Stop
24	34-78	Drosselklappe	Throttle valve
25	98-329	Feder	Spring
26	30-775	Drosselachse	Throttle shaft
27	96-517	Schraube	Screw
28	98-217	Feder	Spring
29	84-500	Filter mit haltering	Screen
30	128-64	Brennstoffanschluss	Fuel intake
31	140-31	Brennstoffsieb	Fuel inlet screen
32	325-508	Reparatursatz	Kwik Kit
33	350-508	Dichtungssatz	Gasket Kit

