


PARTS LIST NO. <b>545014301</b>		<b>IKRA ® PARTS LIST</b>	CHAIN SAW MODEL(s) <b>3940</b>
DATE <b>3/08/05</b>	NEW		PAGE NO. <b>1</b>
<b>Note:</b> Illustration may differ from actual model due to design changes			




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530059667	Assy.-Isolator	28.	530056402	Handle-Starter	53.	530047061	Assy.-Clutch Drum w/bearing
2.	530047608	Limiter Strap	29.	530027531	Spring-Recoil	54.	530015611	Washer-Clutch
3.	530059668	Spring-Isolator	30.	530015920	Screw	55.	530014949	Assy. Clutch
4.	530015158	Washer	31.	530015127	Washer-Flywheel	56.	530071259	Kit - Oil Pump (incl. 57,58,60)
5.	530016018	Screw	32.	530039187	Assy-Flywheel	57.	530037820	Gear-Worm Spring
6.	530015843	Screw	33.	530047192	Assy-Fuel Cap	58.	530049477	Elbow-Oil Pickup
7.	530047583	Front Handle	34.	530023877	Fitting-fuel line	59.	530016064	Screw
8.	530015940	Screw	35.	530069216	Kit-Fuel line (large)	60.	530019206	Seal Block
9.	530015814	Screw	36.	530016149	Spring-Switch	61.	530047663	Assy-Oil Pick-up (Incl. 62,63)
10.	545035801	Bar - 16"	37.	530015775	Screw	62.	530038373	Pick-up Oiler
11.	952051211	Chain - 16"	38.	530047581	Cover-Rear Handle	63.	530056533	Filter-Oil
12.	530014381	Kit-Spike (Incl. 13)	39.	530015886	Screw	64.	530056960	Assy.-Chain Brake
13.	530016439	Screw	40.	530015906	Screw	65.	530015917	Nut-Bar Mounting
14.	530016132	Screw	41.	530036098	Throttle Lockout	66.	530015826	Pin-Bar Adjust
15.	530038238	Plate-Bar Mount.	42.	530036097	Trigger-Throttle	67.	530038593	Retainer
16.	530015814	Screw	43.	530047582	Handle - Rear	68.	530069611	Kit-Bar Adjusting (incl. # 66,67)
17.	530029850	Chain Catcher	44.	530071958	Kit-Isolator (Upper)			
18.	530016133	Bolt-Bar	45.	530015875	Screw			
19.	530057236	Assy-Oil Cap	46.	530059668	Spring-Isolator			
20.	530071666	Kit-Oil Vent	47.	530057473	Lever-Switch			
21.	530016134	Nut-Flywheel	48.	530057474	Lever-Choke			
22.	530016080	Screw	49.	530049005	Grommet-Knob			
23.	530037817	Starter Pulley	50.	530015922	Nut-"U"-Type			
24.	530055723	Baffle-Air	51.	530057479	Assy.-Chassis fuel lines and caps )			
25.	530015892	Screw	52.	530015907	Washer-Thrust			
26.	530055858	Housing-Fan						
27.	530069232	Kit - Rope						

↖ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

PARTS LIST NO. <b>545014301</b>		<b>IKRA ® PARTS LIST</b>	CHAIN SAW MODEL(s) <b>3940</b>
DATE <b>3/08/05</b>	NEW		PAGE NO. <b>2</b>
<b>Note:</b> Illustration may differ from actual model due to design changes			



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016153	Screw	19.	530012550	Cylinder	35.	530069608	Kit-Engine Gasket (Incl. 21, 27 & 31)
2.	530056914	Assy-Cylinder Shield (includes # 16)	20.	530049870	Backplate-Muffler	36.	530031135	Scrench
3.	530069247	Kit-Fuel Line (Small)	21.	530069608	Gasket-Muffler(kit)	37.	530056363	Assy-Seal & Bearing
4.	530071835	Kit-Air Purge (incl. #5)	22.	530037813	Diffuser-Muffler	38.	530037935	Cap-Crankcase
5.	530015780	Screw	23.	530036103	Screen-Spark	39.	530047062	Assy-Crankshaft
6.	530095646	Assy-Fuel Pick-up	24.	530016132	Bolt-Muffler	40.	530047207	Assy-Muffler (Incl. 20-24)
7.	530047442	Strap-Ground	25.	530047631	Grommet-Throttle Cable			
8.	530039198	Ignition Module	26.	---	Kit-Carburetor			
9.	530015814	Screw		530071820	Zama (W-20)			
10.	530057475	Assy-Wire Harness		530071821	Walbro (WT-662)			
11.	530037793	Foam-Air Filter	27.	530069608	Gasket-Carb. (kit)			
12.	530016101	Nut	28.	530016386	Screw			Not Shown
13.	530057702	Assy-Air Box	29.	530049700	Carb. Adapter			
14.	530035526	Grommet-Carb Adjust	30.	530016187	Screw	545001450		Manual
15.	530054144	Seal-Carb Adapter	31.	530069608	Gasket-Adaptor(kit)			
16.	530055698	Reflector-Heat	32.	530038729	Ring-Piston			
17.	952030150	Spark Plug (RCJ-7Y)	33.	530015697	Retainer-Piston Pin			
18.	530016136	Clip-High Tension Lead	34.	530071408	Kit-Piston (Incl. 32 & 33)			

✓ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)