


No.1



Stückliste:

06	16-900702-00028	Seegerring, innen, 28mm	1.0000 St
07	16-900706-00012	Haltering	1.0000 St
08	16-900801-06001	Kugellager	1.0000 St
09	16-900800-06001	Kugellager	1.0000 St
10	16-610300-41030	Getriebebesatz	1.0000 St
14	16-610511-01230	Dichtung	1.0000 St
15	16-610510-01930	Getriebestopfen	1.0000 St
16	16-900220-05010	Schraube	1.0000 St
18	16-900600-00005	Scheibe PB-500	10.0000 St
19	16-900162-05035	Schraube	2.0000 St
20	16-610239-04130	Scheibe	2.0000 St
21	16-890135-41030	Aufkleber, Modell	1.0000 St
22	16-900562-00005	Sicherungsmutter	11.0000 St
23	16-610410-05131	Getriebegehäuse	1.0000 St
27	16-900503-00012	Mutter	1.0000 St
29	16-900810-06201	Kugellager	1.0000 St
30	16-610315-05130	Hülse	1.0000 St
31	16-610434-03830	Stopfen	1.0000 St
32	16-900720-00008	O-Ring	1.0000 St
33	16-900105-05022	Schraube 5x22	6.0000 St
34	16-900340-30010	Spannstift 3x10	1.0000 St
35	16-610408-05130	Gehäuse	1.0000 St
39	16-900811-06201	Kugellager 6201DU	1.0000 St
40	16-610310-05130	Antriebswelle	1.0000 St
41	16-610325-02730	Keil	1.0000 St
42	16-610307-05130	Antrieb	2.0000 St
43	16-610327-01261	Nadellager	2.0000 St
44	16-610327-40930	Scheibe	1.0000 St
45	16-900600-00008	Scheibe	1.0000 St
46	16-610320-03830	Mutter	1.0000 St
50	16-699110-05130	Messerhalter RSAR (oben)	1.0000 St
51	16-699111-05130	Messerführung	3.0000 St
52	16-697000-05130	Messersatz RSAR	1.0000 St
53	16-V203-000090	Schraube	3.0000 St
54	16-699117-05130	Messerhalter RSAR (unten)	1.0000 St
55	16-610414-05130	Gehäusedichtung RSAR, Gummi	1.0000 St
56	16-610426-05130	Filzdichtung RSAR	1.0000 St
57	16-610411-05130	Gehäusedeckel unten	1.0000 St
58	16-900162-05043	Schraube 5x43	1.0000 St
64	16-895610-00130	Imbusschlüssel - 4mm	1.0000 St
65	16-895314-03430	Steckschlüssel 8	1.0000 St
66	16-880300-03830	Fettpresse	1.0000 St

43 referenz(en)

