

brand	<b>HOMEBASE</b>
-------	-----------------


date	FEB/04	SHEET 1/3
------	--------	-----------

Model

<b>PIONEER 460 SDE</b>

Product number

<b>9538780-33</b>



## ELECTROLUX OUTDOOR PRODUCTS

brand	HOMBASE	
-------	---------	--

date	feb-04	SHEET 2/2	
------	--------	-----------	--

Pos.	PN ELX	DESCRIPTION	Q.ty
1	531205989	SHEATHING	1
2	531212823	HANDLE	1
3	531212472	LEVER	1
9	531205169	CABLE HOOK	2
10	531207165	NUT	4
11	531204961	WASHER	4
12	531208491	NUT	2
13	531205581	CLAMP	2
14	531211480	SCREW	2
15	531211581	PLATE	2
16	531211473	ADJUSTABLE DISK	2
17	531211476	SPRING	2
18	531211474	ADJUSTABLE DISK	2
19	531207120	WASHER	4
20	531211475	KNOP	2
21	531205999	SPRING	1
22	531205196	SCREW	2
22	531206681	SCREW	1
23	531207981	WASHER	6
24	531207982	NUT	3
25	531204907	KEY	1
26	531210824	WASHER	2
27	531205060	TIE ROD	1
28	531212756	DEFLECTORE	1
29	531205069	ROD	1
30	531205056	SPRING	1
31	531212433	DECK	1
32	531205848	CONNECTION	1
33	531208216	SCREW	2
34	531206653	COTTER PIN	2
35	531212363	REAR AXLE	1
36	531205944	SUPPORT	2
37	531208844	SCREW	6
37	531208859	WASHER	2
38	531205057	SUPPORT	4
39	531205051	AXLE	1
40	531210795	PLUG	4
41	531205042	SCREW	4
43	531212634	WHEEL	2
44	531212635	WHEEL	2
45	531206644	WASHER	4
46	531207978	NUT	4
47	531205048	SUPPORT	1
48	531207243	WASHER	1
49	531211652	BLADE	1
50	531207237	WASHER	1
51	531208008	SCREW	1
52	531207986	SHEATHING	1
53	531211436	SACK FRAME	1
54	531211437	SACK	1
55	531210617	MULCH-PLUG	1
56	531211184	SPRING	1

Pos.	PN ELX	DESCRIPTION	Q.ty
57	531205557	CABLE HOOK	1
58	531207856	SCREW	3
59	531205047	BELT HOUSING	1
60	531207280	BELT	1
61	531204758	GEAR-BOX	1
62	531206182	SPRING	1
63	531207697	SPACER TUBE	1
64	531205108	KEY	2
65	531205045	PINION	1
65/1	531205046	PINION	1
66	531207847	WASHER	2
67	531208772	SEEGER	6
68	531208778	BALL- BEARING	2
69	531212813	ACCELERATOR LEVER	1
70	531212812	CLUTCH LEVER	1
71	531205596	SPRING	1
72	531205820	COVER	1
73	531205823	SCREW	2
74	531208966	WASHER	1
75	531206610	SCREW	1
76	531208492	NUT	1
77	531212849	DASH-BOARD	1
78	531210570	BATTERY COVER	1
79	531211141	ACCELERATOR LEVER	1
80	531206000	CLUTCH CABLE	1
81	531212815	SPRING	1
92	531212818	CABLE	1
99	531212835	SWITCH	1
100	531212821	BATTERY	1
101	531211256	CABLE	1
102	531211738	CHARGER	1
103	531212834	BUTTON	1
104	531212820	CABLE	1
105	531212833	RING NUT	1
106	531212763	NUT	1
107	531212814	CABLE ACC.	1
108	531208043	CABLE HOOK	1
109	531207937	SCREW	1
110	531212364	LEVER	1
111	531210817	SPRING	1
112	531208492	NUT	1
113	531206346	SCREW	1
114	531212900	LABEL -DECK-	1
115	531212840	LABEL -DASCH B.-	1
108	531208043	CABLE HOOK	1
109	531207937	SCREW	1
110	531212364	LEVER	1
111	531210817	SPRING	1
112	531208492	NUT	1
113	531206346	SCREW	1
114	531212900	LABEL -DECK-	1
115	531212840	LABEL -DASCH B.-	1