




B119




Ausgabe Issue 2006- 1A		Bild Nr Picture No B119		HT 55 HECKENSCHERE CHASSIE		HT 55 HEDGE TRIMMER CHASSIS		Seite Page 90	
Pos. Fig.	Anzahl/Quantity				Artikel Nr. Part No	Bezeichnung	Description	Satz Kit	Anmerkung Notes
	HT55								
1	1				1911-4407-01	Handgriff- rechts.....	Handgrip- RH .....		
2	1				1911-4406-01	Erdungskabel.....	Ground cable.....		
3	1				1911-4405-01	Kabel .....	Coil- switch cable .....		
4	1				1911-4408-01	Stoppschalter .....	Stop switch .....		
5	1				1911-4402-01	Kabel .....	Wire .....		
6	1				1911-4400-01	Feder .....	Spring .....		
7	1				1911-4401-01	Gashebel.....	Throttle lever.....		
8	1				1911-4396-01	Feder .....	Spring .....		
9	1				1911-4397-01	Einstellhebel .....	Adjusting knob .....		
10	1				1911-4399-01	Haken .....	Hook .....		
11	1				1911-4398-01	Gashebellenk.....	Throttle rod .....		
12	1				1911-4403-01	Feder .....	Spring .....		
13	1				1911-4404-01	Sicherheitssperre.....	Safety lever .....		
14	1				1911-4409-01	Handgriff- links .....	Handgrip- LH.....		
15	1				1911-4394-01	Stütz- rechts .....	Support- RH .....		
16	1				1911-4357-01	Mutter .....	Nut .....		
17	1				1911-4379-01	Gehäuse.....	Case .....		
18	1				1911-4395-01	Stütz- links .....	Support- LH .....		
19	1				1911-4370-01	Scheibe.....	Washer.....		
20	1				1911-4367-01	Scheibe.....	Washer.....		
21	1				1911-4363-01	Schraube .....	Screw .....		
22	3				1911-4371-01	Scheibe.....	Washer.....		
23	3				1911-4368-01	Scheibe.....	Washer.....		
24	3				1911-4355-01	Schraube .....	Screw .....		
25	1				1911-4354-01	Kugellager .....	Ball bearing .....		
26	1				1911-4389-01	Ritzel .....	Pinion.....		
27	1				1911-4390-01	Zahnrad .....	Sprocket.....		
28	1				1911-4366-01	Ring .....	Ring .....		
29	1				1911-4391-01	Verbindungsstab .....	Connecting rod .....		
30	1				1911-4392-01	Verbindungsstab .....	Connecting rod .....		
31	1				1911-4324-01	Kugellager .....	Ball bearing .....		
32	1				1911-4383-01	Gleitblock.....	Glide shoe .....		
33	1				1911-4393-01	Gehäuse.....	Case .....		
X 34	6				1911-4425-01	Schraubensatz .....	Screw set .....		
35	1				1911-4423-01	Knopf.....	Button .....		
X 37	2				1911-4432-01	Schraube .....	Screw .....		
38	1				1911-4380-01	Halter.....	Plate.....		
X 39	2				1911-4431-01	Mutter.....	Nut .....		
40	1				1911-4385-01	Klinge- untere .....	Blade- bottom.....		
41	1				1911-4384-01	Klinge- obere .....	Blade- top .....		
42	1				1911-4382-01	Klingenführung.....	Blade holder .....		
43	1				1911-4381-01	Klingenschutz .....	Blade guard .....		
44	4				1911-4387-01	Schraube .....	Screw .....		
45	4				1911-4386-01	Scheibe.....	Washer.....		
X 46	4				1911-4426-01	Mutter.....	Nut .....		
47	1				1911-4410-01	Handgriff- vordere .....	Handle- front.....		
48	2				1911-4365-01	Schraube .....	Screw .....		
49	2				1911-4370-01	Scheibe.....	Washer.....		
50	2				1911-4367-01	Scheibe.....	Washer.....		
51	2				1911-4357-01	Mutter.....	Nut .....		
52	1				1911-4388-01	Klingenabdeckung .....	Blade cover .....		
53	5				1911-4364-01	Schraube .....	Screw .....		
54	1				1911-4370-01	Scheibe.....	Washer.....		
55	1				1911-4367-01	Scheibe.....	Washer.....		
56	1				1911-4362-01	Schraube .....	Screw .....		



B120



Ausgabe Issue 2006- 1A		Bild Nr Picture No B120		HT 55 HECKENSCHERE MOTOR		HT 55 HEDGE TRIMMER ENGINE		Seite Page 92	
Pos. Fig.	Anzahl/Quantity				Artikel Nr. Part No	Bezeichnung	Description	Satz Kit	Anmerkung Notes
	HT55								
X	1	1			1911-4337-01	Schraubensatz.....	Screw set.....		
	2	1			1911-4369-01	Scheibe.....	Washer.....		
	3	1			1911-4373-01	Abweiser.....	Deflector.....		
	4	1			1911-4427-0	Motorhaube- rot.....	Engine cover- red.....		
	5	2			1911-4336-01	Schraubensatz.....	Screw set.....		
	6	1			1911-4374-01	Schalldämpfer.....	Muffler.....		
	7	1			1911-4316-01	Schalldämpferschutz.....	Muffler shield.....		
	8	4			1911-4334-01	Schraubensatz.....	Screw set.....		
	9	1			1911-4377-01	Zündkerzen.....	Spark plug.....		
	10	1			1911-4337-01	Schraubensatz.....	Screw set.....		
	11	1			1911-4318-01	Schutz.....	Guard.....		
	12	1			1911-4279-01	Zylinderdichtung.....	Cylinder gasket.....		
	13	2			1911-4290-01	•• Schließring.....	•• Lock ring.....		
	14	1			1911-4289-01	•• Kolbenbolzen.....	•• Piston pin.....		
	15	2			1911-4288-01	•• Kolbenring.....	•• Piston ring.....		
	16	1			1911-4287-01	• Kolben.....	• Piston.....		Inkl. pos 13 - 15 Inkl. pos 16
	17	1			1911-4278-01	Zylinder- Kolben kpl.....	Cylinder- piston assy.....		
	18	1			1911-4292-01	Nadellager.....	Needle bearing.....		
	19	1			1911-4291-01	Kurbelwelle.....	Crankshaft.....		
	20	1			1911-4323-01	Keil.....	Key.....		
	21	2			1911-4324-01	Kugellager.....	Ball bearing.....		
	22	2			1911-4283-01	Dichtring.....	Seal ring.....		
	23	1			1911-4281-01	Kurbelgehäuse- hinten.....	Crankcase- rear.....		
	24	1			1911-4306-01	Startsperrgehäuse.....	Starter cup.....		
	25	1			1911-4345-01	Feder.....	Spring.....		
	26	1			1911-4305-01	Startsperre.....	Starter hook.....		
	27	1			1911-4282-01	Dichtung.....	Gasket.....		
	28	2			1911-4342-01	Zentrierstift.....	Centering pin.....		
	29	1			1911-4280-01	Kurbelgehäuse- vordere.....	Crankcase- front.....		
	30	1			1911-4277-01	Schwungrad.....	Flywheel.....		
	31	4			1911-4328-01	Schraubensatz.....	Screw set.....		
	32	1			1911-4343-01	Scheibe.....	Washer.....		
	33	1			1911-4358-01	Mutter.....	Nut.....		
	34	1			1911-4309-01	Feder.....	Spring.....		
X	35	2			1911-4430-01	Scheibe.....	Washer.....		
	36	2			1911-4307-01	Kupplung.....	Clutch unit.....		
	37	2			1911-4310-01	Schraube.....	Screw.....		
	38	2			1911-4337-01	Schraubensatz.....	Screw set.....		
	39	2			1911-4308-01	Scheibe.....	Washer.....		
	41	1			1911-4418-01	Elektronikspule.....	Electronic coil.....		
	42	1			1911-4298-01	Zündkerzenschutz.....	Spark plug cover.....		
	43	1			1911-4348-01	Kabelhalter.....	Cable retainer.....		
	44	2			1911-4297-01	Kabel.....	Switch wire.....		
	45	1			1911-4419-01	Stütz.....	Support.....		
	46	2			1911-4337-01	Schraubensatz.....	Screw set.....		
	49	4			1911-4339-01	Schraubensatz.....	Screw set.....		
	50	1			1911-4417-01	Bremsband.....	Brake band.....		
	51	1			1911-4416-01	Feder.....	Spring.....		
	52	1			1911-4412-01	Abdeckung.....	Cover.....		
	53	1			1911-4415-01	Hebel.....	Lever.....		
	54	1			1911-4414-01	Schraube.....	Screw.....		
	55	1			1911-4413-01	Mutter.....	Nut.....		
	56	1			1911-4411-01	Flansch.....	Flange.....		
	57	4			1911-4359-01	Schraube.....	Screw.....		
	58	1			1911-4378-01	Kupplungsglocke.....	Clutch drum.....		
	59	2			1911-4313-01	Benzinschlauch.....	Fuel hose.....		
	60	1			1911-4314-01	Gummiringe.....	Grommet.....		
	61	1			1911-4311-01	Benzintank kpl.....	Fuel tank assy.....		
X	62	1			1911-4424-01	Tankdeckel.....	Fuel tank cap.....		
	63	3			1911-4327-01	Schraubensatz.....	Screw set.....		
	65	1			1911-4255-01	Filter.....	Intake filter.....		



B121



Ausgabe Issue 2006- 1A		Bild Nr Picture No B121		HT 55 HECKENSCHERE VERGASER		HT 55 HEDGE TRIMMER CARBURETTOR		Seite Page 94	
Pos. Fig.	Anzahl/Quantity				Artikel Nr. Part No	Bezeichnung	Description	Satz Kit	Anmerkung Notes
	HT55								
1	4				1911-4337-01	Schraubensatz .....	Screw set .....		Inkl. pos 4 - 9                       WYJ397
2	1				1911-4375-01	Startergehäuse .....	Starter recoil case .....		
4	1				1911-4300-01	• Starterfeder .....	• Rewind spring .....		
5	1				1911-4301-01	• Seilrolle .....	• Starter pulley .....		
6	1				1911-4304-01	• Starterseil .....	• Starter cord .....		
7	1				1911-4302-01	• Startergriff .....	• Starter handle .....		
8	1				1911-4353-01	• Scheibe .....	• Washer .....		
9	1				1911-4360-01	• Schraube .....	• Screw .....		
11	1				1911-4286-01	Dichtung .....	Gasket .....		
12	1				1911-4285-01	Ansaugrohr .....	Intake manifold .....		
13	1				1911-4293-01	Dichtung- membransatz .....	Gasket- diaphragm kit .....		
X 14	2				1911-4428-01	Schraubensatz .....	Screw set .....		
15	1				1911-4123-01	Vergaser kpl .....	Carburettor assy .....		
16	1				1911-4352-01	Chokerhebel .....	Choke lever .....		
X 17	1				1911-4351-01	Chokerklappe .....	Choke valve .....		
18	1				1911-4429-01	Schraube .....	Screw .....		
19	1				1911-4346-01	Filtergehäuse .....	Filter housing .....		
20	2				1911-4329-01	Schraubensatz .....	Screw set .....		
23	1				1911-4295-01	Luftfilter .....	Air filter .....		
24	1				1911-4349-01	Filterdeckel .....	Filer cover .....		
25	1				1911-4347-01	Schraube .....	Screw .....		

