





05005

| Pos.-Nr. | Ersatzteil-Nr. | Bezeichnung | Pos.-Nr. | Ersatzteil-Nr. | Bezeichnung |
|----------|----------------|--------------------|----------|----------------|---------------|
| 001 | 05005-01001 | Handgriff komplett | 005 | 05005-01005 | O-Ring |
| 002 | 05005-01002 | Wellendichtring | 006 | 05005-01006 | Zwischenring |
| 003 | 05005-01003 | Laufрад | 007 | 05005-01007 | Dichtungsring |
| 004 | 05005-01004 | Mutter | 008 | 05005-01008 | Bodenplatte |

