





05006

Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung	Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung
001	94625-02001	Handgriff	005	94625-02005	O-Ring oben
002	94625-02002	Wellendichtring	006	94625-02006	Zwischenstück
003	94625-02003	Laufrad	007	94625-02007	Untere Dichtung
004	94625-02004	Mutter	008	94625-02008	Pumpenboden

