




94188





94188

Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung	Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung
001	94191-02001	Pumpengehäuse	007	94191-02020	Spritzring
002	94191-02005	Laufrad	008	94191-02021	Laufradsperrschraube
003	94191-02006	Schneckenrad	009	94191-02022	Rillenkugellager
004	94191-02009	Leitrad / 1-fach (Diff.)	010	94191-02027	Blindstopfen 1/8 Zoll
005	94191-02010	Leitrad / doppelt (Diff.)	011	94191-02042	Deckel
006	94191-02013	Mechanische Dichtung	012	94191-02046	Zugstange / 215 mm

