

CS2137

Spare parts


Ersatzteile

Pièces détachées

Reserve onderdelen


Repuestos

Reservdelar



▲ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530 04 79-63	Assy.—Isolator	27.	530 05 64-02	Handle—Starter	53.	530 04 76-05	Knob—Choke
2.	530 04 76-08	Strap—Limiter	28.	530 02 75-31	Spring—Recoil	54.	530 04 90-05	Grommet—Knob
3.	530 04 20-82	Spring—Isolator	29.	530 03 78-17	Pulley—Starter	55.	530 05 65-99	Assy—Chassis
4.	530 01 51-23	Washer	30.	530 01 59-20	Screw	56.	530 07 12-59	Kit—Oil Pump (Incls. 57, 58, 60)
5.	530 01 60-18	Screw	31.	530 01 61-34	Nut—Flywheel	57.	530 03 78-20	Gear—Worm Spring
6.	530 01 58-43	Screw	32.	530 01 51-27	Washer—Flywheel	58.	530 04 94-77	Elbow—Oil Pickup
7.	530 03 61-42	Sleeve—AV Spring	33.	530 03 92-09	Assy—Flywheel	59.	530 01 60-64	Screw
8.	530 04 75-83	Handle—Front	34.	530 01 61-33	Bolt—Bar	60.	530 01 92-06	Seal Block
9.	530 01 59-40	Screw	35.	530 04 71-92	Assy—Fuel Cap	61.	530 04 76-63	Assy—Oil Pickup (Incl. 62—64)
10.	530 01 58-14	Screw	36.	530 01 59-22	Nut—iUi—Type	62.	530 03 83-73	Pick-up Oiler
11.	---	Bar	37.	530 02 38-77	Fitting—fuel line	63.	530 03 78-21	Filter—Oil
12.	---	Chain	38.	530 06 92-16	Kit—Fuel line (large)	64.	530 03 01-89	Plug—Oil Filter
13.	530 01 43-81	Kit—Assy Spike(incl.14)	39.	530 04 76-31	Grommet—Ca ble	65.	530 01 59-07	Washer—Thrust
14.	530 01 58-05	Screw	40.	530 04 76-02	Ca ble—Throttle	66.	530 04 70-61	Assy.—Clutch Drum w/bearing
15.	530 03 82-38	Plate—Bar Mounting	41.	530 04 75-81	Cover—Rear Handle	67.	530 01 56-11	Washer—Clutch
16.	530 01 58-14	Screw	42.	530 01 59-06	Screw	68.	530 01 49-49	Assy. Clutch
17.	530 02 98-50	Chain Catcher	43.	530 01 58-86	Screw	69.	530 05 46-78	Assy—Chain Brake
18.	530 01 61-32	Screw	44.	530 03 60-98	Lockout—Throttle	70.	530 01 59-17	Nut—Bar Mounting
19.	530 02 61-19	Check Valve	45.	530 03 60-97	Trigger—Throttle	71.	530 01 58-26	Pin—Retainer
20.	530 03 82-64	Plug—Bronze Vent	46.	530 04 20-82	Spring	72.	530 03 85-93	Retainer
21.	530 01 08-46	Assy—Oil Cap	47.	530 06 95-72	Kit—Switch	73.	530 06 96-11	Kit—Bar Adjust
22.	530 02 38-17	Spring—Starter Dog	48.	530 04 75-82	Handle—Rear			
23.	530 01 60-80	Screw	49.	530 01 58-14	Screw			
24.	530 01 58-92	Screw	50.	530 05 32-74	Assy. Isolator—lower			
25.	530 05 70-99	Housing—Fan	51.	530 07 13-85	Kit—Isolator (Upper)			
26.	530 06 92-32	Kit—Rope	52.	530 01 58-75	Screw			

n = NEW PART NUMBER FOR THIS IPL

K= REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530 01 61-53	Screw	19.	530 03 61-03	Screen-Spark	36.	530 04 76-04	Housing-Air Filter
2.	530 05 57-09	Shield-Cylinder	20.	530 03 78-13	Diffuser-Muffler	37.	530 01 61-01	Nut
3.	530 04 72-13	Assy-Air Purge	21.	530 06 96-08	Gasket-Muffler (kit)	38.	530 03 77-93	Air Filter - Foam
4.	530 01 57-80	Screw	22.	530 04 72-07	Assy-Muffler (Incl. 17-21)	39.	530 03 11-35	Wrench-Bar
5.	530 09 56-46	Assy-Fuel Pick-up	23.	530 04 70-62	Assy-Crankshaft	40.	530 06 96-08	Kit-Engine Gasket (incl. 34,30,21)
6.	530 06 92-47	Kit-Line Purge/Carb. (Small Dia)	24.	530 03 79-35	Cap-Crankcase			
7.	530 06 92-16	Kit-Line Purge/Tank (large line)	25.	530 05 63-63	Assy-Seal & Bearing			
8. n	530 03 55-26	Grommet-Carb Adjust.	26.	530 03 87-29	Ring-Piston			
9.	530 05 41-44	Seal-Carb Adapter	27.	530 01 56-97	Retainer - Piston Pin			
10.	952 0 301-50	Spark Plug (RCJ-7Y)	28.	530 07 14-08	Kit-Piston - (incl. 26-27)			
11.	530 01 61-36	Clip-High Tension Lead	29.	530 07 14-12	Kit-Cylinder			
12.	530 04 91-17	Assy-Wire Harness (includes switch)	30.	530 06 96-08	Gasket-Carb. Adapter (kit)			
13.	530 01 58-14	Screw	31.	530 01 61-87	Screw			
14. n	530 03 91-98	Module-Ignition	32.	530 04 97-00	Kit-Carb. Adapter			
15.	530 04 74-42	Strap-Ground	33.	530 01 63-86	Screw			
16.	530 03 76-52	Insulator-Heat	34.	530 06 96-08	Carb. Gasket (kit)			
17.	530 04 98-70	Back Plate-Muffler	35.	---	Kit-Carburetor			
18.	530 01 61-32	Screw	n	530 06 97-22	(WT-391)			
				530 07 16-21	(WT-625)			
								Not Shown
								530 16 32-80 Manual - (Scan)
								530 16 32-81 Manual - (Euro - I)
								530 04 76-30 Decal - Stop


n = NEW PART NUMBER FOR THIS IPL

K= REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

Carburetor Assembly – WT-391 – #530 06 97-22



Kit - Carburetor Assembly No. 530 07 16-21 - WT-625



Note: No Repair kits are available for this carburetor, please order the complete assembly part number 530-071621 - WT-625