



**Jonsered**

SERVICE 		
		I0300067

IPL, Trimmer and brushcutter Accessory guide 2003, 2003-04, 106 24 74-62

# Trimmer and brushcutter Accessory guide 2003

Spare parts


Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar



# TRIMMER & BRUSHCUTTER ACCESSORY GUIDE 2003



	RS52/ RS44	GR50/ GR41	BP2052	GR2036	GR2032D	GR2032L	BC2125	GC2125	GT2125	GT2124
Tap'n Go VII (R)  531 00 80-51									B	A
Tap'n Go Pro  531 01 77-52					C	C				
Tap'n Go 35  531 00 80-74							E,F	E,F		
Auto 32 (1") 531 00 80-71					C	C	E,F	E,F		
Auto 55 (1") 531 00 80-96	D	D	N	C						
Trimmy III M10 (1") 531 00 80-50					C	C				
535  531 00 80-73							E,F	E,F		
Trimmy SII (1") 502 26 08-13	D	D	N	C						
Polytrim M10  531 01 77-49					C	C	E,F	E,F		
Polytrim M12  531 01 77-25	D,M	D,M	N	C,L						
Grass 255-8 (1") 537 02 19-03					K,P	R	F,P	F,P		
Grass 255-4 (1") 537 14 96-03			N,O,Q	L,O,Q	K,P	R	F,P	F,P		
Grass 255-4  537 14 95-03		M,O,Q								
Multi 275-4 (1") 537 14 92-03			N,O,Q	L,O,Q	K,P					
Multi 255-3  537 14 89-03	M,O,Q	M,O,Q								
Multi 255-3 (1") 537 14 90-03				L,O,Q						
Multi 300-3  537 14 93-03	M,O,Q	M,O,Q								
Multi 300-3 (1") 537 14 94-03			N,O,Q	L,O,Q						
Opti S 200-26 (1") 508 90 45-03				H	H		J			
Opti XS 200-22  508 90 14-03	G	G								
Opti XS 225-22  508 90 24-03	I	I								

Splash Guard  530 06 96-66	Splash Guard  537 02 61-02	Splash Guard  503 74 50-06	Splash Guard  503 91 60-03	Splash Guard  503 97 71-03	Blade Guard  503 93 42-04	Blade Guard  502 27 22-01	Blade Guard  503 77 39-01	Blade Guard  502 03 94-05	Blade Guard  537 02 21-01	Blade Guard  503 74 40-03
<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>	<b>G</b>	<b>H</b>	<b>I</b>	<b>J</b>	<b>K</b>

Blade Guard  503 89 52-03	Blade Guard  502 26 34-03	Blade Guard  531 00 79-01	Support Cup  503 90 18-02	Support Cup  503 89 01-01	Support Cup  502 15 70-01	J-handle Kit  503 78 17-04
<b>L</b>	<b>M</b>	<b>N</b>	<b>O</b>	<b>P</b>	<b>Q</b>	<b>R</b>