



Jonsered

Accessories



9
I0400501

IPL, Spreader, 2004-01, 106 31 84-61

954 12 00-46

Spreader

Spare parts


Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar



REPAIR PARTS FOR MODEL 954 12 00-46



REF. NO.	PART NO.	QTY.	DESCRIPTION	REF. NO.	PART NO.	QTY.	DESCRIPTION
1	531 00 76-74	1	Hopper	15	531 00 81-54	2	Hub Cap (Push Nut)
2	531 00 76-61	1	Frame Tube	16	531 00 76-48	2	Push Nut, 1/2"
3	531 00 76-62	1	Hitch Tube (LH)	17	531 00 76-89	1	Drive Wheel Plate
4	531 00 76-63	1	Hitch Tube (RH)	18	531 00 76-90	2	Spacer
5	531 00 76-64	1	Hitch Control Tube	19	531 00 76-91	1	Impeller/Axle Assembly
6	721 68 02-51	2	Hair Cotter Pin	20	531 00 81-57	1	Impeller
7	725 23 79-51	6	Hex Bolt, 1/4-20 x 1-3/4	21	531 00 76-58	2	Hex Flange Bearing
8	531 00 76-29	2	Hex Lock Nut, 1/4-20	22	531 00 81-41	2	Hitch Bracket
9	734 11 52-01	2	Washer, 1/4 Std	23	531 00 76-49	8	Hex Nut, 1/4-20 (SEMS)
10	531 00 76-52	1	Carriage Bolt 1/4-20 x 2-1/4	24	531 00 76-47	4	Hex Blot, 1/4-20 x 2-1/4
11	531 00 76-51	1	Nylon Wing Nut 1/4-20	25	531 00 28-42	3	Vinyl Cap
12	531 00 76-59	1	Flow Slide	26	531 00 81-18	1	Hitch Pin
13	531 00 76-60	1	Control Cable		531 00 76-92	1	Owner's Manual
14	531 00 76-88	2	Wheel & Tire				