

LCT

291CC SNOW ENGINE SERVICE PARTS


PLMHK19850781DE-ABGIJOQUE1M/S

PW2HK19850781DE-ABGIJOQTUVE1M

PW2HK19850781DY-ABGIJOQTUVZE7M

1	Heater Box Assembly-Snow	21001	29	Ignition Coil Assy	46901
3	Muffler Assembly-Snow	42001	30	Crankcase Cover Assy	29136001
4	Fuel Tank Assembly-Snow	23001	31	Black Oil Dipstick	41437111
5	Fuel Tank Cap-Oversized (Click Style)-Snow	43011	32	Charging Coil AC/DC	41417101
6	Carburetor Assembly-Snow	23021	33	Electric Starter Bracket	44051
8	Primer Bulb Assembly w/ Hose-Snow	43041	34	Spark Plug Boot	46911
10	Electric Starter Assembly-Snow	24001	36	Governor Arm Assy	25021
10A	European 230V Electric Starter	24121	37	Governor Shaft	29131001
11	Key Switch Assembly-Snow	44011	38	Governor Gear Assembly	29129001
12	CDI Box Assembly-Snow	44041	39	Camshaft	29116001
13	On/Off Switch-Snow	44031	40	Cylinder Head Assy	29110001
15	Choke Knob-Snow	45001	41	Spark Plug	29115501
16	Governor Linkage Shield Plate-Snow	25011	42	CDI Box Bracket-Snow	44021
17	Recoil Starter Assembly-Snow (Hex)	26001	44	Piston and Rod Assy	29114001
18	Starter Cup Small-Snow	26011	46	Vapor Shield	46061
19	Starter Grip-Snow	26031	47	Seal Kit	29139001
20	Blower Housing Assembly, Electric Start-Snow	26021	48	Wire Harness	44061
21	Shield, Cylinder	41410101	49	Crankshaft	29118001
22	Shield, Under Flywheel Charging System-Snow	46041	50	Top Shield	29110201
23	Valve Cover	41445001	51	Fuel Tank Skirt	21011
25	Fuel Petcock, Snow	49001	52	Rocker Arm Kit	41411001
26	Flywheel Assembly, Electric Start-Snow	29117011	53	Push Rod Tappet Kit	29110011
26A	Flywheel Assembly, Manual Start-Snow	29117001	54	Cylinder Assembly	22221
27	High Oil Fill Assy Kit, Snow	49111	56	Engine Gasket Kit	29143001
28	Flywheel Fan	29140001	57	Fuel Hose Kit	29160001
			58	Extended Oil Drain Tube	47001
			61	Fuel Knob-Snow	45031
			62	Non-Removable Oil Plug	41437151
			63	CE Compliant Muffler Shield	22021
			64	Red Key Set (2)	04071

rev. 1/11/11



Electric Start Only