


LCT

414CC SNOW ENGINE SERVICE PARTS
 PLMHK191150781DE-ABGIJQUVE1M/S
 PW2HK191150781DE-ABGIJQQTUVE1M
 PW2HK191150781DY-ABGIJQQTUVZE7



1	Heater Box Assembly-Snow	41001	29	Ignition Coil Assy	46901
3	Muffler Assembly-Snow	42001	30	Crankcase Cover Assy	41436001
4	Fuel Tank Assembly-Snow	43001	31	Black Oil Dipstick	41437111
5	Fuel Tank Cap-Oversized (Click Style)-Snow	43011	32	Charging Coil AC/DC	41417101
6	Carburetor Assembly-Snow	43021	33	Electric Starter Bracket	44051
8	Primer Bulb Assembly W/ Hose-Snow	43041	34	Spark Plug Boot	46911
10	Electric Starter Assembly-Snow	44001	36	Governor Link Assembly	41430001
10A	European 230V Electric Starter	44121	37	Governor Shaft	41431001
11	Key Switch Assembly-Snow	44011	38	Governor Gear Assembly	41429001
12	CDI Box Assembly-Snow	44041	39	Camshaft	41416001
13	On/Off Switch-Snow	44031	40	Cylinder Head Assy	41410501
15	Choke Knob-Snow	45001	41	Spark Plug	29115501
16	Governor Linkage Shield Plate-Snow	45011	42	CDI Box Bracket-Snow	44021
17	Recoil Starter Assembly-Snow	46001	44	Piston and Rod Assy	41414001
18	Starter Cup Small-Snow	46011	46	Vapor Shield	46061
19	Starter Grip-Snow	46031	47	Seal Kit	41439051
20	Blower Housing Assembly, Electric Start-Snow	46021	48	Wire Harness	44061
21	Shield, Cylinder	41410101	49	Crankshaft	41418001
22	Shield, Under Flywheel Charging System-Snow	46041	50	Top Shield	41410201
23	Valve Cover	41445001	51	Fuel Tank Skirt	41011
25	Fuel Petcock, Snow	49001	52	Rocker Arm Kit	41411001
26	Flywheel Assembly, Electric Start-Snow	41417011	53	Push Rod Tappet Kit	41410011
26A	Flywheel Assembly, Manual Start-Snow	41417001	54	Cylinder Assembly	44441
27	High Oil Fill Assy Kit, Snow	49111	55	Counter Weight Kit	41416501
28	Flywheel Fan	41440001	56	Engine Gasket Kit	41443001
			57	Fuel Hose Kit	41460001
			58	Extended Oil Drain Tube	47001
			61	Fuel Knob-Snow	45031
			62	Non-Removable Oil Plug	41437151
			63	CE Compliant Muffler Shield	42021
			64	Red Key Set (2)	04071

rev. 1/11/11