


MODEL 20111x98A


REPAIR PARTS



1	Engine	—	9	Deflector, Rear	671912	16	Blade – 20"	672814E701
2	Housing	7950007	10	Bolt	1x121	17	Washer, Blade	710210
3	Bolt, Engine	710265	11	Washer	710256	18	Washer	710207
4	Bolt, Axle	9x10	12	Screw	710271	19	Bolt	710163
5	Wheel and Tire	672789	13	Locknut	710203	20	Locknut	45171
6	Washer	996416	14	Deflector, Chute	671929	21	Washer	17x191
7	Screw	26x235	15	Blade Adapter	71056	–	Book, Instruction	F-000501M
8	Extension, Rear	672750E701						

MODEL 20111x98A

REPAIR PARTS



1	Handle, Upper (Gray)	1101023	7	Guide, Rope	43956	11	Bolt	710082
2	Handle, Lower (Gray)	1101022	8	Locknut	710203	12	Washer	996416
3	Bracket, Stop Lever	643628BZ	9	Screw	3x136	13	Spacer	671914
4	Lever, Stop	671924-860	10	Fastener, Cable	71372	14	Nut	710140
6	Engine Stop Cable	672836						