


# MODEL 312002x98B

# REPAIR PARTS CHASSIS & HOOD




# MODEL 312002x98B

# REPAIR PARTS CHASSIS & HOOD

Key No.	Part No.	Description	Key No.	Part No.	Description
1	690566	Seat	31	26x270	Screw
2	028x23	Cap, Push On	32	26x238	Screw
3	094057	Spring	33	1001491	Bearing, Steering
4	26x229	Screw	34	1001584E245	Dash
5	1001054	Bolt, Wing	35	26x201	Screw
6	017x47	Washer	36	093007E245	Panel, Access
7	009x56	Bolt, Shoulder	37	095318E245	Support, Dash
8	094154E701	Support, Seat	38	1001270E701	Bracket, Rear Hanger
9	094156 Z	Rod, Pivot	39	094085E701	Support, Left Grille
10	1001648E700	Bracket, Pivot	40	094007E701	Axle, Hanger
11	001x45	Bolt	41	094084E701	Support, Right Grille
12	015x89	Nut	42	009x58	Bolt, Shoulder
13	009x55	Bolt, Shoulder	43	1001928E701	Frame, Right
14	094155 Z	Washer	44	1001927E701	Frame, Left
15	164x31	Spring	45	690424	Container, Battery
16	26x249	Screw	46	1001002E701	Plate, Hitch
17	26x263	Screw	47	690434E701	Panel, Rear
18	164x30	Spring	48	690482E701	Support, Battery
19	1001558E245	Deck, Seat	49	26x277	Screw
20	15x123	Nut	50	015x81	Nut
21	094151E701	Plate, Index	51	15x124	Nut
22	009x47	Screw	53	1001540	Insert, Grille
23	094999	Mat, Left	54	26x259	Screw
24	094998	Mat, Right	57	1001652	Trim, Hood (3.75")
25	1001534E245	Hood	58	1001653	Trim, Hood (6.5")
26	1001531E245	Grille	59	1001755	Grommet, Parking Brake
27	1001546	Lens, Left	70	1001542	Holder, Cup
28	1001544	Housing, Left Headlamp	—	1001306	Bag, Parts
29	1001545	Lens, Right	—	F-040755L	Instruction Book & Parts List
30	1001543	Housing, Right Headlamp			

# MODEL 312002x98B

# REPAIR PARTS MOTION DRIVE



# MODEL 312002x98B

# REPAIR PARTS MOTION DRIVE


Key No.	Part No.	Description	Key No.	Part No.	Description
1	009x39	Bolt, Shoulder	32	0031x6	Pin, Hair
2	015x89	Nut, Hex	33	017x38	Washer
3	690173 Z	Arm, Idler	34	690369	Spacer
4	094041 Z	Rod, Clutch	35	06x105	Bolt
5	015x79	Nut	36	— † —	Transaxle
6	17x102	Washer	37	015x88	Nut
7	092697	Grip	38	020697	Key, Woodruff
8	030x20	Pin, Cotter	39	01x155	Bolt
9	094043 Z	Lever, Shift	40	094008E701	Bracket, Transaxle
10	017x47	Washer	41	690409	Pulley
11	094044 Z	Link, Shift	42	094433E701	Bracket, Transaxle Support
12	021920 Z	Nut, Adjuster	43	0011x7	Ring, Snap
13	091079	Grip	44	095094	Pulley, Drive
14	1001245 Z	Rod, Parking Brake	45	021553	Key, Square
15	094815 Z	Nut, Adjuster	46	17x160	Washer
16	1001303 Z	Bracket, Shift Pivot	47	690554 Z	Spacer, Transaxle
17	26x249	Screw	48	024373	Stem, Valve
18	015x84	Nut	49	7601048	Tire *
19	094042 Z	Mount, Stud Spring	—	407049	Tube
20	009x54	Bolt, Shoulder	50	690376–601	Wheel & Tire Assembly
21	165x116	Spring, Extension	51	17x195	Washer
22	1001302E701	Bracket, Right Shifter	52	0011x3	E–Ring
23	1001928E701	Frame, Right	53	094618	Hub Cap
24	002x53	Bolt, Carriage	54	093349	Guide, Belt
25	1001927E701	Frame, Left	55	0031x4	Pin, Hair
26	094045 Z	Latch, Parking Brake	56	165x141	Spring, Extension
27	021544	Pedal	57	165x92	Spring, Extension
28	094038E700	Lever, Brake/Clutch	58	26x216	Screw
29	015x98	Nut	59	17x148	Washer
30	037x87	Belt, Motion Drive	60	26x267	Screw
31	094031 Z	Yoke, Shift	61	17x169	Washer

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

† For Replacement Parts see the Transaxle manufacturer.

# MODEL 312002x98B

# REPAIR PARTS STEERING



# MODEL 312002x98B


# REPAIR PARTS STEERING

Key No.	Part No.	Description	Key No.	Part No.	Description
1	095336	Wheel, Steering	23	17x104	Washer
2	690625	Shaft, Steering	24	017x53 Z	Washer
3	095338	Insert, Steering Wheel	25	015x84	Nut, Flange
4	094124	Bearing	26	690210E701	Axle Assembly
5	15x111	Nut, Flange	27	095329E701	Drag Link, Left
6	009x57	Bolt, Shoulder	28	1001298E701	Spindle Assembly, Right
7	690183	Gear, Pinion	29	095328E701	Drag Link, Right
8	011x25	Ring, Snap	30	26x249	Screw
9	094121	Gear, Sector	31	091334	Bearing, Wheel
10	094123	Bearing	32	024373	Stem, Valve
11	001x84	Bolt	33	7601049	Tire *
12	1001121E701	Plate, Steering	—	407046	Tube
13	094006E700	Plate, Engine	34	690377-601	Wheel and Tire Assembly
14	015x88	Nut, Flange	35	17x195	Washer
15	15x118	Nut, Flange	36	17x192	Washer
16	1001270E701	Bracket, Hanger	37	017x83	Washer
17	094007E701	Axle, Hanger	38	094618	Hub Cap
18	01x146	Bolt	39	26x267	Screw
19	030x49	Pin, Cotter	40	092059	Bellows
20	690150	Bearing	41	0025x3	Bolt
21	1001299E701	Spindle Assembly, Left	42	17x146	Washer
22	01x111	Bolt			

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

# MODEL 312002x98B

# REPAIR PARTS MOWER HOUSING SUSPENSION



# MODEL 312002x98B


# REPAIR PARTS MOWER HOUSING SUSPENSION

Key No.	Part No.	Description	Key No.	Part No.	Description
1	092698	Grip	26	001x74	Bolt, Hex
2	094157 Z	Handle, PTO	27	690386E700	Arm Assembly, Right Lift
3	094022 Z	Pad, Switch	28	094180E700	Arm, Right Lift
4	0025x3	Bolt	29	094030E700	Plate, Lift Arm
5	092697	Grip	30	094067	Pin
6	166x40	Spring	31	094055E701	Bracket, Rear Suspension
7	17x103	Washer	32	094065	Bushing, Lift Tube
8	690533	Handle, Lift	33	009x53	Bolt, Shoulder
9	094017 Z	Lever, PTO	34	094015E700	Bracket, Pivot
10	009x39	Bolt, Shoulder	36	17x191	Washer
11	030x20	Pin, Cotter	37	015x84	Nut, Flange
12	017x57	Washer	38	165x117	Spring
13	094004 Z	Link, PTO	39	015x68	Nut, Flange
14	015x84	Nut, Flange	40	094005E700	Bracket, PTO
15	26x249	Screw	41	094026E700	Hanger, Right Deck
16	166x39	Spring	42	094027E700	Hanger, Left Deck
17	094018E701	Bracket, PTO	43	094158 Z	Rod, Hanger
18	165x116	Spring	44	690381E700	Hanger, Front
19	690394E701	Crank, PTO	45	015x89	Nut, Flange
20	094053E701	Link, Lift	46	030x49	Pin, Cotter
21	094028 Z	Link, Lift Handle	47	690382	Pin, Threaded Shoulder
22	15x118	Nut, Flange	48	26x49	Screw
23	017x57	Washer	49	01x106	Bolt, Hex
24	0031x4	Pin, Hair	50	017x38	Washer
25	017x91	Washer	51	690370E701	Plate, Weight (4 Required)



# MODEL 312002x98B

# REPAIR PARTS MOWER HOUSING




# MODEL 312002x98B

# REPAIR PARTS MOWER HOUSING

<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	690432	Pulley	30	015x89	Nut, Flange
2	015x84	Nut, Flange	31	054695	Strap, Rubber
3	15x140	Nut	32	01x139	Screw
4	037x74	Belt, Blade	33	690367	Chute
5	690387	Pulley, Idler	34	015x79	Nut
6	094129	Mandrel	35	165x118	Spring, PTO
7	0025x7	Screw	36	165x140	Spring, Extension
8	092424	Guide, Belt	37	015x84	Nut, Flange
9	094130	Spacer	38	690380E700	Bracket, Front Deck
10	094055E701	Bracket, Rear Suspension	39	094067	Pin, Threaded Shoulder
11	009x52	Bolt, Shoulder	40	017x91	Washer
12	094068	Knob	41	0031x4	Pin, Hair
13	017x45	Washer	42	690381E700	Hanger, Front
14	009x51	Bolt, Shoulder	43	1401275	Housing, Jackshaft
15	690379E700	Plate, Suspension	44	690359	Fan, Assist
16	094137	Pad, Friction	45	1001237E701	Housing, Fan
17	166x43	Spring	46	017x37	Washer
18	015x79	Nut, Flange	47	001x71	Bolt
19	690378E700	Bracket, Rear Deck	48	001x106	Bolt
20	095194	Pin, Hanger	49	15x100	Nut
21	094053	Link, Lift	50	17x165	Washer
22	15x116	Nut	51	17x166	Washer, Belleville
23	690427E700	Bracket, Idler Arm	52	690398E701	Blade
24	690647	Assembly, Idler Arm & Pad	53	092466	Adapter, Blade
25	26x249	Screw	54	01x121	Bolt
26	009x39	Bolt, Shoulder	55	015x98	Nut, Flange
27	002x64	Bolt, Carriage	56	690369	Spacer
28	690530E700	Housing, Blade	1-56	776110	Blade Housing, Complete
29	690399E700	Baffle			


# MODEL 312002x98B

# REPAIR PARTS ENGINE MOUNT



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	092317	Fuel Cap (Incl'd w/Key 2)
2	690280	Fuel Tank
3	095197	Hose Clamp (Incl'd w/Key 2)
4	7601033	Fuel Line (Incl'd w/Key 2) (st cut to Length)
5	095197	Hose Clamp
6	26x201	Screw
7	094006E701	Plate, Engine
8	092371	Throttle Control
9	— * —	Engine, Briggs & Stratton
10	0025x7	Bolt, Engine Mount
11	690439 Z	Stack Pulley Assembly
12	019x35	Lockwasher
13	01x140	Bolt, Hex
14	17x170	Washer
15	26x249	Screw
16	091309	Gasket
17	091271	ffler
18	1001350	Deflector, ffler
19	26x208	Screw
20	01x134	Bolt, Hex
21	093349	Guide, Belt
22	015x79	Nut, Flange
23	094066	Guide, Belt
24	10015950 Z	Shield, Heat
26	26x253	Screw
27	26x263	Screw
28	091277	Shield, Heat
29	093077	Spacer, Engine

\* For information on Replacement Parts for this engine contact the manufacturer.




IGNITION SWITCH	
OFF	M+G
RUN 1	X+L
RUN 2	-----
START	B+S

**MAIN HARNESS: 250X126**  
**REAR HARNESS: 250X130**  
**LIGHT HARNESS: 250X92**

<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	250x92	Harness, Light Wire
	1001716	Socket, Light
	090084	Bulb, Light
2	250x126	Harness, Chassis Wire
3	092377	Switch, Ignition
	020729	Key, Ignition
	091489	Nut, Hex
	091488	Cap, Ignition
4	1001575	Switch, Limit
5	302031	Fuse
	407078	Holder, Fuse
6	094613	Solenoid
	26x229	Screw, Mounting
	15x116	Locknut
7	024x32	Cable, Battery Ground
	26x229	Screw, Ground Cable
8	021075	Battery
	002x82	Bolt, Carriage
	014x79	Wingnut
	690604	Boot, Battery –Positive
9	250x130	Harness, Seat Switch Wire
10	094159	Switch, Seat Sensor
11	024x31	Cable
12	1001845	Switch, Bag Sensor
13	094136	Switch, Limit

# MODEL 312002x98B

# REPAIR PARTS GRASS BAGGER



# MODEL 312002x98B

# REPAIR PARTS GRASS BAGGER

<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	690404	Tube, Top	15	015x89	Nut, Flange
2	01x121	Bolt	16	17x185	Washer
3	15x116	Nut	17	690402	Latch, Spring
4	690433	Strut, Bag	18	690362E701	Pan, Rear
5	015x79	Nut, Flange	19	002x53	Bolt, Carriage
6	0193x2	Fastener, Panel	20	690355E700	Bracket, Bagger Mounting
7	690491	Seal, Bag (Right End)	22	1001000E701	Plate, Hitch
8	690492	Seal, Bag (Center)	23	1001001E701	Bracket, Lower Mounting
9	690493	Seal, Bag (Left End)	24	1001002E701	Plate, Hitch
10	690356E700	Hinge	26	054563	Pin, Latch
11	26x249	Screw	27	002x39	Bolt, Carriage
12	690403	Assembly, Bag Frame	28	690368	Tube, Connecting
13	690400E700	Bracket, Switch	29	690429	Grommet, Extension Tube
14	002x82	Bolt, Carriage	30	690438	Bag, Grass