


# MODEL 405602x51A

## REPAIR PARTS CHASSIS & HOOD



# MODEL 405602x51A


# REPAIR PARTS CHASSIS & HOOD

Key No.	Part No.	Description
1	690566	Seat
2	028x23	Cap, Push On
3	094057	Spring
4	26x229	Screw
5	1001054	Bolt, Wing
6	017x47	Washer
7	009x56	Bolt, Shoulder
8	094154E701	Support, Seat
9	094156 Z	Rod, Pivot
10	1001648E701	Bracket, Pivot
11	001x45	Bolt
12	015x89	Nut
13	009x55	Bolt, Shoulder
14	094155 Z	Washer
15	164x31	Spring
16	26x249	Screw
17	26x263	Screw
18	164x30	Spring
19	1001559E245	Deck, Seat
20	015x123	Nut
21	094829E700	Plate, Index
23	094999	Mat, Left
24	094998	Mat, Right
25	1001492E245	Hood
26	094079E700	Grille
27	094081	Lens, Left
28	094807 Z	Bezel

Key No.	Part No.	Description
29	094080	Lens, Right
30	094376	Bumper
31	26x270	Screw
32	26x238	Screw
33	1001491	Bearing, Steering
34	1001584E700	Dash
35	26x201	Screw
36	093007E701	Panel, Access
37	095318E701	Support, Dash
38	1001270E701	Bracket, Rear Hanger
39	094083E701	Support, Left Grille
40	094007E701	Axle, Hanger
41	094082E701	Support, Right Grille
42	009x58	Bolt, Shoulder
43	1001928E701	Frame, Right
44	1001927E701	Frame, Left
45	690424	Container, Battery
46	1001002E700	Plate, Hitch
47	690434E700	Panel, Rear
48	690482E701	Bracket, Battery Support
49	015x81	Nut
50	15x124	Nut
51	26x277	Screw
70	1001542	Holder, Cup
—	690651	Bag, Assembly Parts
—	F-040753L	Instruction Book & Parts List

# MODEL 405602x51A

## REPAIR PARTS DRIVE ASSEMBLY



# MODEL 405602x51A

# REPAIR PARTS DRIVE ASSEMBLY


Key No.	Part No.	Description	Key No.	Part No.	Description
1	26x249	Screw	30	092132 Z	Nut, Adjusting
2	091079	Grip, Parking Brake	31	015x84	Nut, Centerlock
4	1001245 Z	Rod, Parking Brake	32	030x20	Pin, Cotter
5	094008E701	Bracket, Left Transaxle	33	017x48	Washer
6	1001013 Z	Rod, Clutch	34	165x92	Spring, Extension
7	094045 Z	Latch, Parking Brake	35	17x148	Washer
8	37x106	V-Belt, Drive	36	1001086 Z	Arm, Disconnect
9	015x79	Nut, Flange	37	06x105	Capscrew
10	021544	Pedal, Brake/Clutch	38	165x150	Spring, Brake
11	1001011E701	Assembly, Brake Pedal	39	015x98	Locknut, Flange
12	094384	Screw, Guide	40	690409	Pulley, Idler
14	002x53	Bolt, Carriage	41	690369	Spacer
15	017x57	Washer	42	1001097E701	Bracket, Idler Assembly
16	0031x4	Pin, Hair	43	009x49	Bolt, Shoulder
17	095121E701	Pedal Assembly, Hydro	44	1001007 Z	Link, Clutch
18	092289-601	Wheel & Tire Ass'y, Rear	45	1001014	Nut, Tee
--	091914	Tire ONLY *	46	690410	Pulley, Idler
--	407049	Tube ONLY	47	1001012	Bushing, Pivot
19	17x160	Washer	48	1001018 Z	Arm Assembly, Idler
20	690554 Z	Spacer	49	094008E701	Bracket, Right Transaxle
21	024373	Stem, Valve	50	01x155	Bolt, Hex
22	17x195	Washer	51	1001214 Z	Bracket, Dump Valve
23	0011x3	E-Ring	52	1001215 Z	Rod, Roll Release
24	094618	Cap, Hub	53	1001108E701	Bracket, Idler Pivot
25	015x88	Nut, Centerlock	54	002x92	Bolt, Carriage
26	--- ** ---	Transaxle, Peerless Hydro	55	002x78	Bolt, Carriage
27	1001085E701	Strap, Torque	56	165x155	Spring, Clutch
28	26x216	Screw	57	017x38	Washer
29	1001234 Z	Rod, Control	58	021553	Key, Square 3/16"

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

\*\* For information on Replacement Parts for this transaxle contact the manufacturer.

# MODEL 405602x51A

## REPAIR PARTS STEERING





# MODEL 405602x51A


# REPAIR PARTS STEERING

Key No.	Part No.	Description	Key No.	Part No.	Description
1	095336	Wheel, Steering	23	17x104	Washer
2	690625	Post, Steering	24	017x53 Z	Washer
3	095338	Insert, Steering Wheel	25	015x84	Nut, Flange
4	094124	Bearing	26	1001460E701	Axle Assembly
5	15x111	Nut, Flange	27	095329E701	Drag Link, Left
6	009x57	Bolt, Shoulder	28	094575E701	Spindle Assembly, Right
7	690183	Gear, Pinion	29	095328E701	Drag Link, Right
8	011x25	Ring, Snap	30	26x249	Screw
9	094121	Gear, Sector	31	091334	Bearing, Wheel
10	094123	Bearing	32	024373	Stem, Valve
11	001x84	Bolt	33	091912	Tire *
12	1001121E701	Plate, Steering	—	407046	Tube
13	094006E700	Plate, Engine	34	1001840-601	Wheel and Tire Assembly
14	015x88	Nut, Flange	35	17x195	Washer
15	15x118	Nut, Flange	36	17x192	Washer
16	1001270E701	Bracket, Hanger	37	17x113	Washer
17	094007E701	Axle, Hanger	38	094618	Hub Cap
18	01x146	Bolt	39	26x267	Screw
19	030x49	Pin, Cotter	40	092059	Bellows
20	690150	Bearing	41	0025x3	Bolt
21	094576E701	Spindle Assembly, Left	42	17x146	Washer
22	01x111	Bolt			

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.


**MODEL 405602x51A**

**REPAIR PARTS  
MOWER HOUSING SUSPENSION**



# MODEL 405602x51A

# REPAIR PARTS MOWER HOUSING SUSPENSION



Key No.	Part No.	Description	Key No.	Part No.	Description
1	092698	Grip	23	017x57	Washer
2	094157 Z	Handle, PTO	24	0031x4	Pin, Hair
3	094022 Z	Pad, Switch	25	017x91	Washer
4	0025x3	Bolt	26	002x85	Bolt, Carriage
5	092697	Grip	27	1001111E701	Lever Assembly, Lift
6	166x40	Spring	30	094067	Pin
7	17x103	Washer	31	094055E701	Bracket, Rear Suspension
8	690533	Handle, Lift	32	690151	Spacer, Lifter
9	094017 Z	Lever, PTO	33	009x53	Bolt, Shoulder
10	009x39	Bolt, Shoulder	34	094015E700	Bracket, Pivot
11	030x20	Pin, Cotter	36	17x191	Washer
13	094004 Z	Link, PTO	37	015x84	Nut, Flange
14	015x84	Nut, Flange	38	165x131	Spring
15	26x249	Screw	39	015x68	Nut, Flange
16	166x39	Spring	40	094005E700	Bracket, PTO
17	094018E701	Bracket, PTO	41	094027E701	Hanger, Left Deck
18	165x119	Spring	42	094026E701	Hanger, Right Deck
19	690394E701	Crank, PTO	43	094158 Z	Rod, Hanger
20	690212E701	Link, Lift	44	690539E701	Bracket, Suspension
21	690122E700	Link, Lift Handle	45	1001098E701	Plate, Stiffening





# MODEL 405602x51A


# REPAIR PARTS MOWER HOUSING

Key No.	Part No.	Description	Key No.	Part No.	Description
1	092851	Pulley, Jackshaft	30	094142E700	Bracket, Suspension
2	15x140	Nut, Hex	31	091770E700	Plate
3	037x62	Belt, Mower Drive	32	015x88	Nut, Flange
4	690387	Pulley, Idler	33	002x53	Bolt, Carriage
5	015x84	Nut, Flange	34	1001200	Mandrell (Includes Key 6)
6	1001197 *	Spacer, Pulley	35	690539E701	Bracket, Suspension
8	690212E701	Link, Lift	36	690411	Adapter, Blade
9	094137	Pad, Friction	37	1001428E701	Blade
10	009x52	Bolt, Shoulder	38	17x166	Washer
11	094055E701	Bracket, Suspension	39	17x165	Washer
12	094049E701	Pad Assembly, Left Brake	40	15x100	Nut
13	094068	Knob	41	0166x4	Spring
14	009x51	Bolt, Shoulder	42	028x23	Cap, Push On
15	094128E700	Plate, Suspension	43	094957 Z	Rod, Pivot
16	166x43	Spring	44	094707	Deflector Assembly
17	015x79	Nut, Flange	45	094956E701	Bracket, Deflector
18	094143E700	Bracket, Suspension	46	094144E700	Bracket, Front Hanger
19	095194	Pin, Hanger	47	017x45 Z	Washer
20	017x91	Washer	48	094781	Guide, Belt
21	0031x4	Pin, Cotter	50	094681E700	Bracket, Support
22	0025x7	Bolt	51	26x249	Screw
23	094051E701	Cover, Pulley	52	165x119	Spring, Extension
24	009x39	Bolt, Shoulder	53	690369	Spacer
25	1001500	Arm, Idler	54	7601060	Housing, Blade
26	0166x41	Spring	55	015x98	Nut, Flange
27	094047E701	Pad Assembly, Right Brake	56	009x72	Bolt, Shoulder
28	094145E700	Bracket Assembly, Brake	1-56	7601044	Complete Mower Housing Assy.
29	166x42	Spring			

\* Included with Key 34.


# MODEL 405602x51A

# REPAIR PARTS ENGINE MOUNT



# MODEL 405602x51A

## REPAIR PARTS ENGINE MOUNT



Key No.	Part No.	Description
1	092317	Fuel Cap **
2	690294	Fuel Tank
3	095197	Hose Clamp **
4	302031	Fuel Line (must cut to length) **
5	095197	Hose Clamp
6	26x201	Screw
7	094006E701	Plate, Engine
8	092371	Throttle Control
9	— * —	Engine, Tecumseh
10	0025x7	Bolt, Engine Mount
11	690439 Z	Stack Pulley Assembly
12	019x35	Lockwasher
13	01x140	Bolt, Hex
14	17x170	Washer
15	26x249	Screw
16	094120	Muffler
17	091309	Gasket
18	092378	Lock, Screw
19	01x134	Bolt
21	094384	Guide, Belt
22	015x79 Z	Nut, Flange
23	094066	Guide, Belt
26	26x253	Screw
28	1001459	Heat Shield Assembly –Muffler
29	15x122	Nut


\* These parts are included with Key No. 2.

\*\* For information on Replacement Parts for this engine contact the manufacturer.



# MODEL 405602x51A

# REPAIR PARTS ELECTRICAL SYSTEM



Key No.	Part No.	Description
1	250x92	Harness, Light Wire
	1001716	Socket, Light
	090084	Bulb, Light
2	250x113	Harness, Chassis Wire
3	092377	Switch, Ignition
	020729	Key, Ignition
	091489	Nut, Hex
	091488	Cap, Ignition
4	1001575	Switch, Limit
5	302031	Fuse
	407078	Holder, Fuse
6	094613	Solenoid
	26x229	Screw, Mounting
	15x116	Locknut
7	024x32	Cable, Battery Ground
	26x213	Screw, Ground Cable
8	021075	Battery
	002x82	Bolt, Carriage
	014x79	Wingnut
	690604	Boot, Battery –Positive
9	250x67	Harness, Seat Switch Wire
10	094159	Switch, Seat Sensor
11	024x31	Cable