



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	1001028	Seat	31	26x270	Screw
2	028x23	Cap, Push On	32	26x238	Screw
3	094057	Spring	33	1001491	Bearing, Steering
4	26x229	Screw	34	1001593E701	Dash
5	1001054	Bolt, Wing	35	26x201	Screw
6	017x47 Z	Washer	36	093007E701	Panel, Access
7	009x56	Bolt, Shoulder	37	095318E701	Support, Dash
8	094154E701	Support, Seat	38	1001270E701	Bracket, Rear Hanger
9	094156 Z	Rod, Pivot	40	094007E701	Axle, Hanger
10	1001648E701	Bracket, Pivot	43	1001268E701	Frame, Right
11	001x45	Bolt	44	1001269E701	Frame, Left
12	015x89	Nut	45	690424	Container, Battery
13	009x55	Bolt, Shoulder	46	1001002E701	Plate, Hitch
14	094155 Z	Washer	47	690218E700	Plate, Rear
15	164x31	Spring	48	94186E700	Top, Rear Plate
16	26x249	Screw	50	015x81	Nut
17	26x263	Screw	51	690482E701	Bracket, Battery Support
18	164x30	Spring	53	1001617	Insert, Grille
19	1001557E700	Deck, Seat	55	0193x1	Fastener, Panel
20	15x123	Nut	56	094680	Cover, Detent
21	094194E701	Plate, Index	57	1001652	Trim, Hood (3.75")
22	009x47	Screw	58	1001653	Trim, Hood (6.5")
23	095408	Mat, Left	59	1001755	Grommet, Parking Brake
24	1001827	Mat, Right	60	1001456	Shield, Heat
25	1001537E700	Hood	61	009x58	Bolt, Shoulder
26	1001533E700	Grille	62	15x124	Locknut, Flange
27	1001552	Lens, Left	63	165x124	Spring
28	1001550	Housing, Left Headlamp	70	1001542	Holder, Cup
29	1001551	Lens, Right	—	690622	Parts Bag, Assembly
30	1001549	Housing, Right Headlamp	—	F-040703L	Instruction Book & Parts List



Key No.	Part No.	Description	Key No.	Part No.	Description
1	094497	Grip, Shift	40	1001576	Link, Variator
2	030x20	Pin, Cotter	40a	01x194	Bolt, Hex
3	094043 Z	Lever, Shift	40b	1001520	Spacer, 1/2"
4	017x47	Washer	40c	1001519	Spacer, 3/4"
5	094044 Z	Link, Shifter	41	093349	Guide, Belt
6	021920	Nut, Adjuster	42	1001277E701	Bracket, Front Frame
7	091079	Grip	43	015x87	Nut, Lock
8	1001245 Z	Rod, Parking Brake	44	165x153	Spring, Extension
9	015x84	Nut	45	690409	Pulley
10	1001187	Pulley, Idler	46	690369	Spacer
11	1001122	Guide, Belt	47	015x98	Nut
12	1001121E701	Plate, Steering	48	1001133	Assembly, Variator and Idler
13	015x79	Nut	49	037x112	Belt, Primary
14	01x111	Bolt, Hex	50	037x113	Belt, Secondary
15	1001138	Pad, Motion Drive	51	1001106	Pulley, Transaxle
16	1001148E700	Assembly, Speed Control	52	0011x7	Ring, Snap
17	26x249	Screw, Self Tapping	53	094045 Z	Latch, Parking Brake
18	1001139	Pad, Brake Pedal	54	094815	Nut, Adjusting
19	1001147E700	Assembly, Brake Pedal	55	1001145 Z	Rod, Clutch
20	165x115	Spring, Extension	56	1001135 Z	Bracket, Brake
21	17x169	Washer	57	094433E701	Strap, Torque
22	1001120	Rod, Speed Control	58	002x53	Screw
23	1001104 Z	Bellcrank	59	1001268E701	Rail, Right Frame
24	009x39	Bolt, Shoulder	60	1001269E701	Rail, Left Frame
25	17x124	Washer	61	1001302E701	Bracket, Right Shift
26	165x152	Spring, Extension	62	17x102	Washer
27	06x105	Screw, Cap	63	1001303 Z	Bracket, Shift Pivot
28	17x148	Washer	64	26x267	Screw
29	—	Transaxle	65	1001132 Z	Assembly, Idler
30	015x88	Nut	66	094031 Z	Yoke, Shift
31	092300-650	Assembly, Wheel and Tire	67	1001136	Pulley, Stack
31a	024430	Tire *	68	0031x4	Pin, Hair
31b	024373	Stem, Valve	69	1001308	Guide, Belt
32	17x195	Washer	70	165x75	Spring, Return
33	0011x3	E-Ring	71	26x216	Screw
34	094618	Hubcap	72	0031x6	Pin, Hair
35	17x160	Washer	73	017x38	Washer
36	690554 Z	Spacer	74	1101159	Bearing
37	021553	Key, Square	75	1001267 Z	Rod, Belt Guide
38	01x155	Bolt, Hex	76	028x23	Nut, Push-On
39a	094184E701	Bracket, Right Transaxle	77	17x174 Z	Washer
39b	094185E701	Bracket, Left Transaxle			


\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

\*\* For information on Replacement Parts for this transaxle contact the manufacturer.




Key No.	Part No.	Description	Key No.	Part No.	Description
1	095185	Wheel, Steering	23	17x104	Washer
2	690625	Post, Steering	24	017x53 Z	Washer
3	711326	Insert, Steering Wheel	25	015x84	Nut, Flange
4	094124	Bearing	26	1001460E701	Axle Assembly
5	15x111	Nut, Flange	27	095329E701	Drag Link, Left
6	009x57	Bolt, Shoulder	28	094575E701	Spindle Assembly, Right
7	690183	Gear, Pinion	29	095328E701	Drag Link, Right
8	011x25	Ring, Snap	30	26x249	Screw
9	094121	Gear, Sector	31	091334	Bearing, Wheel
10	094123	Bearing	32	024373	Stem, Valve
11	001x84	Bolt	33	024380	Tire *
12	1001121E701	Plate, Steering	—	407924	Tube
13	094006E701	Plate, Engine	34	094581-650	Wheel and Tire Assembly
14	015x88	Nut, Flange	35	17x195	Washer
15	15x118	Nut, Flange	36	17x192	Washer
16	1001270E701	Bracket, Hanger	37	17x113	Washer
17	094007E701	Axle, Hanger	38	094618	Hub Cap
18	01x146	Bolt	39	26x267	Screw
19	030x49	Pin, Cotter	40	092059	Bellows
20	690150	Bearing	41	0025x3	Bolt
21	094576E701	Spindle Assembly, Left	43	17x146	Washer
22	01x111	Bolt			

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.




Key No.	Part No.	Description	Key No.	Part No.	Description
1	094496	Grip, PTO	24	0031x4	Pin, Hair
2	094826 Z	Handle, PTO	25	017x91 Z	Washer
3	094022 Z	Pad, Switch	26	002x85	Bolt, Carriage
4	0025x3	Bolt	27	1001111E701	Lever Assembly, Lift
5	094497	Grip, Lift	30	094067	Pin
6	166x40	Spring	31	094055E701	Bracket, Rear Suspension
7	17x103	Washer	32	690151	Spacer, Lifter
8	690533	Lever, Lift	33	009x53	Bolt, Shoulder
9	094017 Z	Lever, PTO	34	094015E701	Bracket, Pivot
10	009x39	Bolt, Shoulder	36	17x191	Washer
11	030x20	Pin, Cotter	37	015x84	Nut, Flange
12	017x57	Washer	38	165x133	Spring
13	094004 Z	Link, PTO	39	015x68	Nut, Flange
14	015x84	Nut, Flange	40	094005E700	Bracket, PTO
15	26x249	Screw	41	094027E701	Hanger, Left Deck
16	166x39	Spring	42	094026E701	Hanger, Right Deck
17	094018E701	Bracket, PTO	43	094158 Z	Rod, Hanger
18	165x120	Spring	44	690539E701	Bracket, Suspension
19	690394E701	Crank, PTO	45	1001098E701	Plate, Stiffening
20	690212E701	Link, Lift	46	094042 Z	Stud, Spring Mount
21	690122E701	Link, Lift Handle	47	690182	Stud, Swivel
22	17x168	Washer	48	015x88	Nut
23	017x57	Washer			





Key No.	Part No.	Description	Key No.	Part No.	Description
1	094607E701	Cover, Right Pulley	46	166x34	Spring, Torsion
2	26x250	Screw	47	092159 Z	Rod, Deflector
3	26x249	Screw	48	092140E701	Bracket, Cover
4	091754 Z	Guide, Belt	49	165x120	Spring, Extension
5	094645E701	Cover, Left Pulley	50	092104E701	Bracket, Hinge
6	015x79	Nut, Hex	51	015x88	Nut, Flange
7	15x140	Nut, Flange	52	094601E701	Bracket, Bell Crank
8	015x84	Nut, Flange	53	094603E701	Crank, Bell
9	037x89	Belt, Primary	54	094596E701	Plate, Brake Arm
10	094592	Pulley	55	094602E701	Bracket, Brake Plate
11	037x66	Belt, Secondary	56	094919E700	Bracket, Left Gauge Wheel
12	690549	Pulley, Idler	57	094025	Axle
13	094639	Arm, Idler	58	017x91 Z	Washer
14	009x39	Bolt, Shoulder	59	031x11	Ring, Locking
15	1001197	Spacer, Pulley	60	092683	Wheel, Gauge
16	690387	Pulley, Idler	61	094918E701	Bracket, Right Gauge Wheel
17	009x52	Bolt, Shoulder	62	092103E701	Deflector, Inside
18	094068	Knob	63	002x53	Bolt, Carriage
19	017x45 Z	Washer	64	030x49	Pin, Cotter
20	009x51	Bolt, Shoulder	65	017x57	Washer
21	094055E701	Bracket, Rear Suspension	66	094997SE	Bracket, Front Deck
22	094128E700	Plate, Suspension	67	094996	Rod, Hanger
23	094137	Pad, Friction	68	094604E701	Stiffener
24	166x43	Spring	69	690539E701	Bracket, Front Suspension
25	690212E701	Link, Lift	70	690411	Adapter, Blade
26	094600E700	Bracket, Left Lift	72	1001252	Roller
27	095194	Pin, Hanger	73	1001200	Housing, Jackshaft
28	0031x4	Pin, Hair	74	056631E701	Blade
29	094640E701	Brake Assembly, Left	75	17x166	Washer, Belleville
31	166x41	Spring	76	15x100	Nut
32	030x20	Pin, Cotter	77	17x165	Washer
33	094641E701	Brake Assembly, Right	78	690221E701	Bracket, Pulley Cover
34	017x47 Z	Washer	79	690369	Spacer
35	690579E700	Idler, Arm	80	019x35	Washer
36	17x103	Washer	81	094996	Rod, Hanger
37	094606 Z	Link, Bell Crank	82	26x277	Screw
38	092116 Z	Guide, Belt	84	094936E701	Housing, Blade *
39	0025x7	Screw	1-84	7601031	Complete Mower Housing
40	165x79	Spring, Extension	87	091797 Z	Guide, Belt
41	166x42	Spring, Torsion	88	025x15	Screw
42	094598E701	Bracket, Suspension	90	095086	Cover, Mulch
43	015x98	Nut	91	014x86	Wingnut
44	092100	Deflector, Chute	92	002x64	Bolt, Carriage
45	028x23	Push On Cap			


\* Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	092317	Cap, Fuel **	26	711851	Gasket
2	690289	Tank, Fuel	27	018x15	Washer
3	26x253	Screw	28	06x103	Bolt
6	26x263	Screw	29	690541	Tube, Right Exhaust
14	*	Engine *	30	690542	Tube, Left Exhaust
15	7601033	Line, Fuel (18 inches long) **	31	690537E701	Bracket, Muffler Mounting
16	095197	Clamp **	32	093259	Muffler
18	092279	Pipe, Oil Drain	33	690538E701	Bracket, Muffler
19	021651	Cap, Oil Drain	34	690401	Choke
20	0025x7	Bolt	35	015x68	Nut
21	093077	Spacer	36	26x201	Screw
22	1001136	Pulley, Stack	37	093165	Control, Throttle
23	17x170	Washer	38	1001456E701	Shield Assembly, Heat
24	019x35	Lockwasher	39	1001588	Plenum
25	01x140	Bolt			

\* For information on Replacement Parts for this engine contact the manufacturer.

\*\* These parts are included with Key number 2.



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	250x92	Harness, Light Wire
--	1001716	Socket, Light
--	090084	Bulb, Light
2	250x117	Harness, Chassis Wire
3	092556	Switch, Ignition
--	020729	Key, Ignition
--	091489	Nut, Hex
--	091488	Cap, Ignition
4	094136	Switch, Limit
5	302031	Fuse
--	407078	Holder, Fuse
6	094613	Solenoid
--	26x229	Screw, Mounting
--	15x116	Locknut
7	024x32	Cable, Battery Ground
--	26x213	Screw, Ground Cable
8	021075	Battery
--	002x82	Bolt, Carriage
--	014x79	Wingnut
9	250x67	Harness, Seat Switch Wire
10	094159	Switch, Seat Sensor
11	024x31	Cable

