


MODEL 465601x50B

REPAIR PARTS CHASSIS AND HOOD



MODEL 465601x50B


REPAIR PARTS CHASSIS AND HOOD

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	095236	27	Screw **	26x239
2	Cap, Push On	028x23	28	Lens, Right **	092539
3	Spring	094057	29	Brace, Grille **	092541
4	Screw	26x229	30	Pin, Hair	031x4
5	Bolt, Wing	1001054	31	Screw	26x270
6	Washer	017x47	32	Screw	26x238
7	Bolt, Shoulder	009x56	33	Bearing, Steering	094219
8	Support, Seat	094154E700	34	Dash (Grey)	095034
9	Rod, Pivot	094156 Z	35	Plate, Dash	094221E700
10	Bracket, Pivot	094153E700	36	Panel, Access	093007E700
11	Bolt	001x45	37	Support, Dash	095082E700
12	Nut	015x89	38	Bracket, Rear Hanger	1001270E701
13	Bolt, Shoulder	009x55	40	Axle, Hanger	094007E701
14	Washer	094155 Z	43	Frame, Right	1001268E701
15	Spring	164x31	44	Frame, Left	1001269E701
16	Screw	26x249	45	Container, Battery	690424
17	Screw	26x263	46	Plate, Hitch	1001002E701
18	Spring	164x30	47	Plate, Rear	690218E700
19	Deck, Seat	1001556E245	48	Top, Rear Plate	094186E700
20	Nut	015x88	49	Channel	095081E700
21	Plate, Index	094886E700	50	Lens, Left **	092540
22	Screw	009x47	52	Support, Battery	690482E701
23	Mat, Left	095437	55	Clip (Grey)	311087
24	Mat, Right	095438	70	Holder, Cup	1001542
25	Hood	093215E245	—	Instruction Book & Parts List	F-030734L
26	Grille Assembly (Includes Lens)	094869			

** These parts are included with Key number 26.

MODEL 465601x50B

REPAIR PARTS DRIVE ASSEMBLY



MODEL 465601x50B

REPAIR PARTS DRIVE ASSEMBLY


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Screw	26x249	30	Nut, Adjusting	092132
2	Grip, Parking Brake	091079	31	Nut, Centerlock	015x84
4	Rod, Parking Brake	1001271 Z	32	Pin, Cotter	030x20
5	Bracket, Left Transaxle	094185E701	33	Washer	017x48
6	Rod, Clutch	1001013 Z	34	Spring, Extension	165x92
7	Latch, Parking Brake	094045 Z	35	Washer	17x148
8	V-Belt, Drive	37x106	36	Arm, Disconnect	1001086 Z
9	Nut, Flange	015x79	37	Capscrew	06x105
10	Pedal, Brake/Clutch	021544	38	Spring, Brake	165x150
11	Assembly, Brake Pedal	1001011E701	39	Locknut, Flange	015x98
12	Screw, Guide	094384	40	Pulley, Idler	690409
14	Bolt, Carriage	002x53	41	Spacer	690369
15	Washer	017x57	42	Bracket, Idler Assembly	1001097E701
16	Pin, Hair	0031x4	43	Bolt, Shoulder	009x49
17	Pedal Assembly, Hydro	1001231E701	44	Link, Clutch	1001007 Z
18	Wheel & Tire Ass'y, Rear	092300-601	45	Nut, Tee	1001014
--	Tire ONLY *	024430	46	Pulley, Idler	690410
--	Tube ONLY	407049	47	Bushing, Pivot	1001012
19	Washer	17x160	48	Arm Assembly, Idler	1001018 Z
20	Spacer	690554 Z	49	Bracket, Right Transaxle	094184E701
21	Stem, Valve	024373	50	Bolt, Hex	01x155
22	Washer	17x195	51	Bracket, Disconnect	1001214 Z
23	E-Ring	0011x3	52	Rod, Disconnect	1001215 Z
24	Cap, Hub	094618	53	Bracket, Idler Pivot	1001108E701
25	Nut, Centerlock	015x88	54	Bolt, Carriage	002x92
26	Transaxle	**	55	Bolt, Carriage	002x78
27	Strap, Torque	1001085E701	56	Spring, Clutch	165x155
28	Screw	26x216	57	Washer	017x38
29	Rod, Control	1001234 Z			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** For information on Replacement Parts see the Central Parts Distributor in your area.

MODEL 465601x50B

REPAIR PARTS
STEERING



F-030734L

MODEL 465601x50B


**REPAIR PARTS
STEERING**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	095184	23	Washer	17x104
2	Post, Steering	690338	24	Washer	017x53 Z
3	Insert, Steering Wheel	711325	25	Nut, Flange	015x84
4	Bearing	094124	26	Axle Assembly	1001460E701
5	Nut, Flange	15x111	27	Drag Link, Left	095329E701
6	Bolt, Shoulder	009x57	28	Spindle Assembly, Right	094575E701
7	Gear, Pinion	690183	29	Drag Link, Right	095328E701
8	Ring, Snap	011x25	30	Screw	26x249
9	Gear, Sector	094121	31	Bearing, Wheel	091334
10	Bearing	094123	32	Stem, Valve	024373
11	Bolt	001x84	33	Tire *	024380
12	Plate, Steering	1001121E701	—	Tube	407924
13	Plate, Engine	094006E700	34	Wheel and Tire Assembly	094581-601
14	Nut, Flange	015x88	35	Washer	17x195
15	Nut, Flange	15x118	36	Washer	17x192
16	Bracket, Hanger	1001270E701	37	Washer	17x113
17	Axle, Hanger	094007E701	38	Hub Cap	094618
18	Bolt	01x146	39	Screw	26x267
19	Pin, Cotter	030x49	40	Bellows	092059
20	Bearing	690150	41	Bolt	0025x3
21	Spindle Assembly, Left	094576E701	42	Washer	17x146
22	Bolt	01x111			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

MODEL 465601x50B

REPAIR PARTS MOWER HOUSING SUSPENSION




MODEL 465601x50B

**REPAIR PARTS
MOWER HOUSING SUSPENSION**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Grip, PTO	092698	25	Washer	017x91
2	Handle, PTO	094217 Z	26	Bolt, Carriage	002x85
3	Pad, Switch	094022 Z	27	Lever Assembly, Lift	1001111E701
4	Bolt	0025x3	30	Pin	094067
5	Grip	092697	31	Bracket, Rear Suspension	094055E701
6	Spring	166x40	32	Spacer, Lifter	690151
7	Washer	17x103	33	Bolt, Shoulder	09x53
8	Handle, Lift	690533	34	Bracket, Pivot	094015E700
9	Lever, PTO	094017 Z	36	Washer	17x191
10	Bolt, Shoulder	009x39	37	Nut, Flange	015x84
11	Pin, Cotter	030x20	38	Spring	165x133
13	Link, PTO	094004 Z	39	Nut, Flange	015x68
14	Nut, Flange	015x84	40	Bracket, PTO	094005E700
15	Screw	26x249	41	Hanger, Left Deck	094027E700
16	Spring	166x39	42	Hanger, Right Deck	094026E700
17	Bracket, PTO	094018E701	43	Rod, Hanger	094158 Z
18	Spring	165x120	44	Bracket, Suspension	690539E701
19	Crank, PTO	690394E701	45	Plate, Stiffening	1001098E701
20	Link, Lift	690212E701	46	Stud, Spring Mount	094042 Z
21	Link, Lift Handle	690122E700	47	Stud, Swivel	690182
22	Washer	17x168	48	Nut	015x88
23	Washer	017x57			
24	Pin, Hair	0031x4			

MODEL 465601x50B

REPAIR PARTS MOWER HOUSING



F-030734L

MODEL 465601x50B

REPAIR PARTS MOWER HOUSING


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Cover, Right Pulley	094607E701	44	Deflector, Chute	092100
2	Screw	26x250	45	Push On Cap	028x23
3	Screw	26x249	46	Spring, Torsion	166x34
4	Guide, Belt	091754 Z	47	Rod, Deflector	092159 Z
5	Cover, Left Pulley	094645E701	48	Bracket, Cover	092140E700
6	Nut, Hex	015x79	49	Spring, Extension	165x120
7	Nut, Flange	15x140	50	Bracket, Hinge	092104E701
8	Nut, Flange	015x84	51	Nut, Flange	015x88
9	Belt, Primary	037x89	52	Bracket, Bell Crank	094601E701
10	Pulley	094592	53	Crank, Bell	094603E701
11	Belt, Secondary	037x66	54	Plate, Brake Arm	094596E700
12	Pulley, Idler	690549	55	Bracket, Brake Plate	094602E701
13	Arm, Idler	094639E701	56	Bracket, Left Gauge Wheel	094919E700
14	Bolt, Shoulder	009x39	57	Axle	094025
15	Spacer, Pulley	1001197	58	Washer	017x91 Z
16	Pulley, Idler	690387	59	Ring, Locking	031x11
17	Bolt, Shoulder	009x52	60	Wheel, Gauge	092683
18	Knob	094068	61	Bracket, Right Gauge Wheel	094918E701
19	Washer	017x45 Z	62	Deflector, Inside	092103E701
20	Bolt, Shoulder	009x51	63	Bolt, Carriage	002x53
21	Bracket, Rear Suspension	094055E701	64	Pin, Cotter	030x49
22	Plate, Suspension	094128E700	65	Washer	017x57
23	Pad, Friction	094137	66	Bracket, Front Deck	094997SE
24	Spring	166x43	67	Rod, Hanger	094996
25	Link, Lift	690212E701	68	Stiffener	094604E700
26	Bracket, Left Lift	094600E700	69	Bracket, Suspension	690539E701
27	Pin, Hanger	095194	70	Adapter, Blade	690411
28	Pin, Hair	0031x4	72	Roller	1001252
29	Brake Assembly, Left	094640E700	73	Housing, Jackshaft * *	1001200
31	Spring	166x41	74	Blade	1001508E701
32	Pin, Cotter	030x20	75	Washer, Belleville	17x166
33	Brake Assembly, Right	094641E701	76	Nut	15x100
34	Washer	017x47 Z	77	Washer	17x165
35	Idler, Arm	690579E700	78	Bracket, Pulley Cover	690221E701
36	Washer	17x103	79	Spacer	690369
37	Link, Bell Crank	094606 Z	80	Washer	019x35
38	Guide, Belt	092116 Z	81	Rod, Hanger	094996
39	Screw	0025x7	82	Screw	26x277
40	Spring, Extension	165x79	84	Housing, Blade *	094936E701
41	Spring, Torsion	166x42	1-84	Complete Mower Housing Assy	7601031
42	Bracket, Suspension	094598E700	87	Guide, Belt	091797 Z
43	Nut	015x98	88	Screw	025x15

* Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.

* * Includes Key No. 15.

MODEL 465601x50B

REPAIR PARTS
ENGINE MOUNT ASSEMBLY



MODEL 465601x50B

REPAIR PARTS ENGINE MOUNT ASSEMBLY


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Cap, Fuel	1001279	29	Tube, Right Exhaust	690541
2	Tank, Fuel	690333	30	Tube, Left Exhaust	690542
6	Screw	26x263	31	Bracket, Muffler Mounting	690537
15	Line, Fuel (18 inches long) **	7601033	32	Muffler	093259
16	Clamp **	095197	33	Bracket, Muffler	690538
18	Pipe, Oil Drain	092279	34	Choke	690401
19	Cap, Oil Drain	021651	35	Nut	015x68
20	Bolt	0025x7	36	Screw	26x201
21	Spacer	093077	37	Control, Throttle	093165
22	Pulley, Stack	690507	38	Shield Assy., Heat -Twin	1001656-717
23	Washer	17x170	39	Rod, Pivot	093137 Z
24	Lockwasher	019x35	40	Pin, Hair	0031x4
25	Bolt	01x140	41	Brace, Grille	092541
26	Gasket	711851	42	Guard, Heal Shield	1001620-717
28	Bolt	06x103	43	Screw	26x277

* Parts are available from an Engine Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

** These parts are included with Key number 2.

MODEL 465601x50B

REPAIR PARTS ELECTRICAL SYSTEM



MODEL 465601x50B

**REPAIR PARTS
ELECTRICAL SYSTEM**

Key No.	Description	Part No.
1	Harness, Light Wire	250x92
	Socket, Light	092372
	Bulb, Light	090084
2	Harness, Chassis Wire	250x112
3	Switch, Ignition	092556
	Key, Ignition	020729
	Nut, Hex	091489
	Cap, Ignition	091488
4	Switch, Limit	1001575
5	Fuse	302031
	Holder, Fuse	407078
6	Solenoid	094613
	Screw, Mounting	26x229
	Locknut	15x116
7	Cable, Battery Ground	024x32
	Screw, Ground Cable	26x213
8	Battery	021075
	Bolt, Carriage	002x82
	Wingnut	014x79
	Boot, Battery –Positive	690604
9	Harness, Seat Switch Wire	250x67
10	Switch, Seat Sensor	094159
11	Cable	024x31