


MODEL 620301x61NB

REPAIR PARTS
ENGINE ASSEMBLY




342519E

Key No.	Part No.	Description
10	-----	ENGINE
11	180077	SCREW, 5/16-18 X.75
12	018x16	WASHER
14	71071	WASHER, FLAT
25	313440	GUIDE, BELT
28	710312	SCREW
33	339017	SPRING, IDLER BRAKE
40	1501013	ASSY, IDLER BRAKE ARM
41	333594	BOLT
42	71391	NUT, 5/16-18
45	48924	PULLEY, IDLER
46	45892	BOLT, CARRIAGE
47	590	NUT
70	338849	PULLEY, ENGINE
71	25840	WASHER, BELLEVELLE
72	181595	SCREW, 5/16-24X.75
73	018X16	WASHER, SPLTLK
75	37x132	BELT, V 3L 34.8"
--	F-031090C	OPERATOR'S MANUAL

MODEL 620301x61NB

REPAIR PARTS
FRAME COMPONENTS ASSEMBLY




342516

Key No.	Part No.	Description
80	760272E701	FRAME SIDE SUPPORT RH
81	760271E701	FRAME SIDE SUPPORT LH
90	760169	ROD, SUPPORT
91	71063	WASHER
92	71044	NUT, 3/8-16 HEX
100	578093E701	BRACKET, GAS TANK
101	302628	SCREW, 1/4-20X.75
102	15X143	NUT, 1/4-20
110	55381	TANK, FUEL
111	313681	SCREW, 1/4-14X.88
112	1257	CAP, GAS-RED
113	327290	TUBING 11.50 IN.
114	323387	CLAMP, FUEL LINE

MODEL 620301x61NB


REPAIR PARTS
TOP COVER ASSEMBLY



313937

MODEL 620301x61NB


REPAIR PARTS TOP COVER ASSEMBLY



Key No.	Part No.	Description
120	302265	COVER, BOTTOM
121	313674	SCREW, 1/4-20X1.25
122	71067	WASHER, FLAT .281X.63X.065
124	15X143	NUT, 1/4-20 YZ
126	326212	COVER, CARB
127	313685	SCREW, 1/4-14X.75
128	578109	NUT, 1/4-10 SPEED J TYPE
130	57587	GROMMET & WASHER, ROPE GUIDE
131	333643	KNOB, STAND TEE
140	56992	SWITCH, IGNITION
141	313683	WASHER
142	300193	NUT, 5/8-32 ACC
143	49643	2 KEYS & RING
145	54601	PRIMER, ENGINE
146	1259	HOSE, PRIMER
147	271172	KEPS NUT, 1/4-20
150	57036	COVER, BELT
151	12342	SCREW, 10-24X.50
152	312300	NUT, #10-24
153	313686	SCREW, 1/4-20X.50
154	71067	WASHER, FLAT .281X.63X.065
155	578107	NUT, 1/4-20 TINN
157	313685	SCREW, 1/4-14X.75
158	71067	WASHER, FLAT .281X.63X.065
159	578109	NUT, 1/4-20 SPEED J TYPE
170	1501038	COVER, TOP
171	313685	SCREW, 1/4-14X.75
172	71067	WASHER, FLAT .281X.63X.065
173	578109	NUT, 1/4-10 SPEED J TYPE
174	55379	SEAL, FOAM
175	55380	SEAL, STRIP CHUTE & GAS SEAL

MODEL 620301x61NB

REPAIR PARTS
AUGER HOUSING



342517


MODEL 620301x61NB

**REPAIR PARTS
AUGER HOUSING**

Key No.	Part No.	Description
480	330312	HOUSING, ASSY
481	302628	SCREW, 1/4-20X.75
482	71067	WASHER, FLAT .281X.63X.065
483	15X143	NUT, HEX 1/4-20 YZ
486	579052	SCREW, 1/4-20X.63
487	331126	BRACKET, STOP
488	331211	WASHER, FLAT .333X.87X.119
489	780029	NUT, 1/4-20 HEX NYLOCK
490	334031	BLADE, SCRAPER
491	577707	RIVET, OVSET
492	302628	SCREW, 1/4-20X.75
493	15X143	NUT, 1/4-20 YZ
510	577023	BEARING, FLANGE
511	710263	SCREW, 1/4-20X1.00
512	71067	WASHER, FLAT .281X.63X.065
513	15X143	NUT, 1/4-20 YZ
520	302783	AUGER, ASSY
520-2	302565	BLADE, AUGER
520-6	49838	RIVET
520-8	335992	BLADE, CENTER
520-10	302552E701	AUGER & BLADE SUPPORT
530	583459	BEARING & PLATE ASSY
531	334287	PLATE, RETAINER
532	579052	SCREW, 1/4-20X.63
533	71067	WASHER, FLAT .281X.63X.065
534	73826	NUT, 1/4-20
541	338965	PULLEY

MODEL 620301x61NB

REPAIR PARTS
DISCHARGE CHUTE




313939

Key No.	Part No.	Description
580	314239	RING, CHUTE
581	711752	SCREW, #10X.50
582	577021	GUIDE, CHUTE
590	334234	CHUTE, LOWER
591	313686	SCREW 1/4-20X.50
592	15X143	NUT, CNTRLK 1/4-2 YZ
600	325847	CHUTE, UPPER
601	308931	WIRE, HINGE
602	302843	BOLT, CARRIAGE 5/16-18X1.25
603	71071	WASHER, FLAT .349X.69X.066
604	57171	KNOB, T
605	71037	NUT, HEX 5/16-18
606	578088	SCREW, 5/16-18X.75
607	71071	WASHER, FLAT .349X.69X.066
608	71391	NUT, HEX 5/16-18

MODEL 620301x61NB


REPAIR PARTS
WHEELS



Key No.	Part No.	Description
650	313678	AXLE SHAFT
651	583409	WASHER, FLAT .391X1.00X1.25
660	760713	TIRE & RIM
661	583409	WASHER, FLAT .391X1.00X.125
662	577598	RING, RET E

MODEL 620301x61NB

REPAIR PARTS
HANDLE ASSEMBLY




342532

MODEL 620301x61NB


REPAIR PARTS HANDLE ASSEMBLY

Key No.	Part No.	Description
740	760774	CABLE, UPPER
741	313441	BRACKET, CABLE ADJ
742	760773	CABLE, LOWER CONTROL
743	308146	BOOT, CLUTCH SPRING
744	313471	SPRING, EXTENSION
750	313487E701	HANDLE, LOWER
751	313674	SCREW, 1/4-20X1.25
752	71067	WASHER, FLAT
753	15X143	NUT, 1/4-20 YZ
755	761486E701	BRACKET, CABLE
756	712234	BOLT
757	39298	PULLEY
759	15x143	NUT, 1/4-20
760	336453E701	UPPER HANDLE
761	313308E701	BAIL, CONTROL
762	337584	BOLT
763	311936	WASHER, FORM
764	57171	KNOB, T 3.00 WD
765	71037	NUT, 5/16-18



MODEL 620301x61NB

REPAIR PARTS
CHUTE ROD ASSEMBLY




313942

Key No.	Part No.	Description
850	314996	ROD, ASSY UPPER CHUTE CONTROL
851	71072	WASHER, FLAT .406X.81X.066
852	71082	PIN, COTTER
853	313431	WASHER, CURVED SPRING
855	71072	WASHER, FLAT .406X.81X.066
856	57082	KNOB, SLEEVE
857	331532	NUT, PUSH
860	313712	BOLT, EYE 3/8-16X2.00
861	148	GROMMET, EYE BOLT
863	71062	WASHER
864	71045	NUT, HEX JAM 3/8-16
870	333946E701	BRACKET, CHUTE ROTATE
871	340720	BOLT, CARRIAGE 5/16-18X.75
872	71071	WASHER, FLAT .349X.69X.066
873	71060	WASHER .328X.60X.09
874	71037	NUT, HEX 5/16-18

MODEL 620301x61NB


REPAIR PARTS CHUTE GUARD




Key No.	Part No.	Description
595	311206	GUARD, WIRE CHUTE
596	51776	SPRING, TORSION
597	51777	SPRING, TORSION
598	49106	NUT, ACORN

MUFFLER GUARD

Key No.	Part No.	Description
180	57139	GUARD, MUFFLER -EXPT
181	313685	SCREW
182	71067	WASHER, FLAT



CLEARING STICK



Key No.	Part No.	Description
766	304362	CLIP, RETAINER
767	414291	SCREW
768	997319	NUT
769	304361	STICK, CLEARING