


MODEL 620301x85NB

**REPAIR PARTS
ENGINE ASSEMBLY**




342519E

Key No.	Description	Part No.
10	ENGINE	
11	SCREW, 5/16-18 X.75	180077
12	WASHER, SPLTLK	018X16
14	WASHER, FLAT	71071
25	GUIDE, BELT	313440
28	SCREW	710312
33	SPRING, IDLER BRAKE	339017
40	ASSY, IDLER BRAKE ARM	1501013
41	BOLT	333594
42	NUT, 5/16-18	71391
45	PULLEY, IDLER	48924
46	BOLT, CARRIAGE	45892
47	NUT	590
70	PULLEY, ENGINE	338849
71	WASHER, BELLEVELLE	25840
72	SCREW, 5/16-24X.75	181595
73	WASHER, SPLTLK	018X16
75	BELT, V 3L 34.8"	760928
—	INSTRUCTION MONUAL	F-031048C
—	PARTS MANUAL	F-031077C

MODEL 620301x85NB

**REPAIR PARTS
FRAME COMPONENTS ASSEMBLY**




342516

Key No.	Description	Part No.
80	FRAME SIDE SUPPORT RH	760272E701
81	FRAME SIDE SUPPORT LH	760271E701
90	ROD, SUPPORT	760169
91	WASHER, HVSP TLK	71063
92	NUT, 3/8-16 REG HEX	71044
100	BRACKET, GAS TANK	578093E701
101	SCREW, 1/4-20X.75	302628
102	NUT, 1/4-20 REG HEX CTRLK YZ	782585
110	TANK, FUEL	55381
111	SCREW, 1/4-14X.88 WAHHTAP	313681
112	CAP, GAS-BLACK	315433
113	TUBING 11.50 IN.	327290
114	CLAMP, FUEL LINE	48672

MODEL 620301x85NB


REPAIR PARTS
TOP COVER ASSEMBLY



313937

MODEL 620301x85NB


REPAIR PARTS TOP COVER ASSEMBLY



KEY NO.	DESCRIPTION	PART NO.
120	COVER, BOTTOM	302265
121	SCREW, 1/4-20X1.25	313674
122	WASHER, FLAT .281X.63X.065	71067
124	NUT, 1/4-20 YZ	782585
126	COVER, CARB	326212
127	SCREW, 1/4-14X.75	313685
128	NUT, 1/4-10 SPEED J TYPE	578109
130	GROMMET & WASHER, ROPE GUIDE	57587
131	KNOB, STAND TEE	333643
140	SWITCH, IGNITION	56992
141	WASHER	313683
142	NUT, 5/8-32 ACC	300193
143	2 KEYS & RING	49643
145	PRIMER, ENGINE	54601
146	HOSE, PRIMER	1259
147	KEPS NUT, 1/4-20	271172
150	COVER, BELT	57036
151	SCREW, 10-24X.50	12342
152	NUT, #10-24	312300
153	SCREW, 1/4-20X.50	313686
154	WASHER, FLAT .281X.63X.065	71067
155	NUT, 1/4-20 TINN	578107
157	SCREW, 1/4-14X.75	313685
158	WASHER, FLAT .281X.63X.065	71067
159	NUT, 1/4-20 SPEED J TYPE	578109
170	COVER, TOP	337099
171	SCREW, 1/4-14X.75	313685
172	WASHER, FLAT .281X.63X.065	71067
173	NUT, 1/4-10 SPEED J TYPE	578109
174	SEAL, FOAM	55379
175	SEAL, STRIP CHUTE & GAS SEAL	55380

MODEL 620301x85NB

REPAIR PARTS
AUGER HOUSING



342517


MODEL 620301x85NB

**REPAIR PARTS
AUGER HOUSING**

KEY NO.	DESCRIPTION	PART NO.
480	HOUSING, ASSY	330312
481	SCREW, 1/4-20X.75	302628
482	WASHER, FLAT .281X.63X.065	71067
483	NUT, HEX 1/4-20 YZ	782585
486	SCREW, 1/4-20X.63	579052
487	BRACKET, STOP	331126
488	WASHER, FLAT .333X.87X.119	331211
489	NUT, 1/4-20 HEX NYLOCK	780029
490	BLADE, SCRAPER	334031
491	RIVET, OVSET	577707
492	SCREW, 1/4-20X.75	302628
493	NUT, 1/4-20 YZ	782585
510	BEARING, FLANGE	577023
511	SCREW, 1/4-20X1.00	710263
512	WASHER, FLAT .281X.63X.065	71067
513	NUT, 1/4-20	302635
520	AUGER, ASSY	302783
520-2	BLADE, AUGER	302565
520-6	RIVET	49838
520-8	BLADE, CENTER	335992
520-10	AUGER & BLADE SUPPORT	302552E701
530	BEARING & PLATE ASSY	583459
531	PLATE, RETAINER	334287
532	SCREW, 1/4-20X.63	579052
533	WASHER, FLAT .281X.63X.065	71067
534	NUT, 1/4-20	73826
541	PULLEY	338965

MODEL 620301x85NB


**REPAIR PARTS
DISCHARGE CHUTE ASSEMBLY**



Key No.	Description	Part No.
580	RING, CHUTE	314239
581	SCREW, 1/4-20 x .50	711752
582	GUIDE, CHUTE	577021
590	LOWER CHUTE	305862
591	SCREW, 1/4-20 x .50	313686
592	NUT, 1/4-20	782585
600	UPPER CHUTE W/HANDLE	305861
601	WIRE HINGE	310562
602	BOLT, 5/16-18 x 1.25	302843
603	FLATWASHER	71071
604	T KNOB	57171
605	NUT, 5/16-18	71037
606	SCREW, 5/16-18 x .756	578088
607	FLATWASHER	71071
608	NUT, 5/16-18	71391

MODEL 620301x85NB


REPAIR PARTS
WHEELS



Key No.	Description	Part No.
650	AXLE SHAFT	313678
651	WASHER, FLAT .391X1.00X1.25	583409
660	TIRE & RIM	760713
661	WASHER, FLAT .391X1.00X.125	583409
662	RING, RET E	577598

MODEL 620301x85NB

REPAIR PARTS
HANDLE ASSEMBLY




MODEL 620301x85NB

REPAIR PARTS HANDLE ASSEMBLY

Key No.	Description	Part No.
740	CABLE, UPPER	760774
741	BRACKET, CABLE ADJ	313441
742	CABLE, LOWER CONTROL	760773
743	BOOT, CLUTCH SPRING	308146
744	SPRING, EXTENSION	313471
750	HANDLE, LOWER	313487E701
751	SCREW, 1/4-20X1.25	313674
752	WASHER, FLAT	71067
753	NUT, 1/4-20	73826
755	BRACKET, CABLE	761486E701
756	BOLT	712234
757	PULLEY	39298
759	NUT, 1/4-20 YZ	782585
760	UPPER HANDLE	313489E701
761	BAIL, CONTROL	313308E701
762	BOLT	337584
763	WASHER, FORM	311936
764	KNOB, T 3.00 WD	57171
765	NUT, 5/16-18	71037

MODEL 620301x85NB

**REPAIR PARTS
CHUTE ROD ASSEMBLY**




313942

Key No.	Description	Part No.
850	ROD, ASSY UPPER CHUTE CONTROL	314996
851	WASHER, FLAT .406X.81X.066	71072
852	PIN, COTTER	71082
853	WASHER, CURVED SPRING	313431
855	WASHER, FLAT .406X.81X.066	71072
856	KNOB, SLEEVE	57082
857	NUT, PUSH	331532
860	BOLT, EYE 3/8-16X2.00	313712
861	GROMMET, EYE BOLT	148
863	WASHER	71062
864	NUT, HEX JAM 3/8-16	71045
870	BRACKET, CHUTE ROTATE	333946E701
871	BOLT, CARRIAGE 5/16-18X.75	340720
872	WASHER, FLAT .349X.69X.066	71071
873	WASHER .328X.60X.09	71060
874	NUT, HEX 5/16-18	71037

MODEL 620301x85NB

REPAIR PARTS


CHUTE GUARD



Key No.	Description	Part No.
595	GUARD, WIRE CHUTE	311206
596	SPRING, TORSION	51776
597	SPRING, TORSION	51777
598	NUT, ACORN	49106


MUFFLER GUARD

Key No.	Description	Part No.
180	GUARD, MUFFLER -EXPT	57139
181	SCREW	579052
182	WASHER, FLAT	71067
183	NUT, 1/4-20 TINN	578107



MODEL 620301x85NB

REPAIR PARTS



PART NO.	DESCRIPTION
314810	DECAL, OFF-CHOKE-ON
314808	DECAL, CONTROL PANEL
337524	DECAL, AUGER CONTROL BAR
48X321	DECAL, SNOWSTAR – STIGA
300275	DECAL, DANGER –READ
586393	DECAL, MUFFLER HOT
48X381	DECAL, EPA 3HP, MASS
337610	DECAL, DANGER CHUTE –HAND
337611	DECAL, DANGER AUGER –FOOT