


# 22605x50G

## HOUSING ASSEMBLY




## 22605x50G HOUSING ASSEMBLY

1	Engine *	————	38	Spring	166x45
2	Housing	776023	39	Spacer	071789
3	Height Adjuster, Left Rear	672641	40	Arm, Pivot	1101121 Z
4	Knob	071495	41	Spacer	071788
5	Wheel and Tire, Rear	071132	42	Pulley, Idler	071779
6	Locknut, Flange	015x84	43	Bolt, Shoulder	009x50
7	Bolt, Carriage	002x81	44	Belt, Briggs	37x100
9	Bolt, Engine	025x11	45	Washer	17x186
10	Nut	015x68	46	Ring, Retainer	011x16
11	Height Adjuster, Left Front	672643	47	Gear, Pinion	071792
12	Washer, Belleville	17x137	48	Pulley	071791
13	Washer	17x124	49	Pin, Drive	043629
14	Bolt, Hex	01x153	50	Pin, Hair	0031x9
15	Blade	1101120E701	51	Axle	672508
16	Adapter, Blade	672503	52	Washer	17x169
17	Height, Adjuster, Right Frt.	672642	53	Cover, Dust	071780
18	Height, Adjuster, Right Rr.	672640	54	Bolt	001x85
19	Guard, Rear	672738	55	Hub Cap	672122
20	Screw	26x245	56	Plate, Mulch	672422 Z
21	Deflector, Chute	672421	57	Bracket, Left Handle	1101303E245
22	Push-On Cap	028x42	58	Bracket, Right Handle	1101302E245
23	Pin, Pivot	215x11 Z	59	Screw	26x289
24	Spring	0166x5	64	Screw	26x245
25	Baffle	672744E701	65	Shield, Debris	1101026E701
26	Wheel and Tire, Drive	071133	68	Bolt, Carriage	002x86
27	Pulley	071434	69	Bolt	001x81
28	Pin, Spring	032x64	—	Book, Instruction	F-030449L
29	Base, Engine	672671			
30	Cover, Belt (Black)	1101025			
31	Screw	26x279			
32	Bracket, Idler Support	1101240 Z			
33	Washer	17x203			
34	Screw	26x217			
35	Idler, Backside	071778			
36	Locknut	015x43			
37	Bearing	071793			

# 22605x50G

## HANDLE ASSEMBLY



1	Handle, Upper (Black)	1101556E724	9	Bracket, Stop Lever	1101454
2	Handle, Lower (Black)	071137E724	11	Fastener, Cable	1101353
3	Bolt	025x14	12	Bolt	002x77
4	Control, Drive	672877	13	Knob	071294
5	Locknut	15x116	16	Guide, Rope	071530
6	Cable, Stop	1101182			
8	Lever, Stop	672879E701			