


BHC-6160



BHC-6160

KEY NO.	PART NO.	DESCRIPTION	Q'TY	OUR PART NO.
1	328145600	COVER SLEEVE	1	10427
2	328145100	BLADE COVER	1	10428
3	311030200	CLAMPING COLLAR	1	10429
4	311030300	GUARD CLAMP(B)	1	10430
5	065063000	TORX BOLT M6X30	2	10431
6	035630102C	BALL BEARING #6301ZZ	1	10432
7	328130400	WORM	1	10433
8	312910500	PLUG	1	10434
9	035600102C	BALL BEARING #6001ZZ	1	10435
10	065051000	TORX BOLT M5X10	1	10436
11	090181000	PLUG	1	10437
12	329830200	WORM CASE (B)	1	10438
13	039173007	OIL SEAL	2	10439
14	035600302C	BALL BEARING #6003ZZ	2	10440
15	329830600	SHAFT	1	10441
16	329830500	WHEEL	1	10442
17	328133000	CASE SLEEVE	1	10443
18	065061800	TORX BOLT M6X18	2	10444
19	028516263	CT BOLT M5X16	6	10445
20	329830100	WORM CASE	1	10446
21	031160002	PLAIN WASHER	2	10447
22	329820100	HUB	2	10448
23	329820300	PIN	2	10449
24	031080001	PLAIN WASHER 8 (SMALL)	2	10450
25	051081600	R PIN	2	10451
26	311020200	ROTOR	2	10452
27	065061200	TORX BOLT M6X12	6	10453
28	060000700	WRENCH, TORX	1	10454
29	060050000	ALLEN WRENCH 5MM	1	10455