



Westwood



Tractor Chassis, PTO, Brake & Cutter Controls

ITEM	PART NO.	DESCRIPTION	QTY
1	2648	Knob, 3/8"	3
2	7383	Plunger Brake	1
3	1233	Split Pin, 1/8" x 3/8" Steel	3
4	2003	Spring Park Brake	1
5	6817	Swivel Adjuster Rod	1
6	7107	Rod Adjustable	2
7	8418	Spacer, PTO Jockey	1
8	RCL074-0845	Bolt	4
9	8310	Plate PTO Jockey Pulley	1
10	2594	Spring	1
11	9488	Jockey Pulley	6
12	7726	Belt, PTO (A 84 1/2)	1
13	6400	Lever, Engage	1
14	1319	Bolt	2
15	6812	Bush, Jockey Plate	1
16	8538	Lever, PTO Engage	1
17	3683	Spacer	3
18	7285	Bolt	1
19	1613	Spring	2
20	RCL564019-001	Engage Rod (long)	1
21	1695	Swivel Engage Rod	1
22	9093	Transfer Link	1
23	1054	Bolt	1
24	8814	Engage Rod	1
25	4086	"R" Clip, Small	8
26	2103	Clutch Spring	2
27	8817	Swivel	1
28	8676	Brake Rod	1
29	8912	Foot Pedal Rubber	1
30	8218	Foot Pedal	1
31	MX951	Grommet (S1300-S1600 only)	1
32	RCL 812000-00	Key, 3/8" Square x 2"	2
33	4152	Grommet, Open Chassis	3
34	RCL584033-00	Chassis	1
35	2356	Plate Brake Extension	1
36	1270	Nut	1
37	1331	Washer	1
38	1156	Setscrew	1

ITEM	PART NO.	DESCRIPTION	QTY
39	8726	TX Support Bkt., Rear RH	1
40	7301	Pulley 5", Deep Form	1
41	8681	TX Support Bkt., RH Front	1
42	8727	TX Support Bkt., Rear LH	2
43	8680	TX Support Bkt., LH Front	1
44	8350	Gearbox Hydro (Sundstrand)	1
45	6905	Support Bkt. Grass Def. Rear	2
46	1978	Bolt	4
47	3323	Galv. Support Bkts	2
48	8732	Flap Rubber	1
49	RCL023-08114	Bolt	3
50	1735	Screw	3
51	1053	Nut	3
52	9291	Support Bracket	1
53	4949	Grass Deflector	1
54	8682	Grass Deflector Support Bkt., LH Front	1
55	5735	Belt Guide	5
56	1067	Washer	4
57	3613	Washer	8
58	7239	Belt, Transmission A81	1
59	RCL564030-00	Belt Guide Plate Assembly	1
60	8452	Eng. Blk (1000 Series)	1
61	6536	Washer	1
62	027-11114	Bolt	1
63	1558	Pulley, 7"	1
64	2139	Brake Cable Retaining Pin	1
65	7542	Safety Guard	1
66	RCL061-08	Nut	4
67	3397	Spacer	1
68	7541	Post Safety Guard	1
69	RCL584191-00	Belt Guide Pin	1
70	1331	Washer	4
71	1156	Setscrew	2
72	8284	Guard Plate	1
73	RCL090-08	Nut	11
74	8236	Jockey Plate	1
75	4309	Nut	2
76	7662	Eng. Block (Upper)	1

ITEM	PART NO.	DESCRIPTION	QTY
77	RCL030-0825	Setscrew	2
78	1321	Bolt	1
79	1324	Nut	14
80	9572	Spacer	1
81	RCL084-08	Nut	2
82	9573	Stop	1
83	RCL029-0840	Bolt	1
84	RCL011-1001	Washer	1
85	RCL564081-00	Adaptor Plate	1
86	1602	Key, 1/2" SQ x 1" Engine Block	1
87	8340	Spacer	1
88	RCL016-1601	Washer	2
89	9569	Pulley & Shaft Assembly PTO Drive	1
90	6662	Belt Guide Pin	3
91	2045	Washer	6
92	3229	Bearing	2
93	1982	Setscrew	10
94	9567	PTO Bearing Housing	1
95	8337	Pulley Assembly 5"	1
96	017-0802	Washer	1
97	RCL048-0820	Set Bolt	1
98	MX1285	Key, 6mm SQ x 15mm long	1
99	1105	Washer	41
100	9571	Spacer	1
101	1200	Bolt	1
102	8232	Plate Jockey Pulley	1
103	1969	Nut	1
104	1323	Washer	28
105	7418	Bolt	1
106	1273	Nut	23
107	2847	Washer	2
108	3463	Spring	1
109	3414	Switch, Brake & Cutter Dk. Safety	2
110	6393	Bracket Safety Sw. (Short) (Cutter Deck)	1
111	6394	Bracket Safety Sw. (Long) (Brake)	1
112	8220	Shouldered Spacer (Jockey Pulley)	4
113	2592	Chain	Links as req.
114	5822	Pulley	1

A L L Y E A R R O U N D P E R F O R M A N C E