




Westwood



Tractor Chassis, PTO, Brake & Cutter Controls

ITEM	PART NO.	DESCRIPTION	QTY
1	2648	Knob, 3/8"	3
2	7383	Plunger Brake	1
3	1233	Steel Split Pin, 1/8" x 3/8"	3
4	2003	Spring Park Brake	1
5	6817	Swivel Adjuster Rod	1
6	7107	Rod Adjustable	1
7	8418	Spacer, PTO Jockey	1
8	RCL074-0845	Bolt	4
9	8310	Plate PTO Jockey Pulley	1
10	2594	Spring	1
11	9488	Jockey Pulley	5
12	7726	Belt, PTO (A 84 1/2)	1
13	6400	Lever, Engage	1
14	1319	Bolt	2
15	6812	Bush, Jockey Plate	1
16	8538	Lever, PTO Engage	1
17	3683	Spacer	4
18	7285	Bolt	1
19	1613	Spring	2
20	RCL564019-00	Engage Rod (long)	1
21	1695	Swivel Engage Rod	1
22	9093	Transfer Link	1
23	1054	Bolt	1
24	8814	Engage Rod	1
25	4086	"R" Clip, Small	8
26	2103	Clutch Spring	2
27	1694	Swivel	1
28	8515	Brake Rod	1
29	8912	Foot Pedal Rubber	1
30	8218	Foot Pedal	1
31	MX951	Grommet (\$1300-\$1600 only)	1
32	RCL 812000-00	Key, 3/8" Square x 2"	2
33	4152	Grommet Open Chassis	3
34	RCL564033-00	Chassis	1
35	2356	Plate Brake Extension	1
36	1270	Nut	1
37	1331	Washer	1
38	1156	Setscrew	1
39	1996	Circlip External 3/8" Dia.	1
40	8295	Pulley Transaxle	1
41	2831	TX Support Bkt., Right Hand Front	1
42	RCL584061-00	TX Support Bkt., Rear	2

ITEM	PART NO.	DESCRIPTION	QTY
43	9475	TX Support Bkt., Left Hand Front	1
44	9478	Transaxle 200 Series 6 Speed	1
45	8393	Support Bkt. Grass Def. Rear	2
46	1978	Bolt	4
47	3323	Galv. Support Bkts	2
48	3324	Flap Rubber (Std. Tractors)	1
49	7286	Screw	2
50	1735	Screw	3
51	1053	Nut	3
52	9474	Support Bkt. Grass Deflector front	1
53	4949	Grass Deflector	1
54	1104	Key, 3/8" x 3/8"	1
55	5735	Belt Guide	5
56	1067	Washer	4
57	3613	Washer	8
58	1688	Belt Transmission	1
59	RCL564029-00	Belt Guide Plate Assembly	1
60	6796	Eng. Blk	1
61	6536	Washer	1
62	027-11114	Bolt	1
63	1558	Pulley 7"	1
64	2139	Brake Cable Retaining Pin	1
65	7542	Safety Guard	1
66	RCL061-08	Nut	2
67	9304	Hanger Bkt., Front	1
68	7541	Post Safety Guard	1
69	RCL584191-00	Belt Guide Pin	1
70	1331	Washer	4
71	1156	Setscrew	2
72	RCL584099-00	Guard Plate	1
73	RCL090-08	Nut	9
74	8236	Jockey Plate	1
75	4309	Nut	2
76	7684	Spacer	1
77	RCL030-0825	Setscrew	2
78	9302	Hanger Bkt., Left Hand Rear	1
*	9303	Hanger Bkt., Right Hand Rear	1
79	1324	Nut	10
80	8915	Lifting Link	4
81	6213	Setscrew	4
82	RCL017-1003	Washer	30
83	RCL048-1035	Setscrew	8

ITEM	PART NO.	DESCRIPTION	QTY
84	RCL090-10	Nut	16
85	RCL061-10	Nut	8
86	5850	Setscrew	4
87	8340	Spacer	1
88	RCL016-1601	Washer	3
89	9569	PTO Pulley Assembly	1
90	RCL029-0840	Bolt	1
91	2045	Washer	6
92	3229	Bearing	2
93	1982	Setscrew	12
94	9567	PTO Mounting Plate	1
95	8337	Pulley Assembly, 5"	1
96	017-0802	Washer	1
97	RCL048-0820	Bolt	1
98	MX1285	Key, 6mm SQ x 15mm long	1
99	1105	Washer	34
100	1321	Spacer	1
101	1200	Bolt	1
102	8232	Plate Jockey Pulley	1
103	1969	Nut	1
104	1323	Washer	20
105	7418	Bolt	1
106	1273	Nut	16
107	2847	Washer	2
108	3463	Spring	1
109	3414	Switch Brake & Cutter Dk. Safety	2
110	6393	Bracket Safety Sw. (Short) (Cutter Deck)	1
111	6394	Bracket Safety Sw. (Long) (Brake)	1
112	8220	Shouldered Spacer (Jockey Pulley)	4
113	2592	Chain	Links as req.
114	1602	Key, 1/2" SQ x 1" Engine Block	1
115	9573	Stop	1
116	1321	Bolt	1
117	9572	Spacer	1
118	RCL084-08	Nut	1
119	RCL090-0808	Nut	4
120	RCL048-0820	Setscrew	4
121	RCL564081-00	Adaptor Plate (Manual)	1
122	5822	Jockey pulley	1
123	1422	Nut	1
124	RCL013-1001	Washer	8

* Not Shown

A L L Y E A R R O U N D P E R F O R M A N C E