



Westwood



Steering, Gear Change and Electrical Controls

ITEM	PART NO.	DESCRIPTION	QTY
1	8841	Light Battery Charge	1
2	8161	Switch, Cutter Engage (with symbols)	1
3	8160	Switch, Headlights (with symbols)	1
4	2703	Switch, Ignition	1
5	7496	Int. Teethsp. Washer	1
6	6523	Ignition Washer	1
7	2065	Ignition Locknut	1
8	5600	Bezel	1
9	9565	Headlight Harness	1
10	8063	Loom	1
11	8557	Loom Adaptor	1
12	8062	P.C.B. Assembly	1
13	9297	Terminal Cover (Red)	1
14	8233	Battery Connection (Positive)	1
15	RCL472000-00	Terminal Cover (Black)	1
16	8234	Battery Connection (Negative)	1
17	8176	Fuse Holder	1
18	1530	Solenoid	1
19	8906	Bkt. Solenoid & Fuse Holder	1
20	9489	Seat Switch (Spares only) Supplied with seats	1
21	7631	Earth Cable	1
22	3559	Choke Control	1
23	8569	Throttle Control, Assy & Cable	1
24	MX1286	Cable Tie	3
25	RCL794000-00	Cable Tie (Re-usable)	2
26	4972	Label, Sound Power Level (100dB)	1
27	RCL766173-00	Label, Powered by Briggs	1
28	7918	Label, To Drive (Manual)	1
29	7917	Label, To Start (Manual)	1
30	*	Decal - Serial No. (Not Replaceable)	1
31	RCL766137-00	Label, P.G.C. Lower / Raise	1
32	3453	Label, Union Jack	2
33	RCL766134-00	Label, Disengage / Engage	1
34	RCL089-1012	Nut	1
35	RCL766138-00	Label, Parking Brake	1
36	RCL766179-00	Label, Small Caution	3
37	5485	Steering Rod	1
38	6487	Ball Joint, Right Hand	2
39	9380	Ransomes Badge	2
40	9379	Steering Wheel Cap	1
41	1982	Setscrew	3
42	RCL083-0802	Washer	3

ITEM	PART NO.	DESCRIPTION	QTY
43	3613	Washer	2
44	4124	Washer	1
45	9378	Steering Wheel	1
46	9426	Gaiter	1
47	1104	Woodruff Key, 5/16" x 3/8"	2
48	2589	"E" Clip No.1500-62	6
49	1975	Washer	3
50	3539	Bush, Steering Column	3
51	2276	Steering Gear	1
52	1699	Steering Foot	1
53	3403	Steering Quadrant	1
54	3401	Bridge Steering Quadrant	1
55	9377	Steering Column	1
56	3091	Cup Washer (White Plastic)	2
57	3092	Screw Cover (Black Plastic)	2
58	4930	Steering Arm	1
59	1098	Woodruff Key, 5/16" x 1"	1
60	1663	"E" Clip (AM 1500-75)	2
61	RCL030-1065	Bolt	1
62	1323	Washer	28
63	1324	Nut	1
64	8919	Console Assy	1
65	3960	Fuel Tank	1
66	3940	Snapper Hoseclip No.6	4
67	3859	Pipe Fuel Supply (Length as required)	1
68	7331	Fuel Cock	1
69	RCL564033-00	Chassis	1
70	RCL584074-00	Stub Axle, Left Hand	1
71	9004	Convuluted Tubing	As req.
72	9458	Battery Location Plate	1
73	RCL314000-00	Axle Beam (Casting)	1
74	3712/3713	Washer	As req.
75	4086	"R" Clip, Small	1
76	3792	Locknut	6
77	6083	Handgrip	1
78	7760	Bolt	1
79	1156	Setscrew	4
80	3613	Washer	10
81	1423	Grease Nipple	1
82	1273	Nut	19
83	9363	CTR. Body Assembly	1
84	8215	Mounting Frame	1

ITEM	PART NO.	DESCRIPTION	QTY
85	2246	Tow Hitch	1
86	3146	Spacer	4
87	8285	Lifting Shaft	1
88	7851	Rectangular Sleeve	1
89	1948	Setscrew	6
90	7715	Lifting Arm	2
91	014-1301	Washer	2
92	7763	Knob	1
93	1734	Screw	2
94	1053	Nut	2
95	7764	Screw	1
96	7765	Nut	1
97	3963	Cap Fuel Tank	1
98	013-0601	Washer	4
99	1318	Bolt	4
100	2351	Engine Spacer	4
101	2031	Setscrew	3
102	2048	Washer	2
103	1331	Washer	10
104	1270	Nut	2
105	1969	Locknut	3
106	9376	Pivot Bracket	2
107	8280	Lifting Lever	1
108	2015	Setscrew	2
109	8177	Fuse 1 amp	1
110	8178	Fuse 10 amp	1
111	6789	Fuse 20 amp	2
112	2649	Knob, 1/2"	1
113	9372	Gear Lever	1
114	6662	Belt Guide Pin	1
115	RCL090-08	Nut	2
116	1105	Washer	2
117	RCL013-1001	Washer	1
118	6624	Lever Cranked (5 Speed)	1
119	6487	Ball Joint, Right Hand	2
120	9392	Gear Change Rod, 3/8" UNF Stud	1
121	4242	Washer, TX Gearchange	1
122	9373	Gear Lever Assembly	1
123	3541	Bush, Medium Nylon 1/2" x 3/8"	2

A L L Y E A R R O U N D P E R F O R M A N C E