



**ZENOAH  
KOMATSU**

# SERVICE PARTS LIST

EFFECTIVE: Sept. 2002

**CHAINSAW**

# G3200

SERIAL NUMBERS APPLICABLE:

065242001 and up

CONTENTS:

Fig. 1 POWER UNIT

Fig. 2 CARBURETOR COMPONENTS & ACCESSORIES

Fig. 1 POWER UNIT






Fig. 1 POWER UNIT

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	T2050-06050	SHORT BLOCK ASSY	1		54	3310-33262	• SPRING	1		107	2873-71100	ROTOR ASSY	1	
2	T2050-12110	• CYLINDER	1		55	3310-33271	• KNOB	1		108	2873-71120	• PAWL	2	
3	T2050-21110	• CRANKCASE	1		56	2873-33311	THROTTLE LEVER	1		109	2873-71130	• SPRING	2	
4	01252-30530	• BOLT	4		57	3356-33321	SPRING	1		110	2873-71140	• PIN	2	
5	2870-41111	• PISTON	1		58	04025-00524	PIN	1		111	2634-71110	MODULE	1	
6	3319-41210	• RING	1		59	3356-33352	ARM	1		112	5500-72110	CAP	1	
7	3304-41310	• PIN	1		60	T2050-33410	COVER GRIP	1		113	1900-72120	SPRING	1	
8	3310-41320	• SNAP RING	2		61	2630-31950	SCREW	1		114	T1512-71320	TUBE	1	
9	3310-41410	• BEARING	1		62	2630-33511	JOINT(B)(HARD)	1		115	2634-06711	SWITCH SET	1	
10	1650-41510	• WASHER	2		63	2873-33520	JOINT(C)(SOFT)	2		116	2634-71120	• CORD EARTH	1	
11	2870-42002	• CRANKSHAFT COMP	1		64	2640-33530	BOLT	3		117	2630-72610	• WIRE SWITCH	1	
12	06030-06201	• BEARING	2		65	2630-33610	SCREW	6		118	5500-72150	SPACER	2	
13	2630-43150	• OIL SEAL	1		66	2873-43230	NUT	1		119	3310-72150	BOLT	2	
14	04065-03212	• SNAP RING	1		67	2873-43240	WASHER	1		120	1216-73110	SPARK PLUG	1	
15	2169-21210	• OIL SEAL	1		68	2873-43250	WASHER	1		121	T2050-75000	STARTER ASSY	1	
16	T2050-15100	MUFFLER ASSY	1		69	2872-51111	CLUTCH DRUM	1		122	T2050-75100	• CASE COMP	1	
17	2630-15211	GASKET	1		70	2873-51310	BEARING	1		123	3330-75121	•• GUIDE	1	
18	3330-15220	BOLT	2		71	2870-51200	CLUTCH ASSY	1		124	2873-75210	• REEL	1	
19	2870-22102	VALVE ASSY	1		72	2873-98610	• PLATE	1		125	2873-75150	• ROPE	1	
20	2870-22211	GASKET	1		73	2870-51230	• SPRING	1		126	T2050-75420	• KNOB	1	
21	3330-14121	GASKET	1		74	T2050-54000	CHAINBRAKE ASSY	1		127	2873-75220	• SPRING	1	
22	2873-31100	ENGINE CASE COMP	1		75	T2050-54110	• GUARD	1		128	2873-75410	• WASHER	1	
23	2870-31510	VALVE	1		76	2872-54120	• SPRING	1		129	2873-75510	• SCREW	1	
24	T2052-31200	FUEL PIPE ASSY	1		77	00263-80530	• SCREW	1		130	2873-75610	• COVER FAN	1	
25	1492-85410	• PIPE	1		78	2872-54140	• SPACER	1		131	2630-33610	• SCREW	1	
26	1850-85300	• FILTER ASSY	1		79	2850-54211	• SPACER	1		132	2630-31950	SCREW	4	
27	1260-85460	• CLIP	2		80	2872-54220	• WEIGHT	1		133	T2052-75130	LABEL	1	
28	3350-34320	• ELBOW	1		81	2872-54230	• SPRING	1		134	T2052-81000	CARBURETOR ASSY	1	
29	T2052-31250	• GROMMET	1		82	2851-54270	• SPRING	1		135	3310-82110	WASHER	1	
30	3317-86100	BREATHER ASSY	1		83	01641-20510	• WASHER	1		136	2630-82121	CHOKE PLATE	1	
31	2873-31300	OIL PIPE ASSY	1		84	3310-53331	• NUT(B)	1		137	2630-82140	SCREW	2	
32	2630-31321	• GROMMET	1		85	2851-54301	• LEVER COMP	1		138	2873-82151	THROTTLE ROD	1	
33	2873-31330	• JOINT	1		86	2851-54350	• PIN	1		139	2630-82160	GROMMET	1	
34	2630-31350	• FILTER	1		87	2670-54411	• ARM	1		140	2630-82210	GROMMET(A)	1	
35	1492-85410	• PIPE	1		88	2872-54510	• BAND	1		141	2630-82220	GROMMET(B)	1	
36	1492-85410	PIPE	1		89	3356-24140	• PIN	1		142	2630-82311	CHOKE ROD	1	
37	3370-31210	PIN	1		90	2670-54610	• SPRING BRAKE	1		143	3320-33310	GROMMET	1	
38	2630-31510	VALVE ASSY	1		91	2872-54623	• COVER SPRING	1						
39	2870-22251	SEAL	1		92	2630-33610	• SCREW	3		145	2630-98500	COVER ASSY	1	
40	2630-31650	CAP	1		93	T2052-53120	LABEL	1		146	2630-83120	• KNOB	1	
41	2870-31750	SCREW M5x16	4		94	3350-53410	NUT	1		147	00308-00040	• SNAP RING	1	
42	2841-31800	CAP ASSY	2		95	2870-53310	PLATE(A)	1		148	2630-83511	CLEANER	1	
43	2630-31820	• GASKET	2		96	2630-53330	SCREW	1		149	2870-83610	ELEMENT	1	
44	2630-31913	COVER FRONT	1		97	2873-53320	NUT(A)	1		150	T2052-31410	LABEL	1	
45	2630-31950	SCREW	2		98	2630-53412	CATCHER	1		151	T2052-31420	LABEL(CE)	1	
46	2873-32100	FRONT HANDLE ASSY	1		99	2630-32170	SCREW	1		152	T2052-31260	PIPE	1	
47	2630-32121	• JOINT(A)	1		100	2630-55102	OIL PUMP ASSY	1		153	2841-37150	JOINT	1	
48	2630-32151	• STOPPER	1		101	2630-55160	• GEAR WORM	1		154	2850-81900	PUMP	1	
49	2630-32170	• SCREW	1		102	00261-00416	SCREW	2		155	T2052-82510	PIPE	1	
50	2630-32170	SCREW	1		103	2630-55211	PLATE WORM	1		156	T2990-21080	LABEL	1	
51	2630-32610	SCREW	2		104	2630-55251	SEAL	1						
52	T2050-33100	REAR HANDLE COMP	1		105	2630-55312	COVER PUMP	1						
53	3330-33250	• STOPPER	1		106	2630-31950	SCREW	2						

**Fig. 2 CARBURETOR COMPONENTS & ACCESSORIES**



Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	T2052-81000	CARBURETOR ASSY	1	
2	3306-81380	• SCREEN	1	
3	T2052-81120	• PUMP COVER	1	
4	3310-81130	• SCREW	1	
5	1491-81160	• SPRING	1	
6	2630-81170	• IDLE NEEDLE	1	
7	3310-81230	• METERING LEVER	1	
8	3310-81240	• SCREW	1	
9	3310-81250	• PIN	1	
10	3310-81280	• COVER	1	
11	2841-81270	• SPRING	1	
12	3356-81310	• NEEDLE VALVE	1	
13	2630-81330	• SCREW	1	
14	3350-81380	• SPRING	1	
15	T2052-81370	• SHAFT ASSY	1	
16	2670-81410	• SPRING	1	
17	3310-81341	• THROTTLE VALVE	1	
18	2880-81470	• SCREW	1	
19	3310-81351	• SCREW	4	
20	3080-81320	• SPRING	1	
21	2870-81330	• HIGH SPEED NEEDLE	1	
22	1480-81420	• PLUG	1	
23	2630-81440	• LEVER	1	
24	1148-81390	• RING	1	
25	3310-81360	• SCREW	1	
26	T2050-06020	GASKET/DIAPHRAGM KIT	1	
27	3606-52113	BAR12"	1	
28	3607-52112	BAR14"	1	
29	3602-52210	CHAIN 91SG-52E	1	14"
30	3606-52211	CHAIN 91VG-45E	1	12"
31	2873-97110	PROTECTOR	1	
32	2873-91140	WRENCH	1	
33	T2052-93110	MANUAL	1	



**KOMATSU ZENOAH CO.**

1-9 Minamidai, Kawagoe, Saitama, 350-1192 Japan