


Abschnitt: TURBO 35 EL CHASSIE

Pos.	Anzahl		Ersatzteilnr.	Bezeichnung	Satz	Anm.	Neu
	3762	3763	3862	3867			
1	1	1	1	1	1111-1310-01	Messerbalken Kompl	
2	1	1			1111-9046-01	.Messersatz	
2			1	1	1111-9504-01	.Messersatz	
3	2	2	2	2	9997-0812-16	..Schraube	
4	2	2	2	2	9747-0831-02	..Mutter	
6	1	1	1	1	1111-0572-00	Messerbolzen	
7	1	1	1	1	1111-1419-01	Messerschlüssel	
8	1	1	1	1	1111-1309-01	Messerhalterung	
10	4	4	4	4	9997-0816-16	Schraube	
11	4	4	4	4	9699-0090-02	Scheibe	
12	2	2	2	2	9836-9512-12	Schraube	
13	1	1	1	1	1111-1290-01	Motorgehäuse	
15	1	1	1	1	9579-0007-00	Kabelhalter	
16	2	2	2	2	9849-7819-16	Schraube	
17	1	1	1	1	9600-0132-00	Keil	
18	1	1	1	1	9500-1100-00	El-motor	
19	1	1	1	1	9400-0166-00	.Kondensator	
20	1	1	1	1	1111-1396-01	Indikator	
21	1	1	1	1	1111-1384-01	Motorhaube-schwarz	
22	2	2	2	2	9849-7819-16	Schraube	
23	2	2	2	2	9699-0002-02	Scheibe	
25	1	1	1	1	1111-1294-01	Chassie	
26	1	1	1	1	1111-1296-01	Halterung	
27	2	2	2	2	9836-9512-12	Schraube	
28	2	2	2	2	9840-8019-16	Schraube	
30	1	1	1	1	1111-1298-01	Lenkstift	
31	2	2	2	2	9672-0005-02	Verriegelungsscheib	
32	2	2	2	2	1111-1300-01	Federhalter	
33	1	1	1	1	1111-1299-01	Feder	
34	1	1	1	1	1111-1297-01	Klappe	
35		1			1111-1453-01	Schutz	Finland (FIN)
37	1	1	1	1	1111-1315-01	Vorderstück	Ej 3862-55
38	2	2	2	2	9865-0510-16	Schraube	Ej 3862-55
39	2	2	2	2	9699-0099-02	Scheibe	Ej 3862-55
40	2	2	2	2	9747-0531-02	Mutter	Ej 3862-55
42	1	1	1	1	1111-1314-01	Grasfangsack	Ej 3862-55
43	10	10	10	10	9845-7913-16	Schraube	Ej 3862-55
45	1	1	1	1	1111-1392-01	Griff	Ej 3862-55
46	2	2	2	2	9403-0034-70	.Plastikknopf	
47	1	1	1	1	9403-0033-70	.Plastikknopf	
48	1	1	1	1	9839-8013-16	Schraube	Ej 3862-55
50	1	1	1	1	1111-1295-01	Leitschiene	
51	1	1	1	1	9836-9516-12	Schraube	
52	2	2	2	2	9836-9520-12	Schraube	
54	1	1	1	1	1111-1411-01	Schutz	
55	4	4	4	4	9836-9512-12	Schraube	
99	1	1			1111-2233-06	Aufklebersatz	



STIGA
169B
SPARE PARTS

Abschnitt: TURBO 35 EL RADAUFHÄNGUNG

Pos.	Anzahl		Ersatzteilnr.	Bezeichnung	Satz Anm.	Neu	
	3762	3763	3862	3867			
1	2	2		1111-1301-03	Radachse		
1			2	2	1111-1301-02	Radachse	
2	2	2	2	2	1111-1356-01	Halterung	
3	2	2	2	2	1111-1389-01	Halterung	
4	4	4	4	4	9836-9512-12	Schraube	
6	1	1	1	1	1111-1306-01	Feder	
7	2	2	2	2	9675-0008-02	Verriegelungsscheib	
8	1	1	1	1	1111-1305-01	Zugstange	
9	1	1	1	1	9747-0531-02	Mutter	
10	1	1	1	1	9997-0512-16	Schraube	
12	1	1	1	1	1111-1307-01	Regulierhebel	
13	1	1	1	1	1111-1308-01	Griff	
14	1	1	1	1	9849-7909-16	Schraube	
15	1	1	1	1	1111-1630-01	Segment	
17			4	4	9699-0028-02	Scheibe	
18	4	4	4	4	1111-1304-01	Radbuchse	
19	4	4	4	4	1111-2656-01	Rad	
20	4	4	4	4	9699-0112-02	Scheibe	
21	4	4	4	4	1111-1391-01	Feder	
22	4	4	4	4	9675-0012-02	Verriegelungsscheib	
23	4	4	4	4	1111-1335-01	Radkappe	
25	2	2	2	2	9847-8013-16	Schraube	
26	2	2	2	2	1111-1444-03	Führungrohr-Untert	
27	2	2	2	2	1111-1445-01	Führungsholm-Mitter	
28	2	2	2	2	1111-0035-01	.Verriegelungsrads	
28	2	2	2	2	1111-9030-02	Steuerbolzen	
29	2	2	2	2	9699-0025-02	.Scheibe	
30	2	2	2	2	9899-3545-12	.Schraube	
31	1	1	1	1	1111-1447-01	Führungsholm-Obert.	
32	2	2	2	2	9403-0033-70	Plastikknopf	
35		1			9400-0164-04	Schalter	Sverige, Finland
35			1		9400-0164-02	Schalter	
35				1	9400-0164-03	Schalter	
36	2	2	2	2	9843-7813-16	.Schraube	
37		1			1111-0821-01	Leitungsstecker	Sverige, Finland
38	2	2	2	2	9579-0008-00	Kabelhalter	
40	1	1	1	1	1111-1418-01	Frontblech	
41	4	4	4	4	9847-8019-16	Schraube	
45	1	1	1	1	9579-0009-00	Kabelhalter	
50	1	1			1111-1431-01	Seitenschutz-R	
50	1	1			1111-1430-01	Seitenschutz-L	